

Workshop Manual Audi A6 2011 ➤ Audi A6 China 2012 ➤ Audi A7 Sportback 2011 ➤

Running gear, front-wheel drive and four-wheel drive

Edition 12.2018



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



List of Workshop Manual Repair Groups

Repair Group

- 00 Technical data
- 40 Front suspension
- 42 Rear suspension
- 43 Self-levelling suspension
- 44 Wheels, tyres, vehicle geometry
- 48 Steering



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Technical information should always be available to the foremen and mechanics, because their careful and constant adherence to the instructions is essential to ensure vehicle road-worthiness and safety. In addition, the normal basic safety precautions for working on motor vehicles must, as a matter of course, be observed.



Contents

00 - Tech	nnical data	1
1	General notes	1
1.1	General notes on Tyre Pressure Loss Indicator (TPLI+)	1
1.2	General notes on dynamic steering	2
1.3	General notes on drive shaft	3
2	Safety precautions	
_		4
2.1	Safety precautions when working on vehicles with high-voltage system	4
2.2	Safety precautions when working in the vicinity of high-voltage components	5
2.3	Safety precautions when working on vehicles with start/stop system	5
2.4	Safety precautions when working on subframe	5
2.5	Safety precautions when using testers and measuring instruments during a road test	5
3	Repair notes	6
3.1	Leaks at shock absorbers	6
3.2	Checking shock absorbers when removed	7
3.3	Checking shock absorbers on shock tester	7
3.4	Maximum values "a" in mm	9
3.5	Rules for cleanliness	10
3.6	General notes	10
3.7	General repair instructions	11
3.8	Contact corrosion	11
3.9	Steering rack	11
3.10	Gaskets and seals	11
3.11	Bolts and nuts	12
		12
Protected by cop 3.13	Electrical components yright. Copying for private or commercial purposes, in part or in whole, is not Repairing damaged threads in longitudinal member (subframe to body)	12
ان. د permitted anlas	Lifting suspension to unladen position to which some with some suspension to unladen position to which some suspension to unladen position.	12
	Lifting suspension to reference position (vehicles with air suspension)	15
3.16	Raising and lowering vehicle when air spring system has / has not been opened	18
4	Technical data	20
4.1	Running gear	20
4.2	Steering	23
5	Disposal	24
5.1	Releasing gas and draining front gas-filled shock absorbers	24
5.2	Releasing gas and draining rear gas-filled shock absorbers	
5.3	Discharging front suspension strut (air suspension)	
5.4	Discharging accumulator	
40 - Fron	t suspension	27
1	Front axle	27
1.1	Overview - front axle	27
2	Subframe	28
2.1	Exploded view - subframe	28
2.1	·	
2.2	Lowering subframe	30
	Removing and installing subframe with steering rack	40
2.4	Removing and installing subframe cross brace	51
2.5	Removing and installing subframe shield	52
2.6	Removing and installing anti-roll bar	53
2.7	Removing and installing coupling rod (for anti-roll bar)	55
3	Suspension strut, upper links	57
3.1	Exploded view - suspension strut, upper links	57
3.2	Removing and installing suspension strut	59
3.3	Servicing suspension strut	66



3.5	Removing and installing upper links	
3.6	Charging suspension strut	
3.7		
3.8		87
4		89
•		
4.2	•	
4.3		
4.4		
4.5	Removing and installing swivel joint	103
4.6	Removing and installing bonded rubber bush for guide link	104
5	Wheel bearing	108
5.1	Exploded view - wheel bearing	
5.2	Removing and installing wheel bearing housing	110
5.3	Removing and installing wheel bearing unit	113
5.4	Servicing wheel bearing unit	115
6	Drive shaft	120
6.1	Overview - drive shaft	
6.2	Exploded view - drive shaft	120
6.3	Removing and installing drive shaft	
6.4	Loosening and tightening bolt securing drive shaft	124
6.5	Dismantling and assembling drive shaft	125
6.6	Servicing constant velocity joint	
6.7	· · · · · · · · · · · · · · · · · · ·	
6.8	Tightening hose clip on triple roller joint and outer joint	133
Rear	suspension	136
	•	
	Neal axie	130
11	Overview - rear axle	136
1.1	Overview - rear axle	
2	Subframe	138
2 2.1	Subframe Exploded view - subframe	138 138
2 2.1 2.2	Subframe Exploded view - subframe Fixing position of subframe	138 138 141
2 2.1 2.2 2.3	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe	138 138 141 146
2 2.1 2.2 2.3 2.4	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe	138 138 141 146 158
2 2.1 2.2 2.3 2.4 3	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar	138 138 141 146 158 200
2 2.1 2.2 2.3 2.4 3 3.1	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar	138 138 141 146 158 200
2 2.1 2.2 2.3 2.4 3 3.1 P3.2ecte	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar exploded view - anti-roll bar explored and installing anti-roll bar commercial purposes, in part or in whole, is not	138 141 146 158 200 200 200
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Exploded view - anti-roll bar Servicing and installing anti-roll bar commercial purposes, in part or in whole, is not	138 138 141 146 158 200 200 200 203
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Exploded view - anti-roll bar commercial purposes, in part or in whole, is not esuspension links, track rod AG. AUDI AG does not guarantee or accept any liability Exploded viewe transverse links ion in this document. Copyright by AUDI AG.	138 138 141 146 158 200 200 200 203 203
2 2.1 2.2 2.3 2.4 3 3.1 3.2 2.2 2.4 4.2	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar exploded view - anti-roll bar commercial purposes, in part or in whole, is not explosed view - anti-roll bar commercial purposes, in part or in whole, is not explosed view extrack rod AG. AUDI AG does not guarantee or accept any liability of Exploded view extransverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link	138 138 141 146 158 200 200 200 203 203 205
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Removing and installing anti-roll bar Suspension links, track rod AG. AUDI AG does not guarantee or accept any liability Exploded view - transverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link Removing and installing lower transverse link	138 138 141 146 158 200 200 203 203 203 205 207
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte 24.7 mitt v4t1 res 4.2 4.3 4.4	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Exploded view - anti-roll bar Exploded view - anti-roll bar Suspension links, track rod AG. AUDI AG does not guarantee or accept any liability Exploded view extransverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing lower transverse link Removing and installing track rod	138 138 141 146 158 200 200 203 203 203 205 207 212
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte 94 rmitt v4th res 4.2 4.3	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - transverse links ion in this document. Copyright by AUDI.AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring	138 138 141 146 158 200 200 203 203 205 207 212 215
2 2.1 2.2 2.3 2.4 3 3.1 73.2 ectes 94 rmitt v4th res 4.2 4.3 4.4 5	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Exploded view - anti-roll bar Removing and installing anti-roll bar ommercial purposes, in part or in whole, is not suspension links, track rod AG. AUDI AG does not guarantee or accept any liability Exploded view - stransverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring Exploded view - suspension strut/shock absorber, spring	138 138 141 146 158 200 200 203 203 205 207 212 215 215
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte 4.7 4.1 res 4.2 4.3 4.4 5 5.1	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - transverse links ion in this document. Copyright by AUDI.AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring	138 138 141 146 158 200 200 203 203 205 207 212 215 220
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte 4.7 v4t1 res 4.2 4.3 4.4 5 5.1 5.2	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - track rod AG. AUDI AG does not guarantee or accept any liability Exploded view - transverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring Exploded view - suspension strut/shock absorber, spring Modifying spring compressing system	138 138 141 146 158 200 200 203 203 205 207 212 215 220 223
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte 4.7 mitt v4:1 res 4.2 4.3 4.4 5 5.1 5.2 5.3	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Removing and installing anti-roll bar commercial purposes, in part or in whole, is not esuspension links, track rod AG. AUDI AG does not guarantee or accept any liability Exploded view extransverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring Exploded view - suspension strut/shock absorber, spring Modifying spring compressing system Removing and installing shock absorber	138 138 141 146 158 200 200 203 203 205 207 212 215 225 220 223 227
2 2.1 2.2 2.3 2.4 3 3.1 3.2 ecte 4.7 mitt v4:1 res 4.2 4.3 4.4 5 5.1 5.2 5.3 5.4	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Removing and installing anti-roll bar Exploded view - transverse links ion in this document. Copyright by AUDI.AG. Removing and installing lower transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring Exploded view - suspension strut/shock absorber, spring Modifying spring compressing system Removing and installing shock absorber Servicing shock absorber	138 138 141 146 158 200 200 203 203 205 207 212 215 220 223 227 230
2 2.1 2.2 2.3 2.4 3 3.1 3.2 2ctc 4.7 4.1 res 4.2 4.3 4.4 5 5.1 5.2 5.3 5.4 5.5	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Exploded view - anti-roll bar Removing and installing anti-roll bar Suspension links, track rod AG. AUDI AG does not guarantee or accept any liability Exploded view - transverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring Exploded view - suspension strut/shock absorber, spring Modifying spring compressing system Removing and installing shock absorber Servicing shock absorber Removing and installing spring	138 138 141 146 158 200 200 203 203 205 207 215 220 223 227 230 240
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte v4:1 res 4.2 4.3 4.4 5 5.1 5.2 5.3 5.4 5.5 6	Subframe Exploded view - subframe Fixing position of subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Removing and installing anti-roll bar Removing and installing anti-roll bar on mercial purposes, in part or in whole, is not suspension links, track rod AG. AUDI AG does not guarantee or accept any liability Exploded view - transverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring Exploded view - suspension strut/shock absorber, spring Modifying spring compressing system Removing and installing shock absorber Servicing shock absorber Removing and installing spring Wheel bearing, trailing arm Exploded view - wheel bearing Removing and installing wheel bearing housing	138 138 141 146 158 200 200 203 203 205 207 212 215 220 223 227 230 240 240 243
2 2.1 2.2 2.3 2.4 3 3.1 P3.2 ecte 4.7 4.1 res 4.2 4.3 4.4 5 5.1 5.2 5.3 5.4 5.5 6 6.1	Subframe Exploded view - subframe Removing and installing subframe Servicing subframe Anti-roll bar Exploded view - anti-roll bar Removing and installing anti-roll par ommercial purposes, in part or in whole, is not esuspension links, track rod AG. AUDI AG does not guarantee or accept any liability Exploded view - transverse links ion in this document. Copyright by AUDI AG. Removing and installing upper transverse link Removing and installing lower transverse link Removing and installing lower transverse link Removing and installing track rod Suspension strut/shock absorber, spring Exploded view - suspension strut/shock absorber, spring Modifying spring compressing system Removing and installing shock absorber Servicing shock absorber Removing and installing spring Wheel bearing, trailing arm Exploded view - wheel bearing	138 138 141 146 158 200 200 203 203 205 207 212 215 220 223 227 230 240 240 243 250
	3.7 3.8 4.1 4.2 4.3 4.4 4.5 5.1 5.2 5.3 5.4 6.1 6.2 6.3 6.4 6.5 6.6 6.7 6.8	3.7 Removing and installing shock absorber fork 3.8 Removing and installing body brace 4 Lower suspension links, swivel joint 4.1 Exploded view - lower suspension links, swivel joint 4.2 Removing and installing track control link 4.3 Removing and installing guide link 4.4 Renewing bush for track control link 4.5 Removing and installing swivel joint 4.6 Removing and installing bonded rubber bush for guide link 5 Wheel bearing 5.1 Exploded view - wheel bearing 5.2 Removing and installing wheel bearing housing 5.3 Removing and installing wheel bearing unit 5.4 Servicing wheel bearing unit 6 Drive shaft 6.1 Overview - drive shaft 6.2 Exploded view - drive shaft 6.3 Removing and installing drive shaft 6.4 Loosening and tightening bolt securing drive shaft 6.5 Dismantling and assembling drive shaft 6.6 Servicing constant velocity joint 6.7 Checking outer constant velocity joint 6.8 Tightening hose clip on triple roller joint and outer joint Rear suspension



6.5	Renewing bonded rubber bushes for wheel bearing housing	258
7	Drive shaft	267
7.1	Exploded view - drive shaft	267
7.2	Removing and installing drive shaft	269
7.3	Loosening and tightening bolt securing drive shaft	
7.4	Renewing constant velocity joint	
7.5	Checking outer constant velocity joint	
7.6	Checking inner constant velocity joint	
7.0	Checking little constant velocity joint	213
43 - Self-le	evelling suspension	282
1	Electronic damping control	
1.1	Overview of fitting locations - electronic damping control	
1.2	Re-adapting reference position (default position)	
1.3	Bleeding or charging system	
2	Vehicle level senders	
2.1	Exploded view - vehicle level senders	
2.2	Removing and installing front vehicle level senders G78 / G289	
2.3	Removing and installing rear vehicle level senders G76 / G77	287
3	Air suspension	288
3.1	Overview of fitting locations - electrical components	
3.2	Exploded view - air supply unit	
Protected 3.3 cop	Exploded view rain pipes r commercial purposes, in part or in whole, is not	
permitted 3.4	, , , , , , , , , , , , , , , , , , ,	
3.5	Servicing air pipe	296
with resp 3.6 to t	Servicing air pipe Renewing connection piece in this document. Copyright by AUDI AG.	300
3.7	Removing and installing air supply unit	
3.8	Removing and installing adaptive suspension drain valve N111	
3.9	Removing and installing solenoid valve block	
3.10	Removing and installing intake pipe with filter	
3.11	Removing and installing accumulator	
4	Dynamic Ride Control (DRC)	
4.1	System description - DRC	
4.1	Overview of fitting locations - DRC	
4.2 4.3		
	Exploded view - central valve	
4.4	Removing and installing central valve	
4.5	Removing and installing electronically controlled damping control unit J250	
4.6	Checking DRC system	
4.7	Checking DRC system pressure	
4.8	Discharging and charging DRC system	318
44 - Whee	els, tyres, vehicle geometry	329
	•	
1	Wheels, tyres	
2	Wheel alignment	
2.1	Notes on wheel alignment	
2.2	Test requirements	
2.3	Preparations for measurement	332
2.4	Wheel alignment specifications	
2.5	Wheel alignment procedure	
2.6	When does wheel alignment have to be checked?	344
2.7	Explanatory notes on production control numbers (PR numbers)	345
2.8	Adjusting camber at front wheels	346
2.9	Adjusting camber at rear wheels	349
2.10	Adjusting toe setting at rear wheels	
2.11	Adjusting toe setting at front wheels	
2.12	Wheel runout compensation	



	2.13 2.14	Checking full steering lock	
	3	Dynamic steering	
	3.1	Exploded view - dynamic steering	
	3.2	Removing and installing active steering control unit J792	
	3.3	Basic setting for dynamic steering	
	4	Adaptive cruise control	
	4.1	Adjusting adaptive cruise control	
	5	Front camera for driver assist systems	
	5.1	Calibrating front camera for driver assist systems	365
	6	Night vision system	371
	6.1	Calibrating night vision system	371
18 -	Steeri	ing	378
	1	Steering wheel	
	1.1	Exploded view - steering wheel	
	1.2	Removing and installing steering wheel	
	2		
	2.1	Steering column	
	2.1	Exploded view - steering column	
	2.2	Checking steering column for damage	
	2.3	Removing and installing steering column	
	2.5	Removing and installing safety lock for active steering (locking solenoid)	
	2.6	Removing and installing intermediate steering shaft	
	2.7	Removing and installing control unit for electronic steering column lock J764	
	2.8	Removing and installing control unit for electrically adjustable steering column J866	
	3	Steering rack	
		•	
	3.1 3.2	Exploded view - steering rack	
	3.3	Removing and installing steering rack	
	3.4	Removing and installing boot	
	3.5	Removing and installing track rod	
	0.0	INCHIOVING AND INSTAINING HACK TOO DAIL JUHL	44



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



00 – Technical data

1 General notes

(ARL006212; Edition 12.2018)

⇒ "1.1 General notes on Tyre Pressure Loss Indicator (TPLI+)", page 1

⇒ "1.2 General notes on dynamic steering", page 2

⇒ "1.3 General notes on drive shaft", page 3

1.1 General notes on Tyre Pressure Loss Indicator (TPLI+)

Please observe the instructions in the ⇒ Owner's Manual .

The Tyre Pressure Loss Indicator uses information from the ABS speed sensors to compare the rolling circumference and the vibration characteristics of the individual wheels. Any changes on one or more wheels are indicated on the dash panel display. If only one tyre is affected, the tyre position is indicated.

The Tyre Pressure Loss Indicator is a software module in the ABS/ESP control unit designed to detect gradual losses of tyre pressure at one wheel. Using the signals from the ABS speed sensors, the TPLI+ compares the wheel speeds and thus the rolling circumference of the individual wheels. The corresponding display in the instrument cluster lights up if the rolling circumference of one of the wheels changes. The rolling circumference of the tyre may change under the following circumstances:

- If the tyre pressure is too low.
- ♦ If the tyre has structural damage.
- If the wheels or the inflation pressures have been changed and the new tyre pressures not saved.
- If the vehicle is loaded unevenly.
- If the wheels of one axle are subjected to a greater load (e.g. when pulling a trailer or when driving uphill and downhill).
- ◆ If snow chains are fitted pying for private or commercial purposes, in part or in whole, is not
- ◆ µlf-the temporary spare wheel/is lfitted.G. AUDI AG does not guarantee or accept any liability
- If one wheel has been changed on each laxle (this also inent. Copyright by AUDI AG. cludes changing round the wheels from front to rear or vice versa).
- If the left and right wheels run on different surfaces for a sustained period of time.

If the Tyre Pressure Loss Indicator lights up:

The Tyre Pressure Loss Indicator on the instrument cluster indicates if the tyre pressure is too low or if a system malfunction has occurred.

System fault in Tyre Pressure Loss Indicator (TPLI+):

If the warning lamp flashes for about 1 minute after switching on the ignition and then remains steadily lit, there is a system fault. "TPMS" also appears in the instrument cluster.

A system fault is stored in the event memory of the ABS/ESP control unit and indicated by the yellow warning lamp in the instrument cluster remaining continuously lit. The warning lamp cannot be turned off by pressing the button on the multimedia



system operating unit - E380- . Proceed as follows if a fault is stored in the event memory:

- Connect vehicle diagnostic tester and select <u>Guided Fault</u>
 Finding.
- Select the relevant program in Guided Functions.
- Follow the instructions on the screen.

Performing calibration (re-adaption of tyre pressure):

The tyre pressures must be stored in the MMI following any changes to the inflation pressures or after changing a tyre on the vehicle.

 Switch on ignition, press "CAR" function selector button, turn rotary pushbutton on multimedia system operating unit - E380to select tyre pressure monitoring and press rotary pushbutton to save tyre pressure.

1.2 General notes on dynamic steering

In conventional steering systems there is a direct mechanical connection between the steering wheel and the steering rack. This dictates a fixed ratio between the steering wheel lock angle and the turn angle of the steered wheels. In this design, only one steering ratio can be implemented on a vehicle at a time. Selecting the appropriate ratio always represents a compromise in meeting the different - and sometimes conflicting - requirements.

The key requirements can only be fully met by a variable steering ratio. A ratio of this kind varies the actual turn angle of the wheels depending on the vehicle speed and steering angle. The dynamic steering system basically employs two variable steering ratios, with comfort and performance-oriented characteristics respectively.

The variable ratios are achieved by means of an additional electro-mechanical drive of the steering pinion, which is superimposed on the steering input from the driver. In an emergency - that is, if this drive fails - the steering operates just like a conventional steering system. The mechanical connection between the steering wheel and the front axle is not broken.

However, there are many other advantages to dynamic steering. In interaction with the ESP and its sensors, the system is also activated when critical driving states are impending. By targeted variation of the front wheel turn angle, the dynamic steering system assists the ESP at the limits of the vehicle's handling.

The "adjuster" on the steering column is permanently installed. The steering column must be renewed if the "adjuster" is defective.

The basic setting for the dynamic steering system must be performed correctly to ensure proper functioning.



Note

The steering angle sender - G85- must be calibrated using the steering wheel balance - VAS 6458- before the basic setting can be performed.

The basic setting must be performed if:

- ◆ The active steering control unit = J792 has been renewed! purposes, in part or in whole, is not
- ◆ The front axle tole setting has been changed UDI AG does not guarantee or accept any liability
- The rear axle toe setting has been changed ion in this document. Copyright by AUDI AG.



- The steering angle sender G85- has been calibrated.
- The steering column has been renewed.
- The steering wheel is not straight when driving in a straight line.



Note

Before performing the basic setting on the dynamic steering system, check the event memory and rectify any faults. The basic setting for the dynamic steering system must always be performed using the wheel alignment equipment approved by VW/Audi. The basic setting for the dynamic steering system must always be performed using the wheel alignment equipment approved by VW/Audi. The basic setting system must always be performed using the wheel alignment equipment approved by VW/Audi.

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

1.3 with respe General notes on drive shaft this document. Copyright by AUDI AG.

Wheel bearings must not be subjected to load after loosening bolt securing drive shaft at wheel hub.

If the wheel bearings are subjected to the full weight of the vehicle they will be overloaded, resulting in reduced service life. Therefore please note the following:

 ◆ Procedure for slackening bolt securing drive shaft to wheel hub ⇒ page 124

Do not attempt to move the vehicle without the drive shafts fitted; this would result in wheel bearing damage. If the vehicle does have to be moved, always note the following points:

- Fit an outer joint in place of the drive shaft.
- Tighten the outer joint to 200 Nm.

Do not let drive shaft hang down under its own weight when performing repair work, as otherwise excessive bending could damage inner CV joint.

an

2 Safety precautions

- ⇒ "2.1 Safety precautions when working on vehicles with high-voltage system", page 4
- \Rightarrow "2.2 Safety precautions when working in the vicinity of high-voltage components", page 5
- \Rightarrow "2.3 Safety precautions when working on vehicles with start/ stop system", page 5
- ⇒ "2.4 Safety precautions when working on subframe", page 5
- ⇒ "2.5 Safety precautions when using testers and measuring instruments during a road test", page 5

2.1 Safety precautions when working on vehicles with high-voltage system

High voltage! Danger to life!

The voltage levels in the high-voltage system constitute a safety hazard. Danger of severe or fatal injuries from electric shock.

- Persons with life-sustaining or other electronic medical devices in or on their body must not perform any work on the high-voltage system. Such medical devices include internal analgesic pumps, implanted defibrillators, pacemakers, insulin pumps and hearing aids.
- The high-voltage system must be de-energised by a suitably qualified person.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

Risk of injury - engine may start unexpectedly

It is difficult to determine whether the drive system of an electric vehicle or hybrid vehicle is active. Moving parts can trap or draw in parts of the body and/or clothing (safety hazard).

- Switch off ignition.
- Place ignition key outside vehicle interior.

Risk of damage to high-voltage wiring

Incorrect handling may result in damage to the insulation of high-voltage wires or high-voltage connectors.

- Never use high-voltage wiring or high-voltage connectors as a support.
- Never prop tools against high-voltage wiring or high-voltage connectors.
- Never bend or kink high-voltage wiring.
- Pay attention to coding when connecting high-voltage connections.



2.2 Safety precautions when working in the vicinity of high-voltage components

High voltage! Danger to life!

The voltage levels in the high-voltage system constitute a safety hazard. Danger of severe or fatal injuries from electric shock if high-voltage components or high-voltage wiring are damaged.

- Carry out visual check of high-voltage components and high-voltage wiring.
- Never use cutting/forming tools or other sharp-edged implements
- Never perform work using welding, brazing, thermal bonding or hot air.

2.3 Safety precautions when working on vehicles with start/stop system

Risk of injury - engine may start unexpectedly

The engine can start unexpectedly if the vehicle's start/stop system is activated. A message in the instrument cluster indicates whether the start/stop system is activated.

To deactivate the start/stop system, switch off the ignition.

2.4 Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Safety precautions when working on subframe permitted unless authorised by AUDI AG, AUDI AG does not guarantee or accept any liability

Risk of damage to components

ness of information in this document. Copyright by AUDI AG.

Lowering the vehicle onto its wheels can damage components if the assembly mountings, steering rack or subframe cross brace are not properly fitted.

- Never lower vehicle onto its wheels with suspension components unfastened or detached.
- Never support weight of vehicle on subframe or subframe cross brace with suspension components unfastened or detached.

2.5 Safety precautions when using testers and measuring instruments during a road test

Risk of injury if test equipment is not secured

If an accident occurs and the front passenger's airbag is triggered, test equipment which is not secured adequately may be catapulted through the vehicle with potentially serious consequences.

Secure test equipment to the rear seat.

Or

 Have another person operate the test equipment from the rear seat.



3 Repair notes

- ⇒ "3.1 Leaks at shock absorbers", page 6
- ⇒ "3.2 Checking shock absorbers when removed", page 7
- ⇒ "3.3 Checking shock absorbers on shock tester", page 7
- ⇒ "3.4 Maximum values "a" in mm", page 9
- ⇒ "3.5 Rules for cleanliness", page 10
- ⇒ "3.6 General notes", page 10
- ⇒ "3.7 General repair instructions", page 11
- ⇒ "3.8 Contact corrosion", page 11
- ⇒ "3.9 Steering rack", page 11
- ⇒ "3.10 Gaskets and seals", page 11
- ⇒ "3.11 Bolts and nuts", page 12
- ⇒ "3.12 Electrical components", page 12
- ⇒ "3.13 Repairing damaged threads in longitudinal member (subframe to body)", page 12
- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not
 ⇒ "3.14 Lifting suspension to unladen position vehicles with coil
 springs" page 12 ess authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
- ⇒ "3"15 Lifting suspension to reference position (vehicles with air. Copyright by AUDI AG. suspension)", page 15
- ⇒ "3.16 Raising and lowering vehicle when air spring system has / has not been opened", page 18

3.1 Leaks at shock absorbers

Shock absorbers are often replaced because of externally visible leakage. Inspections on the test rig and in the vehicle have shown that in the majority of cases this renewal is not justified.


Slight loss of fluid ("sweating") at the piston rod seal is not a reason for renewing a shock absorber. A shock absorber with slight fluid leakage can be accepted as OK under the following conditions:



Note

Slight fluid leakage is actually beneficial, as it lubricates the piston rod seal and thus extends the life of the shock absorber. This applies to shock absorbers on both the front and rear axles.


- Fluid seepage (as shown in the shaded part of the illustration -arrow-) is visible, but the fluid is dull and possibly dried by dust
- A thin film of fluid or dirt has formed on one side; no drips.





A shock absorber cannot be accepted as OK if the following occurs:

- Drips running down the side -arrow-; large area wet with fluid.
- If the shock absorber has a wet film of fluid running down the side of the tube, it is leaking and must be renewed.



Checking shock absorbers when removed

Defective shock absorbers can be identified by loud rumbling noises when driving, caused by wheel hopping, especially on bad roads. Heavy fluid leakage is an additional visual indication.



Note

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Shock absorbers are maintenance-free; shock absorber fluid cannot be topped up. unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

with respect to the correctness of information in this document. Copyright by AUDI AG.

After removal, a shock absorber can be checked by hand as follows:

- Compress shock absorber by hand.
- The piston rod should move smoothly over the entire stroke with uniform resistance and without jolts.
- Release piston rod.
- If the shock absorber has sufficient gas pressure the piston rod will return by itself to its original position.



Note

- If this is not the case, the shock absorber does not necessarily need to be renewed. Provided there has been no major loss of fluid, it will still be as effective as a conventional shock absorber.
- Even without gas pressure, the shock absorber will provide full damping effect as long as there has been no major loss of fluid. However, it may produce more noise.

3.3 Checking shock absorbers on shock tester

The shock tester allows shock absorbers to be tested without removing them from the vehicle. The damping effect can be assessed on the basis of the pointer deflection or the print-out.

Special tools and workshop equipment required



- Maha shock absorber tester VAS 1990-
- Suspension strut test stand VAS 6636-
- Suspension strut test stand VAS 6640-

Test requirements

- Temperature: +10...+40 °C.
- · Driver in vehicle
- Tyre pressure OK.
- Wheels of vehicle in a central and straight position on the tyre contact plates
- · Front wheels in straight-ahead position
- Electromechanical parking brake released, foot brake not applied.

Test results

The condition of the shock absorbers can only be evaluated as follows:

Satisfactory damping effect

Or

Unsatisfactory damping effect



Note

- It is not possible to obtain intermediate readings specifying the
 exact degree of impairment of damping effect rivate or commercial purposes, in part or in whole, is not
- ♦ A forecast of the remaining service life is not permissible. G does not guarantee or accept any liability
- ♦ Test results will be falsified if the suspension contacts the his document. Copyright by AUDI AG. bump stops when the readings are taken.

The following values apply only to tests conducted on the test equipment listed above. If the maximum values listed below are exceeded, the effectiveness of the shock absorber has deteriorated significantly and renewal is recommended.


Example:

Maximum value = 70

- a = higher than 70: unsatisfactory damping effect
- a = lower than 70: satisfactory damping effect

The damper combinations fitted in the vehicle are indicated by the corresponding PR number on the vehicle data sticker.

Explanatory notes on weight codes used in production (PR nos.) ⇒ page 345.





3.4 Maximum values "a" in mm



Note

- ♦ If the reading is higher than the maximum value "a" listed in the table, the damping effect is unsatisfactory ⇒ renew the shock absorber.
- ♦ If the reading is lower than the maximum value "a" listed in the table, the damping effect is satisfactory ⇒ the shock absorber does not have to be renewed.

Vehicle type	Front axle	Rear axle	Remarks
Air suspension, standard running gear 1BK with 17" and 18" tyres ¹⁾	42	52	Unladen Tank full
Air suspension, standard running gear 1BK with 19" and 20" tyres ¹⁾	40	40	Unladen Tank full
Air suspension, sports running gear 2MB	t.b.a.	t.b.a.	Unladen Tank full
Standard running gear 1BA	46	46	Unladen Tank full
Sports running gear 1BE	40	40	Unladen Tank full
Heavy-duty running gear 1BB	t.b.a.	t.b.a.	Unladen Tank full
Standard running gear 1BH	t.b.a.	t.b.a.	Unladen Tank full
Heavy-duty running gear 1BR	t.b.a.	t.b.a.	Unladen Tank full
Air suspension, heavy- duty running gear 1BS	t.b.a.	t.b.a.	Unladen Tank full
Sports running gear 1BV	40	40	Unladen Tank full
allroad 1BY	t.b.a.	t.b.a.	Unladen Tank full
Air suspension, RS run- ning gear 2MA	t.b.a.	t.b.a.	Unladen Tank full
Air suspension, sports running gear 2MB	t.b.a.	t.b.a.	Unladen Tank full
RS running gear 2MC Protected by copyrig.	t.b.a. ht. Copying for private or con	t.b.a. nmercial purposes, in part or	Unladen in whole, Tank full

 ¹⁾ Vehicle at normal level setting; test must not be carried guarantee or accept any liability out in advantage mode or with vehicle raised to high suspension level.

Test must be carried out with tyre inflation pressures for "part load".



3.5 Rules for cleanliness

- Thoroughly clean all joints and connections and the surrounding areas before disconnecting.
- Ensure proper seating of dowel sleeves for centralising suspension bracket and steering rack when installing.
- Place removed parts on a clean surface and cover them up to keep them clean. Use plastic sheeting or paper for this purpose. Only use lint-free cloths.
- Only install clean components; replacement parts should only be unpacked immediately prior to installation.
- Use only the grease and sealants with the part number stated.
- Carefully cover or seal open components if repairs cannot be carried out immediately.

3.6 General notes



CAUTION

Risk of damage to threads in body.

- ♦ DO NOT use an impact wrench when loosening or tightening bolts and nuts on any chassis components.
- Always start the first few threads of bolts and nuts by hand.
- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not contact surfaces must be cleaned when installing wax-coated components. The contact surfaces must be free of waxs not guarantee or accept any liability and grease.

 With respect to the correctness of information in this document. Copyright by AUDI AG.
- Tightening torques refer to unoiled bolts and nuts.
- Always renew self-locking bolts/nuts.
- Always renew bolts and nuts which are tightened by turning through a specified angle.
- Load-bearing components and other suspension parts must not be welded or straightened.
- Do not subject coil springs to hammer blows or weld splashes and do not make any new colour markings.
- Do not perform welding or cutting operations (using power grinders) near the coil springs or suspension struts. Cover up coil springs or suspension struts if necessary.
- Make sketches or take photographs when unfastening or removing and installing hydraulic and pneumatic lines or electrical wires. This ensures re-installation at the original location.
- Any cable ties, brackets or fasteners removed during repair work must be re-attached at their original standard locations.
- ◆ Before fitting the outer joint in the wheel hub, apply a thin coat of assembly paste to the splines on the outer joint ⇒ Electronic parts catalogue.
- When working on the vehicle, do not allow the drive shafts to hang down under their own weight and never let the joints bend to such an extent that they contact the end stop.
- Do not attempt to move the vehicle without the drive shafts fitted; this would result in wheel bearing damage. If moving the vehicle is unavoidable, note the following points:
- Fit an outer joint in place of the drive shaft.
- ◆ Tighten outer joint to 200 Nm.



- ◆ Bonded rubber bushes can only be turned to a limited extent. The suspension must therefore always be in the unladen position ⇒ page 15 when the suspension link attachments are tightened.
- ♦ If the wheel alignment has to be checked and adjusted at a commercial purposes, in part or in whole, is not later stage, all bolts and nuts which need to be slackened to I AG does not guarantee or accept any liability make adjustments should initially only be tightened to the specified torque figure. After wheel alignment has been ation in this document. Copyright by AUDI AG. checked and adjusted, bolts and nuts must then be fully tightened by turning them through the specified angle.



CAUTION

All bolts and nuts must be fully tightened according to specifications before the vehicle is driven on public roads.

3.7 General repair instructions

To avoid repetition, a number of notes that are generally applicable to the individual procedures described in this manual are summarised here. They apply for this individual Workshop Manual.

◆ Before carrying out repair work on the electromechanical steering rack, identify the cause of the fault as exactly as possible using the ⇒ Vehicle diagnostic tester in the operating modes "Guided Fault Finding", "Vehicle Self-Diagnosis" and "Test Instruments".

3.8 Contact corrosion

Contact corrosion can occur if unsuitable fasteners are used (e.g. bolts, nuts, washers, etc.).

For this reason, all the fasteners on the vehicle have a special surface coating (Dacromet). For correct version refer to \Rightarrow Electronic parts catalogue.

In addition, rubber parts, plastic parts and adhesives are made of non-conductive material.

Always renew parts if you are in any doubt as to whether the old part can be used again.

Please note:

Only use genuine replacement parts; they have been tested and are compatible with aluminium.

Accessories must be approved by AUDI AG.

Damage caused by contact corrosion is not covered by the warranty.

3.9 Steering rack

To achieve the desired results when performing repairs on the steering rack it is important to work with the greatest possible care and cleanliness, and to use proper tools in good condition. Always observe the basic safety rules when performing servicing procedures.


3.10 Gaskets and seals

- Always renew gaskets and seals.
- Check contact surface on housing or shafts for burrs and damage after removing the seals, and repair as required.
- Clean off all residues of liquid gasket thoroughly; make sure that no remaining material enters the steering rack housing.



3.11 Bolts and nuts


- Loosen and tighten bolts and nuts securing covers and housings in diagonal sequence.
- Take care not to tilt particularly sensitive components such as the servo motor with control unit; slacken off and tighten progressively in diagonal sequence.
- Tightening torques refer to unoiled bolts and nuts.
- Always renew self-locking bolts/nuts.
- Always renew bolts and nuts which are tightened by turning through a specified angle.



3.12 Electrical components

You have certainly experienced light electric shocks when touching metal objects. This is due to the electrostatic charge accumulated by the human body. This charge can cause malfunctions if you touch the electric steering rack components.

 Before working on electrical components, touch an earthed object (e.g. water pipe or lifting platform). Do not touch the contact pins of the electrical connectors.




3.13 Repairing damaged threads in longitudinal member (subframe to body)

Instructions for repairing damaged threads ⇒ Body Repairs; Rep. gr. 50; Repairing threads for attachment of subframe

3.14 Lifting suspension to unladen position - vehicles with coil springs

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





- Engine and gearbox jack VAS 6931- or engine and gearbox jack - V.A.G 1383 A-
- ◆ Tensioning strap T10038-
- Support T10149-



Note

All bolts on running gear components with bonded rubber bushes must always be tightened with the suspension in the unladen position (vehicle unladen).

Bonded rubber bushes can only be turned to a limited extent.

Therefore, before tightening the bolts, suspension components with bonded rubber bushes must be brought into a position corresponding to the normal position while driving (unladen position).

Otherwise, the bush would be subject to torsion loading and its service life would be shortened.

This position can be simulated on the lifting platform by raising the appropriate part of the suspension with the engine and gear-box jack and support - T10149- .



 Before commencing work, use measuring tape or similar to measure dimension -a- from wheel centre to lower edge of wheel housing.

This measurement must be taken with the suspension in the unladen position (vehicle unladen).

 Make a note of the measured value. This will be needed when tightening the bolts and/or nuts.

Front axle:

Before raising wheel unit, secure vehicle to arms of lifting platform using tensioning straps - T10038- .

Rear axle:

Before raising wheel unit, secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-.

 Place a piece of rubber foam -1- or similar between side member and tensioning strap - T10038- and tighten tensioning strap - T10038- .



Note

Take care not to scratch side member.



CAUTION

If vehicle is not secured, there is a risk of it slipping off the lifting platform.

with respect to the correctness of information in this d

- Remove wheel ⇒ page 329 .
- Turn wheel hub until one of the wheel bolt holes is at the top.
- Attach support T10149- to wheel hub using wheel bolt.

The bolts/nuts on the relevant suspension mountings must not be tightened until the distance -a- between the wheel centre and the lower edge of the wheel arch is the same as the distance measured before commencing work.


 Raise wheel bearing housing with engine and gearbox jack until distance -a- is obtained.




Do not raise or lower the vehicle while the engine and gearbox jack is under the vehicle.


Do not leave the engine and gearbox jack under the vehicle for longer than necessary.

- Tighten relevant nuts and bolts.
- Lower wheel bearing housing.
- Pull engine and gearbox jack out from below vehicle.
- Remove support T10149- .





ial p





3.15 Lifting suspension to reference position (vehicles with air suspension)


Special tools and workshop equipment required

♦ Engine and gearbox jack - VAS 6931-

Protected by copyright. Copying for private or commercial purposes, in part or permitted unless authorised by AUDI AG. AUDI AG does not guarantee or acce with respect to the correctness of information in this document. Copyrig



Support - T10149-



♦ Vehicle diagnostic tester



Note

All bolts on running gear components with bonded rubber bushes must always be tightened with the suspension in the reference position.

Bonded rubber bushes can only be turned to a limited extent.

Therefore, before tightening the bolts, suspension components with bonded rubber bushes must be brought into a position corresponding to the normal position of the vehicle while driving (reference position).

Otherwise, the bushes will be strained, resulting in reduced service life.

This position can be simulated on the lifting platform by raising the appropriate part of the suspension with the engine and gear-box jack and support - T10149- .

Front axle:

· Engine must be installed



Rear axle:

Before raising wheel unit, secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-

Place a piece of rubber foam -1- or similar between side member and tensioning strap - T10038- and tighten tensioning strap - T10038- .



Note

Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG de


with respect to the correctness of information in this



CAUTION

If vehicle is not secured, there is a risk of it slipping off the lifting platform.

- Position vehicle on lifting platform ⇒ page 18.
- Bleed air spring system ⇒ page 284.
- Remove wheel ⇒ page 329 .



am

- Turn wheel hub until one of the wheel bolt holes is at the top.
- Use wheel bolt to attach support T10149- .
- Insert support T10149- in engine and gearbox jack and press wheel bearing housing upwards until reference position, dimension -a-, is attained.

Dimension -a- depends on the suspension height of the running gear installed on the vehicle:

Front axle, Sportback

Running gear 1)	Dimension -a- in mm
Standard running gear (1BK)	386 mm ± 10 mm
Heavy-duty running gear (1BS)	391 mm ± 10 mm
RS running gear (2MA)	386 mm ± 10 mm
Sports running gear (2MB)	386 mm ± 10 mm

T10149 N40-0650

Front axle, saloon/Avant

Running gear 1)	Dimension -a- in mm	
Standard running gear (1BK)	384 mm ± 10 mm	
Heavy-duty running gear (1BS)	389 mm ± 10 mm	
RS running gear (2MA)	384 mm ± 10 mm	
Sports running gear (2MB)	384 mm ± 10 mm	
allroad (1BY)	393 mm ± 10 mm	

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Rear axle, Sportback permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

Running gear ¹) with respect to the correct Dimension ration in this document. Copyright by AUDI AG.

Running gear With respect to the	e correcti Limension ra ation in th
Standard running gear (1BK)	384 ± 10 mm
Heavy-duty running gear (1BS)	389 ± 10 mm
RS running gear (2MA)	382 ± 10 mm
Sports running gear (2MB)	384 ± 10 mm

Rear axle, saloon/Avant

Running gear 1)	Dimension -a-
Standard running gear (1BK)	382 ± 10 mm
Heavy-duty running gear (1BS)	387 ± 10 mm
RS running gear (2MA)	384 ± 10 mm
Sports running gear (2MB)	382 ± 10 mm
allroad (1BY)	390 ± 10 mm

¹⁾ A PR no. on the vehicle data sticker indicates which type of running gear is installed on the vehicle. To find out which PR Nos. are assigned to which types of running gear, refer to ⇒ page 345.



 Raise wheel bearing housing with engine and gearbox jack until distance -a- is obtained.



Do not raise or lower the vehicle while the engine and gearbox jack is under the vehicle.

Do not leave the engine and gearbox jack under the vehicle for longer than necessary.

Operations following setting of reference position te or commercial pur

- Tighten relevant nuts and bolts sed by AUDI AG. AUDI AG does not g
- Lower white bearing housing ectness of information in this document. Copyright by AUDI AG.

N40-0650

T10149

- Pull engine and gearbox jack out from underneath vehicle.
- Detach support T10149- .
- Fit and secure wheel ⇒ page 329.
- Charge air spring system ⇒ page 284.



CAUTION

All bolts and nuts must be fully tightened according to specifications before the vehicle is driven on public roads.

3.16 Raising and lowering vehicle when air spring system has / has not been opened

Raising vehicle when air spring system has not been opened

 If there is not sufficient clearance for lifting arms, use "Raise" function on MMI to set high suspension level, and activate "Wheel change" mode ⇒ Owner's Manual before raising vehicle with lifting platform.

This procedure ensures that the support arms of the lifting platform can be moved under the vehicle and that there are no uncontrolled changes of the air suspension system settings.

 Position support arms of lifting platform below specified lifting points on longitudinal members and raise vehicle.

Lowering vehicle when air spring system has not been opened

- Lower lifting platform and set vehicle down on its wheels.
- Swivel back support arms of lifting platform.
- Deactivate "Wheel change" mode and select desired drive mode ⇒ Owner's Manual .



Note

"Wheel change" mode is also deactivated automatically at road speeds in excess of 10 km/h.

Raising vehicle when air spring system has been opened

 If the vehicle has been raised and the air spring system has been opened, perform the steps listed under "Lowering vehicle when air spring system has been opened", in the sequence given, before lowering the vehicle back onto its wheels.





Lowering vehicle when air spring system has been opened

- Connect all air pipes to affected components.
- Check that rear air spring is correctly engaged on wheel bearing housing ⇒ page 217.
- Check that centring pin on rear air spring is correctly engaged in hole in body ⇒ page 217.
- Charge system ⇒ page 284 .
- Lower vehicle onto its wheels.
- Deactivate "Wheel change" mode ⇒ Owner's Manual .



Note

"Wheel change" mode is also deactivated automatically at road speeds in excess of 10 km/h.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



4 Technical data

⇒ "4.1 Running gear", page 20

⇒ "4.2 Steering", page 23

4.1 Running gear

⇒ "4.1.1 Running gear (all vehicles)", page 20

⇒ "4.1.2 Running gear (Sportback)", page 20

⇒ "4.1.3 Running gear (saloon/Avant)", page 21

4.1.1 Running gear (all vehicles)

Front axle	Five-link front suspension with top and bottom transverse links, anti-roll bar and twintube, gas-filled shock absorbers. Coil springs or optional air spring struts with variable level settings and damper characteristics
Rear axle	Independent, self-tracking suspension with upper and lower transverse links, transverse anti-roll bar, twin-tube, gas-filled shock absorbers with coil springs, or air springs with variable level settings and damping characteristics

4.1.2 Running gear (Sportback)



Note

- These specifications are applicable for all engines.
- Different track width figures will apply if rims with different rim offset are installed.

	Front-wheel drive / four-wheel drive				
	Standard running gear 1BA ¹⁾	Heavy-duty run- ning gear 1BB ¹⁾	Sports running gear 1BE ¹⁾	Air suspension, standard running gear 1BK in "comfort" level setting ¹⁾	Air suspension, heavy-duty run- ning gear 1BS in "comfort" level setting ¹⁾
Wheel- base	2917	2916	2918	2915	2915
Track width (front)	1645	1644	1646	1645	1635
Track width (rear)	1639	1638	1639	1636	1644
Maximum steering angle at inside wheel			39°36′		

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Front/rear track width only applicable to tyre size 235/55/
R17-ET30 (ET=rim offset) ed by AUDI AG. AUDI AG does not guarantee or accept any liability

with respect to the correctness of information in this document. Copyright by AUDI AG.



	Front-wheel drive / four-wheel drive				
	Sports running gear 1BV ¹⁾	Air suspension, sports running gear (RS models) 2MA ²⁾	Air suspension,	Sports running gear (RS models) 2MC ¹⁾	
Wheel- base	2918	2916	2916	2917	
Track width (front)	1646	1635	1641	1635	
Track width (rear)	1639	1626	1632	1628	
Maximum steering angle at inside wheel			39°36′		

¹⁾ Front/rear track width only applicable to tyre size 235/55/R17 ET30 (ET= rim offset).

Running gear (saloon/Avant) 4.1.3



- These specifications are applicable for all engines.
- Different track width figures will apply if rims with different rim offset are installed.

	Front-wheel drive / four-wheel drive				
	Standard running gear 1BA/1BH ¹⁾	Heavy-duty run- ning gear China 1BB ¹⁾	Sports running gear 1BE ¹⁾	hybrid 1BE ¹⁾	Air suspension, standard running gear 1BK in "comfort" level setting 1)
Wheel- base	2915	3016	2919	2918	2915
Track widthperm	itted unless authori	sed by AUDI AG. AL	1031	rantee or accept an	A C
Track width (rear)	1623	1623	1624	1624	1622
Maximum steering angle at inside wheel			39°36′		

²⁾ Front/rear track width only applicable to tyre size 275/35/ R20 ET35 (ET= rim offset).

³⁾ Front/rear track width only applicable to tyre size 255/40/ R19 ET32 (ET= rim offset).



 $^{1)}$ Front/rear track width only applicable to tyre size 235/55/ R17 ET30 (ET= rim offset).

	Front-wheel drive / four-wheel drive				
	Heavy-duty run- ning gear 1BR ¹⁾	Heavy-duty run- ning gear China 1BR ¹⁾	Air suspension, heavy-duty run- ning gear 1BS in "comfort" level setting ²⁾	Sports running gear (S line) 1BV ¹⁾	allroad 1BY in "normal" level setting ³⁾
Wheel- base	2914	3013	2915	2919	2914
Track width (front)	1628	1628	1630	1632	1643
Track width (rear)	1622	1621	1621	1624	1613
Maximum steering angle at inside wheel	39°36'				

¹⁾ Front/rear track width only applicable to tyre size 235/55/R17 ET30 (ET= rim offset).

³⁾ Front/rear track width only applicable to tyre size 235/55/ R18 ET41 (ET= rim offset).

	Front-wheel drive / four-wheel drive					
	Air suspension, sports running gear (RS models) 2MA ¹⁾	Air suspension, sports running gear 2MB in "sport" level setting ²⁾	Sports running gear (RS models) 2MC ³⁾			
Wheel- base	2915	2916	2917			
Track width (front)	1663	1615	1663			
Track width (rear)	1664	1606	1666			
Maximum steering						
angle at	Protected by copyright. Copying for private or commercial purposes, in part or in who					
inside	permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any					
wheel	with respect to the correctness of information in this document. Copyright by AUDI A					

not

²⁾ Front/rear track width only applicable to tyre size 225/60/ R16 ET37 (ET= rim offset).

¹⁾ Front/rear track width only applicable to tyre size 275/35/ R20 ET21 (ET= rim offset).

²⁾ Front/rear track width only applicable to tyre size 255/40/ R19 ET45 (ET= rim offset).

³⁾ Front/rear track width only applicable to tyre size 275/35/ R20 ET37 (ET= rim offset).



4.2 Steering

Steering rack	Electro-mechanically assisted, maintenance-free rack-and-pinion steering
Turning circle diameter	approx. 11.9 m



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



5 Disposal

- ⇒ "5.1 Releasing gas and draining front gas-filled shock absorbers", page 24
- \Rightarrow "5.2 Releasing gas and draining rear gas-filled shock absorbers", page 25
- ⇒ "5.3 Discharging front suspension strut (air suspension)", page 26
- ⇒ "5.4 Discharging accumulator", page 26

5.1 Releasing gas and draining front gas-filled shock absorbers

- A Releasing gas by drilling
- Clamp gas-filled shock absorber vertically in vice, with piston rod pointing downwards.



CAUTION

Safety goggles must be worn when drilling

Drill a 3 mm Ø hole -arrow A- through outer tube of shock absorber.



Note

Protected by copyright. Copying for private or compermitted unless authorised by AUDI AG. AUDI AG

with respect to the correctness of information in this document. Copyright by AUDI AG.


Gas will escape during drilling.

- Continue drilling until inner tube is fully penetrated (approx. 25 mm deep).
- Drill a second hole (6 mm Ø) -arrow B- through outer and inner tubes of shock absorber.
- Hold shock absorber over a drip tray and move piston rod up and down several times through entire stroke until no more fluid comes out.
- B Opening with pipe cutter



CAUTION

Safety goggles must be worn when drilling.





Drill a 3 mm Ø hole -arrow- through outer tube of shock absorber, or saw through wall of tube.



Note

Gas will escape when drilling or sawing.

- Apply pipe cutter (e.g. Stahlwille Express 150/3) as shown in illustration and cut through outer tube of shock absorber.
- Pull the piston rod upwards, at the same time holding the inner tube securely with pliers and pressing it downwards, so that it remains in the outer tube when the piston rod is slowly pulled upwards.
- Pull piston rod off inner tube of shock absorber.
- Drain shock absorber tube.

5.2 Releasing gas and draining rear gas-filled shock absorbers

- A Releasing gas by drilling
- Clamp gas-filled shock absorber vertically in vice, with piston rod pointing downwards.



CAUTION

Safety goggles must be worn when drilling.

Drill a 3 mm Ø hole -arrow A- through outer tube of shock absorber.



Note

 γ copyright. Copying for private or commercial purposes, in part or in whole, is not permit Gas will escape during drilling AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by A — Continue drilling until inner tube is fully penetrated (approx.

- 25 mm deep). Drill a second hole (6 mm Ø) -arrow B- through outer and inner
- Hold shock absorber over a drip tray and move piston rod up and down several times through entire stroke until no more fluid comes out.
- B Opening with pipe cutter

tubes of shock absorber.



CAUTION


Safety goggles must be worn when drilling.


 Drill a 3 mm Ø hole -arrow- through outer tube of shock absorber, or saw through wall of tube.



Note

Gas will escape when drilling or sawing.








- Apply pipe cutter (e.g. Stahlwille Express 150/3) as shown in illustration and cut through outer tube of shock absorber.
- Pull the piston rod upwards, at the same time holding the inner tube securely with pliers and pressing it downwards, so that it remains in the outer tube when the piston rod is slowly pulled upwards.
- Pull piston rod off inner tube of shock absorber.

Protected by copyright. Copying for private or commercial purposes, in pa

Drain shock absorber tube.
 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or


with respect to the correctness of information in this document. Copyrigh



5.3 Discharging front suspension strut (air suspension)

Special tools and workshop equipment required

♦ Socket - T10158/1-



Procedure

- Remove front air spring strut ⇒ page 62.
- Slowly loosen residual pressure valve -2- on front air spring strut to dissipate air pressure.



Note

Illustration shows air spring strut installed.

Dispose of air spring strut.


5.4 Discharging accumulator

Special tools and workshop equipment required

Vehicle diagnostic tester

Procedure

- Bleed air spring system ⇒ page 284.
- Remove accumulator ⇒ page 309.
- Dispose of accumulator.






40 – Front suspension

Front axle

⇒ "1.1 Overview - front axle", page 27

1.1 Overview - front axle




2 Subframe

- ⇒ "2.1 Exploded view subframe", page 28
- ⇒ "2.2 Lowering subframe", page 30
- \Rightarrow "2.3 Removing and installing subframe with steering rack", page 40
- ⇒ "2.4 Removing and installing subframe cross brace", page 51
- ⇒ "2.5 Removing and installing subframe shield", page 52
- ⇒ "2.6 Removing and installing anti-roll bar", page 53
- ⇒ "2.7 Removing and installing coupling rod (for anti-roll bar)", page 55

2.1 Exploded view - subframe

- 1 Bolt
 - □ Tightening torque ⇒ Rep. gr. 10; Assembly mountings; Exploded view - assembly mountings
- 2 Engine mounting
 - □ Removing and installing ⇒ Rep. gr. 10; Assembly mountings; Removing and installing engine mountings
- 3 Bracket for engine mounting
- 4 Nut
 - □ 9 Nm
- 5 Bolt
 - □ 9 Nm
- 6 Heat shield (upper section)
 - □ Removing and installing
 ⇒ page 52
- 7 Bolt
 - □ 9 Nm
- 8 Bolt
 - □ 9 Nm
- 9 Bolt
 - □ 9 Nm
- 10 Heat shield (lower section)
 - □ Removing and installing⇒ page 52
- 11 Subframe
 - □ Removing and installing ⇒ page 40







The subframe must be pre-adjusted if it has been renewed or if it has been removed and the cross brace has been loosened for subsequent work <u>⇒ page 50</u> .

12 - E	Bolt
	115 Nm +90°
	Always renew if removed
	Tighten in several stages in diagonal sequence
13 - E	3olt 115 Nm +90°
ū	Always renew if removed
Protected b	Tighten in several stages in diagonal sequence by copyright. Copying for private or commercial purposes, in part or in whole, is not solt
permitted	90 Nm +180
	t Always renew if removed mation in this document. Copyright by AUDI AG.
15 - E	Bolt
	90 Nm +180°
	Always renew if removed
16 - 5	Subframe cross brace
	Removing and installing ⇒ page 51
17 - E	Bolt
	90 Nm +180°
	Always renew if removed
18 - E	Bolt
	20 Nm
19 - 0	Guard plate
20 - E	Bolt
	Secures steering rack; tightening torque ⇒ "3.1.1 Exploded view - steering rack with track rods", page 402
21 - 8	Shock absorber fork
	Removing and installing <u>⇒ page 82</u>
22 - E	Bolt
	40 Nm +90°
	Always renew if removed
	Tighten in unladen position ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12
23 - A	Anti-roll bar
	Removing and installing ⇒ page 53
24 - N	Nut
	25 Nm
	Always renew if removed
	Loosen/tighten nuts evenly on alternate sides

		-	


- 25 Clamp
- 26 Rubber bush
 - ☐ The rubber bush must be installed with the opening facing towards the subframe.
 - ☐ The anti-roll bar and rubber bush must be installed free of grease.
- 27 Nut
 - Always renew
- 28 Bolt
 - ☐ 40 Nm +90°
 - Always renew if removed
 - ☐ Tighten in unladen position
 - ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position vehicles with coil springs", page 12
- 29 Coupling rod
 - □ Note installation position ⇒ page 30.
 - □ Removing and installing ⇒ page 55
- 30 Bolt
 - □ 20 Nm
- 31 Bolt
 - □ 20 Nm
- 32 Front longitudinal member (bottom)
 - Not fitted on all engine versions
 - □ Removing and installing ⇒ General body repairs, exterior; Rep. gr. 63; Bumper (front); Exploded view impact bar .
- 33 Bolt
 - For attachment of engine mounting
 - ☐ Tightening torque ⇒ Rep. gr. 10 ; Assembly mountings; Exploded view assembly mountings
- 34 Bolt
 - □ 20 Nm
- 35 Bolt
 - ☐ For attachment of engine mounting
 - ☐ Tightening torque ⇒ Rep. gr. 10 ; Assembly mountings; Exploded view assembly mountings
- 36 Bolt
 - ☐ Tightening torque ⇒ Rep. gr. 10 ; Assembly mountings; Exploded view assembly mountings

Installation position of coupling rod

Left and right coupling rods are identical.

Bolt -1- for connecting coupling rod to anti-roll bar -4- must be affixed to "small" face -2- of coupling rod collar and secured with nut -3-.

Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this document.



2.2 Lowering subframe

Special tools and workshop equipment required



♦ Torque wrench - V.A.G 1331-



♦ Torque wrench - V.A.G 1332-



◆ Engine and gearbox jack - VAS 6931-




Procedure


- Before starting work, measure distance from centre of wheel to lower edge of wheel housing ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15
- Position vehicle on lifting platform ⇒ page 18.
- Detach engine cover panel. Copying for private or commercial purposes, in part or in whole, is not
- Take up weight of engine assembly with support bracket ⇒ Rep. gr. 10_NiAssembly mountings; Supporting engine in in his document. Copyright by AUDI AG. stallation position .
- Remove front wheels.



Remove noise insulation panels -1- and -2- ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation .




Remove front wheel housing liners (both sides) ⇒ General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Removing and installing wheel housing liner (front) .




- If fitted, remove nuts -3- and detach cover -2- for drive shaft on both sides.
- Tilt upper part of cover -2- outwards and disengage from underneath at flange -1-.

Protected by copyright. Copying for private or commercial purposes, in part or in who permitted unless authorised by AUDI AG. AUDI AG does not guarantee d with respect to the correctness of information in this document. Copyrig






Remove wheel spoilers (both sides) ⇒ General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Exploded view - wheel housing liner (front) .




- If fitted, unplug electrical connector -1- from vehicle level sender on both sides and detach clip -arrow-.
- Detach wiring clips for vehicle level sender from subframe on both sides and move wiring clear.
- Move electrical wire clear.




- Unplug electrical connector -1- for signal wires (CAN bus and terminal 15) at power steering control unit - J500- .
- Unplug electrical connector -2- for voltage supply (terminal 30) at power steering control unit - J500- (release retainer -arrow- and push catch downwards).



Release clip -arrow-, unplug electrical connector -1- and move electrical wiring clear.








 If fitted, release remaining clips -arrows- on cross brace and move electrical wiring harness clear.

i Note


Protected by copyright. Copying for private or commercial

-Items 1 ... 5- can be disregarded horised by AUDI AG. AUDI AG does n

with respect to the correctness of information in this docu



 If fitted, release clip -arrow- on subframe (rear left) and move electrical wiring harness clear.



 To prevent unintentional turning, secure steering wheel in straight-ahead position with adhesive tape -arrow-.




Note

- Use adhesive tape that can be completely removed afterwards without leaving marks.
- Do not turn steering wheel while performing repair work, as otherwise airbag coil connector and return ring with slip ring -F138- could be damaged.






- Remove bolt -arrow-.
- Detach universal joint -1- from steering rack -2- and secure intermediate steering shaft to prevent it from dropping.




- Unscrew nut -1- and bolts -2- on both sides and detach heat shield (upper section) -3-.
- If fitted, remove gearbox oil cooling valve N509- ⇒ Rep. gr. 19; Coolant pump/thermostat assembly; Removing and installing coolant valves thorised by AUDI AG. AUDI AG does not guara


with respect to the correctness of information in this document. C



On vehicles with intermediate flange -1-, remove bolts -2 and 3- and move flange clear with hoses connected.




Detach bolt -1- securing coupling rod to shock absorber fork on both sides.






Unplug connectors -1- for right electrohydraulic engine mounting solenoid valve - N145- and -2- for left electrohydraulic engine mounting solenoid valve - N144- and move clear.




Audi RS 6

Remove nut -arrow- and move coolant pipe -1- clear and slightly to one side.



Remove bolt -arrow- and move wiring harness clear.



Applies to vehicles with 6-cylinder or 8-cylinder engine


Unscrew bolts -arrows- and detach front longitudinal member -1- (bottom left).




Protected by copyright. Copying for private or commercial purp permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Remove nuts and bolts -arrows- and move clear earth wire -1- and electrical wire -2-.
- Detach front longitudinal member (bottom right).




Clamp off coolant hoses with hose clamps, up to Ø 25 mm -3094- and detach (to do so, release hose clips -arrows-).




Unplug electrical connectors -1, 2- on both sides.



Protected by copyright. Copying for private or commercial purposes, in p permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document. Copyr




Detach electrical connector -arrow- from bracket, unplug and guide through subframe.





All vehicles (continued):


 If necessary, remove nuts -1 and 2- and move earth wire -arrow- to one side.




- Detach clip -arrow- from bracket for engine mounting on both sides and move clear electrical wiring with metal retainer -1-.
- On some engine versions, an electrical wire is also secured to the left engine mounting bracket (rear).




Protected by copyright. Copying for private or compermitted unless authorised by AUDI AG. AUDI AG



Support subframe vising engine and gearbox jack i V.A.G tion in the 1383 A- with a suitable wooden block, as shown in illustration.



Remove bolt -arrow- for engine mounting on both sides.





- Use a felt-tip pen to mark installation position of subframe on longitudinal members.
- Remove subframe bolts -1, 2 and 3- (left and right) in several stages in diagonal sequence.
- Lower subframe with engine and gearbox jack V.A.G 1383 A- .




Note

When lowering subframe, make sure there is enough clearance

for electrical wiring.

Protected by copyright. Copying for private or comm



Installing

permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability

Installation is carried out in reverse sequence. Note the following: in this document. Copyright by AUDI AG.



NOTICE

With bolt <u>⇒ Item 1 (page 384)</u> screwed in by hand, try to pull off intermediate steering shaft to check that it is correctly seated. Then tighten bolt ⇒ Item 1 (page 384).



Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to reference position ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12
- Position subframe at marked location with respect to body.
- Tighten subframe bolts in diagonal sequence.



CAUTION

All bolts and nuts must be fully tightened according to specifications before the vehicle is driven on public roads.

- Check and adjust wheel alignment as required, see chart <u>⇒ page 344</u> .
- On vehicles with automatic headlight range control, perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights.
- If the vehicle level sender has been removed and refitted or the linkage detached on vehicles with air suspension, the reference position must be re-adapted; start appropriate program on ⇒ Vehicle diagnostic tester in Guided Functions.
- If the reference position has been re-adapted on vehicles with lane departure warning, the camera control unit - J852- must be recalibrated ⇒ page 365.

Tightening torques

- ⇒ "2.1 Exploded view subframe", page 28
- ⇒ "3.1 Exploded view suspension strut, upper links", page 57



- ◆ Prö3e1t1 Exploded view steering rack with track rods

 page 402
 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods

 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods

 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods

 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods

 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods

 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods

 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods

 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods


 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 **Track rods

 permitted unless authorised by AUDI AG. A

2.3 vith respertentioning and installing subframe with steering rack AG.


Special tools and workshop equipment required



- ♦ Torque wrench V.A.G 1331-
- ♦ Torque wrench V.A.G 1332-
- Engine and gearbox jack VAS 6931- or -V.A.G 1383 A-
- ♦ Tensioning strap T10038-, 2x




Support - T10149-



♦ For vehicles with air suspension: vehicle diagnostic tester Removing

- Before starting work, measure distance from centre of wheel to lower edge of wheel housing ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15
- Position vehicle on lifting platform ⇒ page 18.
- Vehicles with air spring system: bleed air spring system ⇒ page 284 .
- Detach engine cover panel.
- Take up weight of engine assembly with support bracket \Rightarrow Rep. gr. 10; Assembly mountings; Supporting engine in installation position .
- Remove front wheels.
- Remove noise insulation panels -1- and -2- ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation.







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Remove front wheel housing liners (both sides) \Rightarrow General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Removing and installing wheel housing liner (front).




- If fitted, remove nuts -3- and detach cover -2- for drive shaft on both sides.
- Tilt upper part of cover -2- outwards and disengage from underneath at flange -1-.



Remove wheel spoilers (both sides) \Rightarrow General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Exploded view - wheel housing liner (front).




Protected by copyright. Copying for private or comme permitted unless authorised by AUDI AG. AUDI AG do with respect to the correctness of information in this







- If fitted, unplug electrical connector -1- from vehicle level sender on both sides and detach clip -arrow-.
- Detach wiring clips for vehicle level sender from subframe on both sides and move wiring clear.
- Move electrical wire clear.



- Unplug electrical connector -1- for signal wires (CAN bus and terminal 15) at power steering control unit - J500- .
- Unplug electrical connector -2- for voltage supply (terminal 30) at power steering control unit - J500- (release retainer -arrow- and push catch downwards).



Release clip -arrow-, unplug electrical connector -1- and move electrical wiring clear.




If fitted, release remaining clips -arrows- on cross brace and move electrical wiring harness clear.




Note

Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG do -Items 1 ... 5- can be disregarded.





 If fitted, release clip -arrow- on subframe (rear left) and move electrical wiring harness clear.



 To prevent unintentional turning, secure steering wheel in straight-ahead position with adhesive tape -arrow-.




Note

- ♦ Use adhesive tape that can be completely removed afterwards without leaving marks.
- Do not turn steering wheel while performing repair work, as otherwise airbag coil connector and return ring with slip ring -F138- could be damaged.




- Remove bolt -arrow-.
- Detach universal joint -1- from steering rack -2- and secure intermediate steering shaft to prevent it from dropping.





is not ility

- Unscrew nut -1- and bolts -2- on both sides and detach heat shield (upper section) -3-.
- If fitted, remove gearbox oil cooling valve N509- ⇒ Rep. gr. 19; Coolant pump/thermostat assembly; Removing and installing coolant valves.





On vehicles with intermediate flange -1-, remove bolts
 -2 and 3- and move flange clear with hoses connected.



Protected by copyright. Copying for private or commercial purpos permitted unless authorised by AUDI AG. AUDI AG does not guara with respect to the correctness of information in this document.


Tie up wheel bearing housing with tensioning strap - T10038 -1- on both sides as shown in illustration.




Note

Wheel bearing housing must be supported to avoid damaging joints of upper links.

Remove track control link on both sides ⇒ page 91.





- A40-10214
- Unscrew nut on joint pin of guide link (on both sides) until it is flush with end of thread. Counterhold joint pin if necessary.
- Press joint pin of guide link out of tapered seat using ball joint puller - T40042- .



Note

- ♦ Take care not to damage boot.
- Make sure the two lever arms of the puller are parallel when maximum force is exerted.
- Detach guide link from wheel bearing housing on both sides of vehicle. Take care to avoid damage to boot on joint pin of guide link.





Detach bolt -1- securing coupling rod to shock absorber fork on both sides.



Protected by copyright. Copying for private or commercial purposes, in p permitted unless authorised by AUDI AG. AUDI AG does not guarantee of


—witUnplug connectors and for right electrohydraulic engine mountapyrig ing solenoid valve - N145- and -2- for left electrohydraulic engine mounting solenoid valve - N144- and move clear.






Audi RS 6

Remove nut -arrow- and move coolant pipe -1- clear and slightly to one side.




Remove bolt -arrow- and move wiring harness clear.






Applies to vehicles with 6-cylinder or 8-cylinder engine


- Unscrew bolts -arrows- and detach front longitudinal member -1- (bottom left).




- Remove nuts and bolts -arrows- and move clear earth wire -1- and electrical wire -2-.
- Detach front longitudinal member (bottom right).



Clamp off coolant hoses with hose clamps, up to Ø 25 mm -3094- and detach (to do so, release hose clips -arrows-).



- Unplug electrical connectors -1, 2- on both sides.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Detach electrical connector -arrow- from bracket, unplug and guide through subframe.



All vehicles (continued):


If necessary, remove nuts -1 and 2- and move earth wire -arrow- to one side.





- Detach clip -arrow- from bracket for engine mounting on both sides and move clear electrical wiring with metal retainer -1-.
- On some engine versions, an electrical wire is also secured to the left engine mounting bracket (rear).



Protected by copyright. Copying for private or commercial pur permitted unless authorised by AUDI AG. AUDI AG does not g










Remove bolt -arrow- for engine mounting on both sides.



- Use a felt-tip pen to mark installation position of subframe on longitudinal members.
- Remove subframe bolts -1, 2 and 3- (left and right) in several stages in diagonal sequence.
- Lower subframe with engine and gearbox jack V.A.G 1383 Α- .



Note

When lowering subframe, make sure there is enough clearance for electrical wiring.

 If necessary, refit attachments for subsequent work. Installing

Installation is carried out in reverse sequence. Note the following:




With bolt ⇒ Item 1 (page 384) screwed in by hand, try to pull off intermediate steering shaft to check that it is correctly seated. Then tighten bolt ⇒ Item 1 (page 384).



Note

The subframe must be pre-adjusted if it has been renewed or if it has been removed and the cross brace has been loosened for subsequent work.

> Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Procedure for pre-adjustment of subframe:

- Place subframe upside down.
- 2 -Attach steering rack and guide links provisionally (handtighten bolts).
- 3 -Adjust longitudinal arms -1- and -2- so that distance -A- is attained (between inside edges of facing holes).
- Fit cross brace and secure with rear 6 bolts. Subframe is now pre-adjusted and self-supporting.
- 5 -Secure steering rack.
- Tighten 2 front bolts to secure cross brace.

Dimension -A- = 599 mm



Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to reference position ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12
- Position subframe at marked location with respect to body.
- Tighten subframe bolts in diagonal sequence.



CAUTION

All bolts and nuts must be fully tightened according to specifications before the vehicle is driven on public roads.

- Check and adjust wheel alignment as required, see chart ⇒ page 344 .
- On vehicles with automatic headlight range control, perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights .
- If the vehicle level sender has been removed and refitted or the linkage detached on vehicles with air suspension, the reference position must be re-adapted; start appropriate program on ⇒ Vehicle diagnostic tester in Guided Functions
- If the reference position has been re-adapted on vehicles with lane departure warning, the camera control unit - J852- must be recalibrated ⇒ page 365.


Tightening torques

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

- ⇒ "2.1 Exploded view subframe", page 28
- with respect to the correctness of information in this document. Copyright by AUDI AG.

 ⇒ "3.1 Exploded view suspension strut, upper links",

 page 57 <u>page 57</u>
- ⇒ "4.1 Exploded view lower suspension links, swivel joint",
- ⇒ "3.1.1 Exploded view steering rack with track rods", page 402





2.4 Removing and installing subframe cross brace

Special tools and workshop equipment required


♦ Torque wrench - V.A.G 1332-



Removing

- Position vehicle on lifting platform ⇒ page 18.
- Remove noise insulation panels -1 and 2- \Rightarrow General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation .

Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does no with respect to the correctness of information in this docu



- Release clips for wiring harness -arrows-.
- Remove bolts -1 to 5- and detach cross brace.

CAUTION

Risk of damage to running gear components.

Never place the vehicle on its wheels if the subframe, steering rack or subframe cross brace is not correctly installed!

The vehicle must not be supported on the subframe or the subframe cross brace (e.g. using a trolley jack or similar)!


If vehicle is to be moved, cross brace must be fitted with old bolts and tightened to specified torque without turning further through specified angle.

Installing

Installation is carried out in reverse sequence.

Tightening torques

♦ "2.1 Exploded view - subframe", page 28






2.5 Removing and installing subframe shield

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1410-




Ratchet - V.A.G 1410/3-



Removing

- Position vehicle on lifting platform ⇒ page 18.
- Remove noise insulation ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation.
- Remove nut -1- and bolts -2- and take out heat shield (upper section) -3-.
- If fitted, remove gearbox oil cooling valve N509- ⇒ Rep. gr.
 19; Coolant pump/thermostat assembly; Removing and installing coolant valves.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Remove bolts -arrows- and nut -1-.
- Take out heat shield (lower section) -2- towards rear of vehicle between body and subframe.


On vehicles with 6-cylinder TDI engine, the cross brace must first be removed ⇒ page 51 before removing the lower section of the heat shield (right-side) as described in the previous step.

Installing

Installation is carried out in reverse sequence. Note the following: Tightening torques

♦ ⇒ "2.1 Exploded view - subframe", page 28

Protected by copyright. Copying for private or commercial purposes, in par permitted unless authorised by AUDI AG. AUDI AG does not guarantee or a with respect to the correctness of information in this document. Copyright




2.6 Removing and installing anti-roll bar

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1332-



- ♦ For vehicles with air suspension: vehicle diagnostic tester Removing
- Before starting work, measure distance from centre of wheel to lower edge of wheel housing ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15.
- Position vehicle on lifting platform ⇒ page 18.
- Remove noise insulation -1- ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation .



- Detach bolted connection -2- on both sides.
- Unscrew bolt connection -1- on both sides and detach clamps -3-.
- Take out anti-roll bar.

Installing

Installation is carried out in reverse sequence. Note the following:



Note


- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to unladen position or reference position
 ⇒ "3.15 Lifting suspension to reference position (vehicles with
 air suspension)", page 15 or
 ⇒ "3.14 Lifting suspension to unladen position vehicles with
 coil springs", page 12
- Anti-roll bar and rubber bushes must be free of grease.
- ♦ Fit the rubber bush with the opening facing towards the contact surface of the subframe.
- Where fitted: if studs -1- have been slackened, screw in as far as stop before refitting clamp -3-.
- Refit bolt connection -1-, but do not tighten yet.
- Fit bolts -2- on both sides, but do not tighten.

- 1 1 2 A40-10325
- Raising suspension to reference position
 ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or
 ⇒ "3.14 Lifting suspension to unladen position vehicles with coil springs", page 12
- Tighten bolted connections -1- and -2-.




Note

- ◆ Tighten bolts -1- evenly on alternate sides.
- ♦ The rubber bush must be installed with the opening facing towards the subframe.
- The anti-roll bar and rubber bush must be installed free of grease.



Tightening torques copyright. Copying for private or commercial purposes, in part or in whole, is not

♦ <u>**2°1°Exploded view " subframe" A page 28</u> AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





2.7 Removing and installing coupling rod (for anti-roll bar)

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1332-





For vehicles with air suspension: vehicle diagnostic tester

stected by copyright. Copying for private or commercial purposes, in part or in whole, is not Removing permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- Before starting work, measure distance from centre of wheel

 Before starting work, measure distance from centre of wheel

 Copyright by AUDI AG. to lower edge of wheel housing orrect ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15.
- Position vehicle on lifting platform ⇒ page 18.
- Detach bolted connections -1- and -3-.
- Take out coupling rod -2-.


Installing

Installation is carried out in reverse sequence. Note the following:




Note

- Note installation position of coupling rod.
- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to unladen position ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12






Bolt -1- for connecting coupling rod to anti-roll bar -4- must be affixed to "small" face -2- of coupling rod collar and secured with nut -3-.



- Fit bolts -1- and -3- but do not tighten.
- Raise suspension to unladen position ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12.
- Tighten bolted connections -1- and -3-.

Tightening torques

⇒ "2.1 Exploded view - subframe", page 28





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Suspension strut, upper links

- ⇒ "3.1 Exploded view suspension strut, upper links", page 57
- ⇒ "3,2 Removing and installing suspension strut" page 59 at purposes, in part or in whole, is not
- ⇒ "3.3 Servicing suspension strut", page 66 AUDI AG does not guarantee or accept any liability
- ⇒ "3:4: Removing and installing upper links" apage 74 his document. Copyright by AUDI AG.
- ⇒ "3.5 Renewing bush for upper link", page 79
- ⇒ "3.6 Charging suspension strut", page 80
- ⇒ "3.7 Removing and installing shock absorber fork", page 82
- ⇒ "3.8 Removing and installing body brace", page 87

3.1 Exploded view - suspension strut, upper links

- 1 Suspension turret
- 2 Nut
 - □ 30 Nm
 - ☐ Loosen and tighten in diagonal sequence
 - □ Always renew if removed
- 3 Bolt
 - □ 20 Nm
- 4 Body brace
 - Removing and installing ⇒ page 87
- 5 Bolt
 - □ 20 Nm
- 6 Bolt
 - ☐ 50 Nm +90°
 - □ Always renew if removed
 - Vehicle must be in reference position when tightening
 - ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15
 - ⇒ "3.14 Lifting suspension to unladen position vehicles with coil springs", page 12
- 7 Upper link (rear)
 - Removing and installing ⇒ page 74
 - □ Renewing bonded rubber bush for upper link (rear) ⇒ page 79
- 8 Bolt
 - Always renew if removed



9 - W	asher
10 - V	Vheel bearing housing
11 - N	Nut
	40 Nm
	Always renew if removed
12 - 0	Coil spring/shock absorber
	Removing and installing <u>⇒ page 59</u>
	Servicing ⇒ page 66
13 - L	Jpper link (front)
	Removing and installing ⇒ page 74
	Renewing bonded rubber bush for upper link (front) ⇒ page 79
	50 Nm +90°
	Always renew if removed
	Vehicle must be in reference position when tightening ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page/15 or is not ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 permitted unless authorised by AUDI AC. AUDI AC does not guarantee or accept any liability
15 - E	with respect to the correctness of information in this document. Copyright by AUDLAG.
u	Always renew if removed
16 - T	rack control link
17 - N	
	90 Nm +90°
	Always renew if removed
	Vehicle must be in reference position when tightening ⇒ page 15
_	Shock absorber fork
	Depending on version, with vibration damper <u>⇒ page 59</u> . For correct version, refer to ⇒ Electronic parts catalogue
	Removing and installing shock absorber fork <u>⇒ page 82</u>
19 - E	· · ·
	40 Nm +180°
u	Always renew if removed
20 - C	Coupling rod
21 - E	Bolt
	40 Nm +90°
	Always renew if removed
	Vehicle must be in reference position when tightening ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12
22 - N	Nut
	Always renew if removed
23 - A	Air spring strut
	Removing and installing <u>⇒ page 62</u>
	Servicing ⇒ page 70
	Note different running gear versions <u>⇒ page 345</u>
24 - C	Connection piece for air pipe and residual pressure valve
	Tightening torque <u>⇒ Item 5 (page 71)</u>
	Only to be unscrewed with vehicle raised and no load on air spring strut (otherwise danger of injury due to vehicle dropping)



- ☐ In the event of leakage, refer to <u>⇒ "3.5 Servicing air pipe", page 296</u> or ⇒ "3.5 Servicing air pipe", page 296
- Clean pipe connection before loosening
- □ Air will escape when this component is unscrewed
- Protect pipe connection from dirt
- Residual pressure valve must not be loosened

Vibration damper for shock absorber fork

- Vibration damper
- Installation position: Marked L for left/R for right (visible on top when installed)
- 2 Nuts
- Renew after removing
- Different tightening torques:
- ♦ For vibration damper -4G0 413 143- / -144- : 9 Nm
- ♦ For vibration damper -4G0 413 143A- / -144A- : 10 Nm + 45°

3.2 Removing and installing suspension strut

⇒ "3.2.1 Removing and installing suspension strut (coil spring/ shock absorber)", page 59

⇒ "3.2.2 Removing and installing suspension strut (air spring strut)", page 62


3.2.1 Removing and installing suspension strut (coil spring/shock absorber)

Special tools and workshop equipment required

Torque wrench - V.A.G 1331-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.







◆ Torque wrench - V.A.G 1332-



Spreader - 3424-



◆ Tensioning strap - T10038-




♦ Wooden block (hardwood) 30 x 50 x 100 mm

Removing


- Place vehicle on lifting platform.
- Remove body brace ⇒ page 87.
- Unscrew bolts -arrows- and push washer fluid reservoir -1slightly to one side.
- Remove wheel ⇒ page 329 .

Protected by copyright. Copying for private or compermitted unless authorised by AUDI AG. AUDI AG with respect to the correctness of information in til





 Tie up wheel bearing housing with tensioning strap - T10038--1-, as shown in illustration.





Vehicles with Dynamic Ride Control (DRC)

- Discharge DRC system ⇒ page 318.
- If vehicle is equipped with driver-adjustable DRC and variable damping, detach electrical connector -1- (on additional element with integral DC motor) from bracket, unplug connector and move clear.
- Remove union screw -2- and move hose clear.
- · Protect open connections from dirt.

All vehicles

- Remove bolt -arrow- and detach bracket -1- for brake line and electrical wiring from wheel bearing housing.
- Remove shock absorber fork ⇒ page 82 .





Unscrew nuts -arrows- and take out coil spring/shock absorber.




Note

When removing coil spring/shock absorber, take care not to damage protective boots on steering and drive shaft.

Installing

Installation is carried out in reverse sequence. Note the following:

Protected by copyright. Copying for private or commercial purposes, permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




- Start by attaching coil spring/shock absorber to body.
- Tighten new nuts -arrows- in diagonal sequence.

Vehicles with Dynamic Ride Control (DRC)

- Fill DRC system ⇒ page 318.
- Fit wheel ⇒ page 329.

Tightening torques

- ⇒ "3.1 Exploded view suspension strut, upper links", page 57
- ⇒ "4.1 Exploded view lower suspension links, swivel joint", page 89




3.2.2 Removing and installing suspension strut (air spring strut)



Before air spring strut is installed or re-installed, it must be sealed at top cable guide to prevent water entering.

This applies when re-installing an air spring strut that was fitted previously and when installing a new air spring strut.

Special tools and workshop





equipment required

- ◆ Torque wrench V.A.G 1331-
- ♦ Torque wrench V.A.G 1332-
- ◆ Torque wrench V.A.G 1783-
- ♦ Open end spanner insert (10 mm) V.A.G 1783/1-
- ♦ Wooden block (hardwood) 30 x 50 x 1000 mm
- Spreader 3424-



◆ Tensioning strap - T10038-



Protected by copyright. Copying for private or commercial purposes, in p permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any lia hility W00-11193 with respect to the correctness of information in this document



♦ Vehicle diagnostic tester

Removing



Note

Take care to prevent indentations forming in boot on air spring strut during assembly work.

- Position vehicle on lifting platform ⇒ page 18.
- Remove body brace ⇒ page 87.

- Unscrew bolts -arrows- and push washer fluid reservoir -1slightly to one side.
- Remove wheel trim; on light-alloy wheels, pull off trim cap (use puller in vehicle tool kit).
- Remove wheel ⇒ page 329 .
- Clean area around air connection on air spring strut.
- Unplug electrical connector -1-.
- Unscrew connection piece at residual pressure valve -2-. This will allow air to escape.
- Detach clip -arrow-pand move pipes/wiring 3 viclear.r private or compermitted unless authorised by AUDI AG. AUDI AC

 $oldsymbol{i}$


Note


with respect to the correctness of information in t

The residual pressure valve -2- MUST NOT be loosened or removed.


- Close both connections. Take care to prevent dirt entering the connections.
- Tie up wheel bearing housing with tensioning strap T10038--1-, as shown in illustration.

A92-10232





- Remove bolt -arrow- and detach bracket -1- for brake line and electrical wiring from wheel bearing housing.
- Remove shock absorber fork ⇒ page 82.





A40-10552

Unscrew nuts -arrows- and take out air spring strut.



Note

When removing air spring strut, take care not to damage protective boots on steering, drive shaft and air spring strut.

Refer to ⇒ page 80 if air spring strut is to be renewed.

Installing

Protected by copyright. Copying for private or comm

NOTICE

Before air spring strut is installed or re-installed, it must be tion in this document. Copyright by AUDI AG. sealed at top cable guide to prevent water entering.

This applies when re-installing an air spring strut that was fitted previously and when installing a new air spring strut.

Before installing, seal air spring strut at cable guide to prevent water entering.



Note

This applies when re-installing an air spring strut that was fitted previously and when installing a new air spring strut.

Clean air spring strut at cable guide using commercially available cleaning solution.



Note

Do not use substances that contain oil for cleaning.

- Cut sealing cord (⇒ Electronic parts catalogue) to 30 mm.
- Press cut sealing cord into cable guide on top of air spring strut inside area measuring 30 mm -arrows-.



Note

- The area measuring 30 mm -arrows- must be covered fully by the sealing cord.
- The cut sealing cord must be flush with the inner contour edge of the plastic ring.
- Press sealing cord flat slightly.


The remaining installation steps are carried out in the reverse sequence. Note the following:




Note

Take care to prevent indentations forming in boot on air spring strut during assembly work.

Start by attaching air spring strut to body.





- Tighten new nuts -arrows- in diagonal sequence.
- Fit wheel ⇒ page 329.
- Charge air spring system ⇒ page 284.
- Re-adapt reference position ⇒ page 283.

Tightening torques

- ⇒ "3.1 Exploded view suspension strut, upper links", page 57
- ⇒ "4.1 Exploded view lower suspension links, swivel joint", page 89

A40-10552

3.3 Servicing suspension strut


⇒ "3.3.1 Servicing suspension strut (coil spring/shock absorber)", page 66

⇒ "3.3.2 Servicing suspension strut (air spring strut)", page 70

3.3.1 Servicing suspension strut (coil spring/ shock absorber)

Special tools and workshop equipment required

 Suspension strut tensioner - V.A.G 1752- with spring retainer - V.A.G 1752/6-



◆ Torque wrench - V.A.G 1332-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




♦ Shock absorber tool set - T10001-




Exploded view

- 1 Nut
 - □ 50 Nm
 - □ Always renew if removed
- 2 Shock absorber mounting
- 3 Washer
- 4 Top spring plate with spring seat
- 5 Coil spring
 - Steel coil spring or GFRP coil spring, depending on model. For allocation refer to ⇒ Electronic parts catalogue
- 6 Auxiliary spring
- 7 Protective sleeve
- 8 Protective cap
- 9 Bottom spring seat ted by copyright.
- 10 Bottom spring plateed unles
- 11 Shock absorben respect to t



Shock absorber with DRC system

- 1 Protective sleeve
- 2 Bump stop
- 3 Coil spring
- 4 Support
- 5 Top spring plate with spring seat
- 6 Washer
- 7 Shock absorber mounting
- 8 Nut
 - □ 50 Nm
 - Always renew if removed
- 9 Bracket
- 10 Retaining spring
 - Renew if damaged
- 11 Union screw
 - □ 14 Nm
- 12 Protective cap
- 13 Bottom spring seat
- 14 Bottom spring plate
- 15 Shock absorber
 - □ For DRC system
- 16 Rivet
- 17 Drain/charge valve with hose
 - Install so that it is free of tension



Removing coil spring


Clamp spring compressor - V.A.G 1752/1- -1- in vice.



Note


Use protective jaw covers to avoid damaging the spring compressor - V.A.G 1752/1- .


Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does now with respect to the correctness of information in this document.





- Clamp coil spring/shock absorber in spring compressor -V.A.G 1752/1- as shown in illustration.
- Compress coil spring using spring compressor V.A.G 1752/1- -1- until top spring plate with spring seat is free.
- Unscrew nut from piston rod.
- Take off suspension strut components and coil spring together with spring compressor - V.A.G 1752/1- .
- 1 Spring compressor V.A.G 1752/1-
- 2 Ratchet, commercially available
- 3 -T10001/7-
- 4 -T10001/11-
- 5 -T10001/3-
- 6 Spring retainer V.A.G 1752/6-
- Ensure that coil spring is correctly seated in spring retainer -V.A.G 1752/6- -arrow-.
- 1 Spring compressor V.A.G 1752/1-
- 2 Spring retainer V.A.G 1752/6-






Renewing shock absorber

- Take off protective cap -1- and bottom spring seat -2-.
- Knock spring plate -3- loose using plastic-headed hammer and lift off.
- Using plastic-headed hammer, knock spring plate -3- onto new shock absorber -4-.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabil with respect to the correctness of information in this document. Copyright by AUDI AG.





Installing coil spring

- Install bottom spring seat and protective cap.
- Position compressed coil spring on bottom spring seat. End of spring coil must make contact with stop -arrow- (maximum permissible clearance 2 mm).
- Fit component parts of suspension strut.




- Install top spring plate with spring seat on compressed coil spring so that spring seat makes contact with end of spring coil -arrow- (maximum permissible clearance 2 mm).
- Fit shock absorber mounting.
- Tighten new nut using special tools ⇒ Item 1 (page 67).
- Slacken and remove spring compressor V.A.G 1752/1- .



Note

When slackening the spring compressor, make sure that the ends of the spring remain in contact with the stops on the spring seats in the upper and lower spring plates.



3.3.2 Servicing suspension strut (air spring strut)



Note

Servicing of the air spring strut is currently limited to replacement of the dust boot and cleaning the piston.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1 - Hose clip


- Before dismantling, mark installation position of fastening lug and retaining clips on air spring strut
- Always renew if removed
- ☐ Tightening ⇒ page 74

2 - Boot

- Must not be kinked. eliminate indentations by hand if necessary
- □ Slide top over shoulder of suspension strut housing
- 3 Piston for U-bellows
 - Clean if dirty
 - Visual inspection ⇒ page 73

4 - Rubber boot

- Surface must be regular and even.
- Visual inspection ⇒ page 73
- 5 Connection piece for air pipe with residual pressure valve
 - Tightening torque for connection piece: 3 Nm
- DO NOT unfasten residual pressure valve, as this would damage air Protected spring strut. Copying for p



perr**6**itt**Electrical wire**orised by AUDI AG. AUDI AG does not guarantee or accept any liability

with respective adding to front left shock absorber damping adjustment valvey AN3364 or front right shock absorber damping adjustment valve - N337-

7 - Air spring strut

Complete air spring strut assembly must be renewed if front left - N336- or front right - N337- shock absorber damping adjustment valve is defective


Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1410-



Clamp tensioner - V.A.G 1682A

Protected by copyright. Copying for private or commercial p permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this docum



◆ Tensioning strap - T10038-



Removing



Note

The boot can be renewed without removing the air spring strut.


 Tie up wheel bearing housing with tensioning strap - T10038--1-, as shown in illustration.




Note

Wheel bearing housing must be supported to avoid damaging joints of upper links.


- Remove shock absorber fork ⇒ page 82.
- Unclip wiring from retainer -arrow- and move wiring clear.








Remove bolt -arrow- and detach bracket -1- for brake line and electrical wiring from wheel bearing housing.



- Mark installation position of fastening lug -1- and retainers -2- and -3- using a felt-tip pen or similar.
- Detach hose clip -1-.
- Carefully pull dust boot -4- downwards off collar on suspension strut housing (at top end) and collar of piston for U-bellows (at bottom end) and remove boot from air spring strut.



Visual inspection



Note

Before fitting the dust boot, check the surface of the piston for Ubellows and the rubber boot for damage and dirt, and rectify if necessary.


- Check rubber boot -1- for damage. Surface must be regular
- Replace air spring strut if damaged.
 Protected by copyright. Copyring for private or commercial purposes, in part or

Check piston for U-bellows -2- for damage and dirt; re-work surface with fine sandpaper if necessary. Take care to avoid with res**scoring**tand scratches of information in this document. Copyright by


Installing

Install in reverse sequence, paying attention to the following:

- Carefully slide new dust boot over shoulder of piston for Ubellows (at bottom end).
- Install shock absorber fork ⇒ page 82.
- Raise suspension to reference position ⇒ page 15.




- Slide dust boot -4- over collar onto suspension strut housing (at top end).
- Fit wiring retainer (front) -2- onto hose clip -1-
- Install hose clip -1-, but do not tighten.
- With only one wiring retainer fitted, position hose clip -1- so
 that fastening lug -3- is aligned with marking made earlier for con
 wiring retainer (rear)
 ermitted unless authorised by AUDI AG. AUDI AG.
- Align wiring retainer (front) with marking made earlier formation in
- Before tightening hose clips ensure that boot is not twisted; straighten boot if necessary.
- Use hose clip pliers V.A.G 1682- to tighten hose clip.



Tightening hose clip on air spring strut


- Apply clamp tensioner V.A.G 1682- as shown. Make sure tips of tool are applied centrally -arrow A- to clip.
- Tighten hose clip by turning spindle with torque wrench (take care to keep clamp tensioner straight).
- Tightening torque: 8 Nm
- Use torque wrench with 4...20 Nm adjustment range (e.g. -V.A.G 1410-).
- Make sure thread of spindle on tool -A- turns freely. Lubricate with MoS2 grease if necessary.
- If the thread is stiff (e.g. due to dirt), the required clamping force will not be attained at the hose clip when the specified tightening torque is applied.
- Tighten loosened bolt connections.



3.4 Removing and installing upper links

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1331-



Ring spanner insert AF 16 - V.A.G 1331/12-



◆ Torque wrench - V.A.G 1332-




Engine and gearbox jack - VAS 6931-



Protected by copyright. Copying for private or commercial purposes, i permitted unless authorised by AUDI AG. AUDI AG does not guarante for accept an with respect to the correctness of information in this document. Copy



♦ Support - T10149-





- ♦ For vehicles with air suspension: vehicle diagnostic tester Removing
- Before starting work, measure distance from centre of wheel to lower edge of wheel housing \Rightarrow "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15.
- Position vehicle on lifting platform ⇒ page 18.
- Remove body brace ⇒ page 87.

- Unscrew bolts -arrows- and push washer fluid reservoir -1slightly to one side.
- Remove wheel ⇒ page 329 .
- Secure brake disc with one wheel bolt.




Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does no with respect to the correctness of information in this docu






Remove bolt -3-.




- Detach brake line and electrical wiring from bracket on wheel bearing housing.
- Turn wheel hub until one of the wheel bolt holes is at the top.



Audi RS 6

- Detach retaining clip -1- and move clear hose for DRC system.
- Move clear brake hose -3- and electrical wiring -2 and 4-.



All vehicles

- Attach support T10149- -1- to wheel hub using wheel bolt.
- Support wheel bearing housing using support T10149- with engine and gearbox jack - V.A.G 1383 A- .



Do not raise or lower the vehicle while the engine and gearbox jack is under the vehicle.

Do not leave the engine and gearbox jack under the vehicle for longer than necessary.

Unscrew bolted connection -1-.



Do not attempt to enlarge slots in wheel bearing housing using a chisel or similar.

Take both joint pins of upper links -2- out of wheel bearing housing.



Note

Lower wheel bearing housing only as far as necessary.


Protected by copyright. Copying for private or commercia permitted unless authorised by AUDI AG. AUDI AG does with respect to the correctness of information in this do


- Unscrew nuts -arrows- and swivel air spring strut or coil spring/ shock absorber down and outwards out of suspension turret.
- Leave air spring strut or coil spring/shock absorber in vehicle.




Note

Take care not to damage any part of the vehicle.









 Remove bolts -4- and -3- and detach upper link (front) and upper link (rear).

Installing


Installation is carried out in reverse sequence. Note the following:





Note


Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position

- ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or
- ⇒ "3.14 Lifting suspension to unladen position vehicles with coil springs", page 12.











 Insert air spring strut or coil spring/shock absorber into suspension turret and tighten nuts -arrows- in diagonal sequence.



Protected by copyright. Copying for private or commercial purposes, in papermitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyrigh



Refit bolt connection -3-, but do not tighten yet.



Tighten bolted connection -1-.



Note

Press down upper links as far as possible while tightening nut.

Raise suspension to reference position ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12



Note

When tightening bolts -3- and -4-, upper links must be pressed towards inside of vehicle.

- Tighten bolts -4- and -3-.
- Tighten remaining bolts.
- Fit wheel ⇒ page 329.
- Set down vehicle on its wheels ⇒ page 18.
- Check and adjust wheel alignment as required, see chart ⇒ page 344 .


Tightening torques

Renewing bush for upper link

Special tools and workshop equipment required


Protected Assembly 1001 or 3301 for private or commercial purposes, in part or in permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept with respect to the correctness of information in this document. Copyright by Al







Assembly tool - 3348-



Procedure

Upper suspension link removed ⇒ page 74.


Extracting bonded rubber bush



Note

Always use soft jaws when clamping suspension links in a vice.

- Set up special tools as shown in illustration.
- Extract bonded rubber bush by turning nut.




Installing bonded rubber bush


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not it Note needs authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Do not use lubricant.

A = Bush

- Set up special tools as shown in illustration.
- Pull in bonded rubber bush as far as the stop.
- Check installation depth of bonded rubber bush -1- in suspension link -2-.
- · Dimensions -a- and -b- must be the same.
- Pull bush in further if dimensions -a- and -b- are not equal.
- Install upper link ⇒ page 74.





3.6 Charging suspension strut




Note

This procedure relates to the air spring strut.




Special tools and workshop equipment required

♦ Adapters - T10157-



♦ Filler unit for air suspension strut - VAS 6231-



Gas cylinder: Argon or Corgon




Note

Replacement air spring struts are supplied with a minimum gas filling. After a period of storage, they may lose some of this initial pressure (in the same way as a tyre). The minimum pressure must therefore be checked, and if necessary »recharged« to the required level before the air spring struts are taken out of their packaging. If the strut is taken out of its packaging without checking and recharging the pressure, this can cause indentations or kinks to form in the U-bellows before it reaches its normal shape. This can damage the bellows and cause premature failure of the purposes, in part or in whole, is not

air spring strut.

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- Remove cover from packaging less of information in this document. Copyright by AUDI AG.
- Remove union screw -arrow- from residual pressure valve.
- Close valve on gas cylinder.
- Make sure that you are familiar with the relevant safety instructions for the use of pressurised containers and industrial gases.



- Connect filler unit for air suspension strut VAS 6231- and adapter - T10157- as illustrated.
- 1 Air spring strut in its packaging
- 2 Gas cylinder for argon or Corgon with fittings
- 3 Filler unit for air suspension strut VAS 6231-
- 4 Adapter T10157-





Note

To stop "unfiltered" air entering the air spring system, the suspension strut (air suspension) may only be »recharged« with the gases listed above.



Set restrictor valve to 2.0 ltr./min -arrow-.
Protected by copyright. Copying for private or commercial purposes, in
permitted unless authorised by AUDI AG. AUDI AG does not guarantee
with respect to the correctness of information in this document. Copyr





- Now charge the air spring strut with gas up to approx. 5.0 bar, using several separate bursts of pressure.
- Disconnect filler unit for air suspension strut VAS 6231- from adapter - T10157-; gas pressure in excess of 3.5 bar will then be released.

The minimum pressure has now been restored. You can take the air spring strut out of the packaging.


 After installation, set the suspension to the raised level setting and then back to the normal level. Repeat this procedure once more.

Most of the gas will be replaced with the filtered air from the air supply unit once the suspension has twice moved up and down to these settings.

Install air spring strut ⇒ page 65.

3.7 Removing and installing shock absorber fork

Special tools and workshop equipment required





♦ Spreader - 3424-



◆ Torque wrench - V.A.G 1331-



V.A.G 1331 with respect to the correctness of information in this document. Copyright by AUDI AG. W00-11166

◆ Torque wrench - V.A.G 1332-




♦ Tensioning strap - T10038-





Ball joint puller - T40010 A-




Removing

- Before starting work, measure distance from centre of wheel to lower edge of wheel housing
 ⇒ "3.14 Lifting suspension to unladen position vehicles with coil springs", page 12 or
 ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15
- Remove plenum chamber cover ⇒ General body repairs, exterior; Rep. gr. 50; Bulkhead; Removing and installing plenum chamber cover.
- Remove wheel ⇒ page 329 .
- Tie up wheel bearing housing with tensioning strap T10038--1-, as shown in illustration.




Note

Wheel bearing housing must be supported to avoid damaging joints of upper links.



- Detach bolted connections -1- and -3-.
- Take out coupling rod -2-.

Protected by copyright. Copying for private or commercial purposes, permitted unless authorised by AUDI AG. AUDI AG does not guarant with respect to the correctness of information in this document. Copy







Unscrew nut -1- on joint pin -2- of track rod ball joint until it is flush with end of thread. Counterhold if necessary when loosening.




Note

Leave nut screwed on a few turns to protect threads on joint pin.







- Detach bolted connections -2 and 3-.
- Detach bolted connection -1-, guide out track control link and swivel forwards.




Note


To remove bolt -1-, turn steering rack to full left or right lock depending on which side of the vehicle you are working on.

- Detach bolt connection -1-.



Protected by copyright. Copying for private or commercial purposes, in protected by copyright. permitted unless authorised by AUDI AG. AUDI AG does not guarantee of with respect to the correctness of information in this document. Copyright by AUDI AG.









- Insert spreader 3424- in slot in shock absorber fork.
- Turn ratchet handle through 90° and pull ratchet handle off spreader - 3424- -1-.
- Pull shock absorber fork downwards off shock absorber tube and remove.

Installing

Installation is carried out in reverse sequence. Note the following:







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Note

- Version 1: If present, make sure that T-bolt -arrow- engages in groove of shock absorber fork when fitting.
- ♦ Version 2: If present, make sure that pin -1- engages in groove -2- of shock absorber fork when fitting.
- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raise suspension to unladen position or reference position ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12.
- On vehicles with automatic headlight range control, perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights .
- If the vehicle level sender has been removed and refitted or the linkage detached, the reference position must be re-adap $ted \Rightarrow page 283$.
- If the reference position has been re-adapted on vehicles with lane departure warning, the camera control unit - J852- must be recalibrated ⇒ page 365.
- Fit wheel ⇒ page 329.
- Check and adjust wheel alignment as required, see chart <u>⇒ page 344</u> .

Tightening torques


- page 57
- ⇒ "4.1 Exploded view lower suspension links, swivel joint", page 89

3.8 Removing and installing body brace

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1783-

Protected by copyright. Copying for private or commercial purposes, permitted unless authorised by AUDI AG. AUDI AG does not guaran with respect to the correctness of information in this document. Co






♦ Torque wrench - V.A.G 1331-

Protected by copyright. Copying for private or commercial purposes, improved permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Removing

- Remove plenum chamber cover ⇒ General body repairs, exterior; Rep. gr. 50; Bulkhead; Removing and installing plenum chamber cover.
- Remove spreader rivets -arrows- on both sides, unscrew nut
 -2- and unclip cover -1-.




Remove bolts -1 to 3- and -arrows- and detach body brace.
 Installing

Installation is carried out in reverse sequence.

Tightening torques

♦ "3.1 Exploded view - suspension strut, upper links", page 57





4 Lower suspension links, swivel joint

- ⇒ "4.1 Exploded view lower suspension links, swivel joint", page
- ⇒ "4.2 Removing and installing track control link", page 91
- ⇒ "4.3 Removing and installing guide link", page 94
- ⇒ "4.4 Renewing bush for track control link", page 97
- ⇒ "4.5 Removing and installing swivel joint", page 103
- ⇒ "4.6 Removing and installing bonded rubber bush for guide link", page 104 with respect to the correctness of information in this document. Copyright by AUDI AG.

4.1 Exploded view - lower suspension links, swivel joint

1 - Bolt

☐ Always renew if removed

2 - Guide link

- Removing and installing ⇒ page 94
- Renewing bonded rubber bush for guide link ⇒ page 104

3 - Nut


- ☐ 70 Nm +180°
- Always renew if removed
- Vehicle must be in reference position when tightening
 - ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or
 - ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12
- 4 Wheel bearing housing

5 - Bolt

- □ 40 Nm
- Always renew if removed

6 - Nut

- □ 140 Nm
- □ Always renew if removed



- ☐ After detaching guide link from wheel bearing housing, remove residual adhesive from thread of joint pin.
- 7 Swivel joint
 - □ Removing and installing ⇒ page 103
 - ☐ Different versions; for correct version, refer to ⇒ Electronic parts catalogue



Note

- ♦ Note installation position ⇒ page 104.
- Insert swivel joint all the way onto contact surface on wheel bearing housing.

8 - Nut	
	M12: 120 Nm
	M14: 140 Nm Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not
	Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Different versions; for correct version, refer to > Electronic parts catalogue permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability Always renew if removed
	After detaching swive joint from wheel bearing housing, remove residual adhesive from thread of joint
pin.	
9 - Nu	90 Nm +90°
	Always renew if removed
	Vehicle must be in reference position when tightening
_	⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12
10 - Track control link	
	Removing and installing ⇒ page 91
	Different versions; for correct version, refer to ⇒ Electronic parts catalogue
	Renewing bonded rubber bush for track control link (at wheel bearing housing end) ⇒ page 97
	Renewing bonded rubber bush for track control link (at subframe end) <u>⇒ page 99</u>
11 - Bolt	
	Always renew if removed
12 - Nut	
	Always renew if removed
	9 Nm
13 - Bolt	
	Always renew if removed
14 - Nut	
	70 Nm +180°
	Always renew if removed
	Vehicle must be in reference position when tightening
	 ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12
15 - F	ront left vehicle level sender - G78- or front right vehicle level sender - G289-
	Remove/install and renew only as a complete assembly ⇒ page 286
	Lever of sender must face towards rear
	Perform basic setting of headlights if sender mountings are loosened ⇒ Electrical system; Rep. gr. 94 ; Headlights; Adjusting headlights
	If the vehicle level sender has been removed and refitted or the linkage detached, the reference position must be re-adapted: start appropriate program on \Rightarrow Vehicle diagnostic tester in Guided Functions.
	If the reference position has been re-adapted on vehicles with lane departure warning, the camera control unit - J852- must be recalibrated \Rightarrow page 365.
16 - Bolt	
	9 Nm
17 - S	Shock absorber fork

V.A.G 1332



4.2 Removing and installing track control link

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1332-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not W00-11165 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability


Att Engine and gearbox jacks-VAS 6931 ion in this document. Copyrigh



♦ Support - T10149-




♦ Ball joint puller - T40010 A-






Ring spanner insert - V.A.G 1332/7-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

- For vehicles with air suspension: Vehicle diagnostic tester of guarantee or accept any liability Removing respect to the correctness of information in this document. Copyright by AUDI AG.
- Before starting work, measure distance from centre of wheel to lower edge of wheel housing
 ⇒ "3.14 Lifting suspension to unladen position vehicles with coil springs", page 12 or
 ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15.
- Position vehicle on lifting platform ⇒ page 18.
- Remove wheel ⇒ page 329 .
- Remove noise insulation ⇒ General body repairs, exterior;
 Rep. gr. 66; Noise insulation; Removing and installing noise insulation.
- Remove nut -2-.
- Detach bolt connection -3-.



 Unscrew nut -1- on joint pin -2- of track rod ball joint until it is flush with end of thread. Counterhold if necessary when loosening.





Leave nut screwed on a few turns to protect threads on joint pin.


 Press track rod ball joint off wheel bearing housing using ball joint puller - T40010 A- . Then remove nut.




Note

Make sure the two lever arms of the puller are parallel when maximum force is exerted; adjust as necessary.

- To avoid damage to joints of upper links, support wheel bearing housing (e.g. using engine and gearbox jack -V.A.G 1383 A-) to prevent the suspension from extending too
- Attach support T10149- to wheel hub using wheel bolt.
- Support wheel bearing housing using support T10149- with engine and gearbox jack - V.A.G 1383 A-.





- Detach bolt connection -1-.



Note


To remove bolt -1-, turn steering rack to full left or right lock depending on which side of the vehicle you are working on.


- Guide out track control link and swivel towards rear.
- Unscrew nut on swivel joint pin until it is flush with end of thread. Counterhold if necessary when loosening.
- Press swivel joint pin out of tapered seat using ball joint puller - T40010 A- .



Note

- ♦ Make sure the two lever arms of the puller are parallel when maximum force is exerted; adjust as necessary.
- Take care not to damage boot.
- To avoid damage to joints of upper links, support wheel bearing housing (e.g. using engine and gearbox jack -V.A.G 1383 A-) to prevent the suspension from extending too far.





- Remove nut from joint pin of track control link, commercial purposes, in part or in whole, is not
- Take out track control link ised by AUDI AG. AUDI AG does not guarantee or accept any liability

Installingh respect to the correctness of information in this document. Copyright by AUDI AG.

Installation is carried out in reverse sequence. Note the following:





Note

- Bonded rubber bushes can only be turned to a limited extent.
 The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raise suspension to reference position
 ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or
 ⇒ "3.14 Lifting suspension to unladen position vehicles with coil springs", page 12.
- ♦ When tightening bolted connection -1-, track control link must be pressed towards inside of vehicle.
- Remove remaining adhesive from thread of joint pin on swivel joint.
- On vehicles with automatic headlight range control, perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights.

Profethe vehicle fevel sender has been removed and refitted ors, in part or in whole, is not per the linkage detached, the reference position must be re-adaptee or accept any liability ted: start appropriate program on a Vehicle diagnostic tester with Guided Functions ess of information in this document. Copyright by AUDI AG.

- If the reference position has been re-adapted on vehicles with lane departure warning, the camera control unit - J852- must be recalibrated ⇒ page 365.
- Fit wheel ⇒ page 329.
- Check and adjust wheel alignment as required, see chart
 ⇒ page 344

Tightening torques


 \$\text{\text{"4.1 Exploded view - lower suspension links, swivel joint",}}
 page 89

4.3 Removing and installing guide link

Special tools and workshop equipment required


◆ Torque wrench - V.A.G 1332-








◆ Ring spanner insert - V.A.G 1332/7-



◆ Engine and gearbox jack - VAS 6931-




♦ Support - T10149-



Ball joint puller - T40042-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is no permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liab with respect to the correctness of information in this document. Copyright by



♦ For vehicles with air suspension: vehicle diagnostic tester

Removing

Before starting work, measure distance from centre of wheel to lower edge of wheel housing ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or


⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15.

- Position vehicle on lifting platform ⇒ page 18.
- Remove wheel ⇒ page 329.
- Remove noise insulation ⇒ General body repairs, exterior;
 Rep. gr. 66; Noise insulation; Removing and installing noise insulation.
- Secure brake disc with one wheel bolt.
- Unscrew nut on joint pin of guide link until it is flush with end of thread. Counterhold joint pin if necessary.
- Press joint pin of guide link out of tapered seat using ball joint puller - T40042- .




Note

- Take care not to damage boot.
- Make sure the two lever arms of the puller are parallel when maximum force is exerted.
- ♦ Secure ball joint puller to prevent it dropping.
- Remove heat shield -2- ⇒ page 52.





Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG d with respect to the correctness of information in this




- Detach bolt connection -1-.
- Remove guide link from subframe.

Installing

Installation is carried out in reverse sequence. Note the following:

- If guide link is to be re-installed, remove locking fluid from thread of ball joint beforehand.
- Initially only hand-tighten bolts/nuts for components with bonded rubber bush.







Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- ♦ Raise suspension to reference position ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 or ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 .
- ♦ When tightening bolted connection -1-, guide link must be pressed towards inside of vehicle.
- Fit wheel ⇒ page 329.
- Set down vehicle on its wheels ⇒ page 18.
- Check and adjust wheel alignment as required, see chart <u>⇒ page 344</u> .

Tightening torques

- ⇒ "4.1 Exploded view lower suspension links, swivel joint",
- ♦ ⇒ "2.1 Exploded view subframe", page 28

4.4 Renewing bush for track control link


⇒ "4.4.1 Renewing bush for track control link (wheel bearing housing end)", page 97

⇒ "4.4.2 Renewing bush for track control link (subframe end)", page 99

4.4.1 Renewing bush for track control link (wheel bearing housing end)




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Special tools and workshop equipment required



- ◆ Thrust plate VW 402-
- ♦ Press tool VW 412-
- ♦ Tube VW 516-
- ♦ Tube 3296-
- Assembly paste G 052 109 A2-

Procedure

Track control link removed ⇒ page 91



Note

Track control link must be held in position while bonded rubber bush is being removed or installed.




Pressing out bonded rubber bush

- Mark position (installation depth) of bonded rubber bush -1on bush -arrow-.

Use a waterproof felt-tip pen or similar for marking.

- Apply special tools as shown in illustration.
- Press bonded rubber bush -1- out of track control link -2-.



Pressing in bonded rubber bush

- Transfer marking for installation depth from old bonded rubber bush to new bush.
- Lightly lubricate bonded rubber bush with assembly paste -G 052 109 A2- .
- Locate bonded rubber bush -1- in track control link -2-.
- Apply special tools as shown in illustration.




Note


Make sure bonded rubber bush remains straight while pressing s, in p permitted unless authorised by AUDI AG. AUDI AG does not guarantee of

- with respect to the correctness of information in this document. Copyrig Press bonded rubber bush -1- into track control link -2-.
- Refit to marking made before removal -arrow-.
- Check installation depth of bonded rubber bush -1- in track control link -2-.

Dimensions -a- and -b- must be equal.

- Press bonded rubber bush -1- in further if dimensions -a- and -b- are not equal.
- Install track control link ⇒ page 91.






4.4.2 Renewing bush for track control link (subframe end)

Special tools and workshop equipment required



Workshop press - V.A.G 1290A-




Press tool - VW 407-




Protected by copyright. Copying for private or commercial purps permitted unless authorised by AUDI AG. AUDI AG does no with respect to the correctness of information in thi



Assembly tool - 3346-



Assembly tool - T40032-





♦ Thrust plate - VW 402-



♦ Assembly paste - G 052 109 A2-

Procedure

Track control link removed ⇒ page 91




Note

Track control link must be held in position while bonded rubber bush is being removed or installed.

Pressing out bonded rubber bush


Mark position of "kidney-shaped cavities" of bonded rubber bush on track control link -arrows-, as shown in illustration.



Use a waterproof felt-tip pen or similar for marking.


- Apply special tools as shown in illustration.
- Press bonded rubber bush out of track control link.

Protected by copyright. Copying for private or commercial purposes, in part or in YWh407, is n permitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyrigi



Pressing in bonded rubber bush


- Lightly lubricate bonded rubber bush with assembly paste -G 052 109 A2- .
- Insert bonded rubber bush into track control link on side with chamfer -arrow-.



Adjust position of "kidney-shaped cavities" with markings -arrows- on track control link made before removal.



Protected by copyright. Copying for private or com



Apply special tools as shown in flustrationsed by AUDI AG. AUDI AG






Note

Make sure bonded rubber bush remains straight while pressing in.


Press bonded rubber bush into track control link.



Check installation depth of bonded rubber bush -1- in track control link -2-.

Dimensions -a- and -b- must be equal.

- Press bonded rubber bush -1- in further if dimensions -a- and -b- are not equal.
- Install track control link ⇒ page 91.





Removing and installing swivel joint 4.5

Special tools and workshop equipment required


♦ Torque wrench - V.A.G 1332-




♦ Ring spanner insert - V.A.G 1332/7-




permitted unless authorised by AUDI AG. AUDI AG does n




Ball joint puller - T40010tA-the correctness of information in this doc



- ♦ For vehicles with air suspension: vehicle diagnostic tester Removing
- Remove track control link ⇒ page 91.
- Remove bolt -1-.



- Insert washer -2- (or similar part) into slot on wheel bearing housing. Choose a washer (or similar part) with the same width as the slot.
- Screw in bolt -1- from rear side until it makes contact with washer (or similar part).
- Widen slot on wheel bearing housing by screwing bolt -1- further in (half a turn).
- Take swivel joint out of wheel bearing housing.



Installing

Installation is carried out in reverse sequence. Note the following:

Insert swivel joint -1- all the way onto contact surface -arrows- on wheel bearing housing -2-.

Protected by copyright. Copying for private or commercial purposes pNotetted unless authorised by AUDI AG. AUDI AG does not guaran

If the swivel joint -1- does not make proper contact with the sur-face -proper contact with the sur-postion on the whole way occur in the area of the bolted connection on the wheel bearing housing -2-.

- Install track control link ⇒ page 91.
- Fit wheel ⇒ page 329.
- Check and adjust wheel alignment as required, see chart <u>⇒ page 344</u> .


Tightening torques

⇒ "4.1 Exploded view - lower suspension links, swivel joint", page 89

4.6 Removing and installing bonded rubber bush for guide link

Special tools and workshop equipment required

♦ Thrust plate - VW 402-









♦ Press tool - VW 412-




♦ Tube - VW 463/2-



♦ Sleeve - 3144-



♦ Workshop press - V.A.G 1290A-



Assembly lubricant (diluted 1:20 with water); for correct type refer to ⇒ Electronic parts catalogue

> Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Pressing out bonded rubber bush

- Guide link removed ⇒ page 94
- Mark installation position -arrow- on bonded rubber bush -4at top and bottom.

Use a waterproof felt-tip pen or similar for marking.

- Set up special tools as shown in illustration:
- Press tool of workshop press V.A.G 1290A-
- Press tool VW 412-
- Tube VW 463/2-
- Bonded rubber bush
- 5 -Guide link
- 6 -Sleeve - 3144-
- Thrust plate VW 402-
- Press bonded rubber bush -4- out of guide link -5-.



Note

Hold the guide link when pressing the bonded rubber bush in or out.


Pressing in bonded rubber bush


- Transfer marking for installation position from old bonded rubber bush to new bush.
- Lightly lubricate new bush with assembly lubricant ⇒ Electronic parts catalogue.

Installation position of bonded rubber bush

Slot in core of bush -1- should be in line with centre line of guide link and should point towards inside of guide link.

Arrow -2- should point towards inside of guide link.







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




- Fit bonded rubber bush -4- into guide link -5- (note correct installation position).
- Set up special tools as shown in illustration:
- Press tool of workshop press V.A.G 1290A-
- Press tool VW 412-
- Tube VW 463/2-3 -
- Bonded rubber bush
- 5 -Guide link
- Sleeve 3144-6 -
- Thrust plate VW 402-7 -



Note

Make sure bonded rubber bush remains straight while pressing





Note marking made before removal arrow. Private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

Check installation depth -a- of bonded rubber bush in guide

Dimension -a- = 18 mm

- If dimension -a- is not attained, press bonded rubber bush in
- Install guide link ⇒ page 94.






5 Wheel bearing

- ⇒ "5.1 Exploded view wheel bearing", page 108
- ⇒ "5.2 Removing and installing wheel bearing housing", page 110
- ⇒ "5.3 Removing and installing wheel bearing unit", page 113
- ⇒ "5.4 Servicing wheel bearing unit", page 115

5.1 Exploded view - wheel bearing



Permissible lateral runout of wheel hub (at out-

er diameter) when installed: max. 0.02 mm

- Measure lateral run-out with dial gauge VAS 6079- and dial gauge bracket for brake discs VAS 6079/1-
- 11 Wheel bearing
 - □ Removing and installing wheel bearing unit ⇒ page 113
 - □ Removing and installing ⇒ page 115
- 12 Bolt
 - □ 40 Nm
 - □ Always renew if removed




- 13 Nut
 - □ 140 Nm
 - Always renew if removed
 - ☐ After detaching guide link from wheel bearing housing, remove residual adhesive from thread of joint pin.
- 14 Track control link
- 15 Nut
 - ☐ M12: 120 Nm
 - ☐ M14: 140 Nm
 - ☐ Different versions; for correct version, refer to ⇒ Electronic parts catalogue
 - Always renew if removed
 - After detaching swivel joint from wheel bearing housing, remove residual adhesive from thread of joint pin.
- 16 Guide link
- 17 Track rod ball joint
- 18 Nut
 - ☐ Tightening torque ⇒ page 402
 - Always renew if removed
- 19 Bolt
 - ☐ Tightening torque ⇒ Brake system; Rep. gr. 45; Sensors; Exploded view front wheel speed sensor
- 20 Speed sensor
- 21 Drive shaft
- 22 Bolt
 - ☐ M10: 50 Nm + 90°
 - ☐ M12: 90 Nm + 90°
 - Always renew if removed
- 23 Countersunk bolts
 - 80 Nm +90°
 - □ Always renew if removed

Avoid dirtying or damaging the seal when picking up, laying down or storing the wheel bearing

- The wheel bearing -1- must always be pointing upwards.
- Always put down the wheel bearing unit with the wheel hub
 -2- facing downwards.

Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG do with respect to the correctness of information in this





- Do not touch the inside of the wheel bearing when you pick it
- Always take hold of the outside of the wheel bearing.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not **Removing and installing wheel bearing**, permitted unless authorised by AUDI AU. AUDI AU does not guarantee or accept any liability 5.2 housing with respect to the correctness of information in this document. Copyright by AUDI AG.

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1331-



Torque wrench - V.A.G 1332-






♦ Ring spanner insert - V.A.G 1332/7-




Removing

- Before starting work, measure distance from centre of wheel to lower edge of wheel housing "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or ⇒ "3.15 Lifting suspension to reference position (vehicles with
 - air suspension)", page 15
- Slacken bolt securing drive shaft to wheel hub ⇒ page 124.
- Prote Remove bolt carrows and detach bracket 1 for brake line and part electrical wiring from wheel bearing housing.
- Remove speed sensor (front) ⇒ Brake system; Rep. gr. 45;
 Sensors, Removing and installing front speed sensors -G45-y ight -G47- .
 - Remove brake disc and brake caliper ⇒ Brake system; Rep. gr. 46; Front brakes; Removing and installing brake disc.




- Remove bolts -arrows- and take off splash plate -1-.
- Remove track control link ⇒ page 91.
- Unscrew nut on joint pin of guide link until it is flush with end of thread. Counterhold if necessary when loosening.



Leave nut screwed on a few turns to protect threads on joint pin.

- Press joint pin of guide link out of tapered seat using ball joint puller - T40042- .





- Unscrew bolted connection -1-.
- opyright. Copying for private or con Take both joint pins of upper links -2- out of wheel bearing housing.

Do not attempt to enlarge slots in wheel bearing housing using a chisel or similar.

Pull wheel bearing housing off drive shaft splines and remove.




Note


- Do not let the drive shaft hang down under its own weight, as otherwise excessive bending could damage the inner CV joint.
- Tie up drive shaft to body with wire.

Installing

Installation is carried out in reverse sequence. Note the following:

- Push wheel bearing housing onto drive shaft splines.
- Fit both joint pins of upper links -2- into wheel bearing housing and insert bolt -1-.
- Remove remaining adhesive from thread of joint pin on swivel joint and guide link.
- Attach guide link to wheel bearing housing and tighten.
- Install track control link ⇒ page 91.









Note

Press down upper links -2- as far as possible while tightening nut.

- Tighten bolted connection -1-.
- Install brake disc and brake caliper ⇒ Brake system; Rep. gr. 46; Front brakes; Removing and installing brake disc.
- Tighten bolt securing drive shaft to wheel hub ⇒ page 124.
- On vehicles with automatic headlight range control, perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights .
- If the vehicle level sender has been removed and refitted or the linkage detached, the reference position must be re-adapted: start appropriate program on ⇒ Vehicle diagnostic tester in Guided Functions.
- If the reference position has been re-adapted on vehicles with lane departure warning, the camera control unit - 1852-must, in part or in whole, is not
- be recalibrated ⇒ page 365. sed by AUDI AG. AUDI AG does not guarantee or accept any liability
- rmitted unless authorise Fi**t wheel** <mark>⇒ page 329</mark> . th respect to the correctness of information in this document. Copyright by AUDI AG. Check and adjust wheel alignment as required, see chart
- ⇒ page 344 .

Tightening torques


- ♦ ± "5.1 Exploded view wheel bearing", page 108
- ⇒ "4.1 Exploded view lower suspension links, swivel joint", page 89

5.3 Removing and installing wheel bearing

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1331-






Torque wrench - V.A.G 1332-




Torque wrench - V.A.G 1576-




Removing

- Remove drive shaft ⇒ page 122 .
- Remove brake disc and brake caliper ⇒ Brake system; Rep. gr. 46; Front brakes; Removing and installing brake disc.
- Remove speed sensor (front) ⇒ Brake system; Rep. gr. 45; Sensors; Removing and installing front speed sensors -G45-/ -G47- .
- Remove countersunk bolts -arrows-.
- Take out wheel bearing unit.




Avoid dirtying or damaging the seal when picking up, laying down or storing the wheel bearing.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- The wheel bearing -1- must always be pointing upwards.
- Always put down the wheel bearing unit with the wheel hub -2- facing downwards.



- Do not touch the inside of the wheel bearing when you pick it up.
- · Always take hold of the outside of the wheel bearing.
- Servicing wheel bearing unit ⇒ page 115.


Installing

Installation is carried out in reverse sequence. Note the following:

- Install drive shaft ⇒ page 122.
- Fit wheel ⇒ page 329 .

Tightening torques

◆ ⇒ "5.1 Exploded view - wheel bearing", page 108




5.4 Servicing wheel bearing unit

Special tools and workshop equipment required

♦ Thrust plate - VW 401-

Protected by copyright. Copying for private or commercial purp permitted unless authorised by AUDI AG. AUDI AG does not guara with respect to the correctness of information in this document. Copyrigh






Thrust plate - VW 402-



Protected by copyright. Copying for private or commercial purposes, in part of in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not of

Press tool - VW 412-





VW 402

Assembly tool - T10230-



- Workshop press VAS 6654-, not illustrated
- Puller set for inner bearing races VAS 701 003- (not illustrated)


Procedure

Wheel bearing unit removed ⇒ page 113



Pressing wheel hub out of wheel bearing

- Set up special tools as shown in illustration.
- 1 Press tool VW 412-
- 2 Sleeve -T10230/3-
- 3 -ProThrust piece yT110230/8 ying for private or commercial purposes, in part or in whole,
- 4 -perWheel bearing unit rised by AUDI AG. AUDI AG does not quarantee or accept any liabi
- 5 -witThrust plateth VW 402-ness of information in this document. Copyright by AUDI AG.
- 6 Thrust plate VW 401-
- Press wheel hub out of wheel bearing.




Pressing inner bearing race off wheel hub

- Prepare puller from puller set for inner bearing races VAS 701 003- as follows:
- Screw clamping sleeve VAS 701 003/1- onto clamp tensioner
 VAS 701 003/7- .
- Screw threaded spindle VAS 701 003/2- into clamping sleeve and fit thrust piece - VAS 701 003/3- .

VAS 701 003/3 VAS 701 003/1 VAS 701 003/2 VAS 701 003/7 A42-10885


Inner bearing race version 1:

- Remove ball cage from inner bearing race -2-.
- Apply puller -1- to ball raceways -arrow- of inner race, as shown.



Inner bearing race version 2:


- Apply puller -1- to groove -arrow- of inner race -2-.



All versions (continued):

- Clamp puller in place on inner race -2-; to do so, use spanner VAS 701 003/7- to turn clamp tensioner VAS 701 003/5- in direction of -arrow- and counterhold clamping sleeve VAS 701 003/1- with tensioner handle VAS 701 003/4- .
- Use threaded spindle VAS 701 003/2- to detach inner bearing race from wheel hub -1-.

Protected by copyright. Copying for private or comme permitted unless authorised by AUDI AG. AUDI AG do with respect to the correctness of information in this





Pressing wheel hub into wheel bearing


Instructions for handling wheel bearing ⇒ page 115

- Set up special tools as shown in illustration.
- 1 Press tool VW 412-
- 2 Thrust plate VW 402-
- 3 Wheel hub
- 4 Wheel bearing
- 5 Thrust plate & MW 401 ight. Copying for private or commercial purp
- The machined surface of the wheelybearing outer race faces of guadownwards.
 With respect to the correctness of information in this document



Take precautions not to damage or dirty the wheel bearing.

- Make sure no dirt gets between thrust plate VW 401- and wheel bearing when pressing in the hub or when the parts are placed on a workbench, etc.
- Press wheel hub into wheel bearing.
- Install wheel bearing unit ⇒ page 113.





6 Drive shaft

- ⇒ "6.1 Overview drive shaft", page 120
- ⇒ "6.2 Exploded view drive shaft", page 120
- ⇒ "6.3 Removing and installing drive shaft", page 122
- ⇒ "6.4 Loosening and tightening bolt securing drive shaft", page 124
- ⇒ "6.5 Dismantling and assembling drive shaft", page 125
- ⇒ "6.6 Servicing constant velocity joint", page 131
- ⇒ "6.7 Checking outer constant velocity joint", page 132
- ⇒ "6.8 Tightening hose clip on triple roller joint and outer joint", page 133

Overview - drive shaft 6.1

- Peened triple roller joint AAR 3300 i with outer constant velocity joint (94 mm diameter)
- Peened triple roller joint AAR 3300 i with outer constant velocity joint (98 mm diameter)
- Peened triple roller joint AAR 3300 i with outer constant velocity joint (100 mm diameter)
- ♦ Peened triple roller joint AAR 3300 i with outer constant velocity joint (106 mm diameter)
 Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not
- 6.2 pe**Exploded**s**view** or i**drive** shaft. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



1 - Hose clip

- Different versions (depending on type of drive shaft)
- Always renew if removed
- □ Tightening ⇒ page 133
- □ Atriple roller joint adapt-d er is installed on drive shafts with peened triple roller joint AAR 3300 i
 - Boot must rest in groove and on contour of joint body.

3 - Hose clip

- □ Different versions (depending on type of drive shaft)
- □ Always renew if removed
- ☐ Tightening ⇒ page 133

4 - Circlip

- Always renew if removed
- □ Fit into annular groove on shaft before installing (no longer visible once joint is installed)
- □ Before fitting constant velocity joint, align ciring facing upwards.
- clip centrally with open-5 - Outer constant velocity joint Renew only as complete unit □ Removing ⇒ page 131
 - □ Checking ⇒ page 132


 - □ Installing ⇒ page 131
 - □ Greasing ⇒ page 122
 - ☐ Grease splines on drive shaft lightly with grease used in joint when fitting joint onto drive shaft

6 - Bolt

- ☐ 200 Nm +180°
- Always renew if removed
- ☐ Before securing, clean the threads in the CV joint using a thread tap
- ☐ Keep to specified sequence when loosening and tightening bolt securing drive shaft to wheel hub ⇒ page 124

7 - Hose clip

- Always renew if removed
- □ Tightening ⇒ page 133
- 8 Boot for outer constant velocity joint
 - Check for splits and chafing
- 9 Hose clip
 - Always renew if removed



10 - Drive shaft

□ Removing and installing ⇒ page 122

11 - Circlip

- □ Always renew if removed
- Insert in groove on shaft

12 - Triple roller spider

- Mark installation position before removing
- □ ⇒ "6.5 Dismantling and assembling drive shaft", page 125
- Grease splines on drive shaft lightly with grease used in joint when fitting triple roller spider onto drive shaft

13 - Circlip

- □ Always renew if removed
- Insert in groove on shaft

14 - Bolt

- Always renew if removed
- □ For correct version refer to ⇒ Electronic parts catalogue
- ☐ Tightening torque ⇒ Item 22 (page 109)

15 - Joint body

⇒ "6.5 Dismantling and assembling drive shaft", page 125

Grease quantity and type

Regrease joint when renewing boot.

For required grease filling of joints, refer to ⇒ Electronic parts catalogue.



Note

Note that different types of grease are required for outer and inner joints.

	Grease	of which in:	
Outer joint	Total quantity	Joint	Boot
Ø mm	[g]	[g]	[g]
94	approx. 194	approx. 70 1)	approx. 124
98	approx. 214	approx. 80 1)	approx. 134
100	approx. 140	approx. 80 1)	approx. 60
106	approx. 280	approx. 80 1)	approx. 200

	Grease	of which in:	
Inner joint	Total quantity	Joint	Boot
Designation	[g]	[g]	[g]
AAR 3300 i	approx. 160	approx. 90	approx. 70

¹⁾ Pack this amount of grease into joint through splines of ball hub. Distribute remainder on face of joint underneath boot.

Removing and installing drive shaft te or commercial purposes, in part or in whole, is not 6.3 Special tools and workshop equipment required by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




◆ Torque wrench - V.A.G 1332-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does


V.A.G 1332

♦ Torque wrenchtb V:AP.G 15761e correctness of information in this do




Removing


- Slacken bolt securing drive shaft to wheel hub ⇒ page 124.
- Remove wheel ⇒ page 329 .
- Remove noise insulation (rear) ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation .
- If fitted, remove nuts -3- and detach cover -2- for drive shaft on both sides.
- Tilt upper part of cover -2- outwards and disengage from underneath at flange -1-.
- Detach both heat shields from subframe ⇒ page 52.
- If fitted, move auxiliary water pump to one side with lines still connected.



Remove bolts -arrows- from flange shaft on gearbox.



Remove bolts -1, 2 and 3- and detach heat shield -4-.



Unscrew nut on joint pin of guide link until it is flush with end of thread. Counterhold if necessary when loosening.

Leave nut screwed on a few turns to protect threads on joint pin.

- Press joint pin of guide link out of tapered seat using ball joint puller - T40042- .
- Turn wheel bearing housing inwards as far as possible.
- Take out drive shaft.



- When removing drive shaft, take care not to damage boot.
- -Arrow- can be disregarded.

Installing

Installation is carried out in reverse sequence. Note the following:


Fit wheel ⇒ page 329.

Tightening torques

- ⇒ "6.2 Exploded view drive shaft", page 120
- ⇒ "6.4 Loosening and tightening bolt securing drive shaft", page 124
- Bolts for heat shield: 23 Nm
- ⇒ General body repairs, exterior, Repygith 66, Noise insulate or commercial purposes, in part or in whole, is not tion; Exploded view - noise insulations authorised by AUDI AG. AUDI AG does not guarantee or accept any liability


of information in this document. Copyright by AUDI AG. Loosening and tightening bolt securing 6.4 drive shaft

Special tools and workshop equipment required






◆ Torque wrench - V.A.G 1576-



Loosening bolt securing drive shaft to wheel hub

- To avoid damage to wheel bearing, slacken off bolt no further than 90° with vehicle standing on its wheels.
- Raise vehicle so that wheels are off the ground.
- Have a second mechanic press the brake pedal.
- Remove bolt -arrow-.




Tightening bolt securing drive shaft to wheel hub

- Renew bolt -arrow-.




Note

- Before securing, clean the threads in the CV joint using a thread tap
- The wheels must not be in contact with the ground when initially tightening the drive shaft bolt; otherwise the wheel bearing can be damaged.
- Have a second mechanic press the brake pedal.
- Tighten bolt to 200 Nm.
- Prower vehicle onto lits wheels for private or commercial purposes, in part or in whole, is not
- Purnibolt 180° further rised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.
- 6.5 Dismantling and assembling drive shaft



Special tools and workshop equipment required



- Thrust plate VW 401-
- Thrust plate VW 402-
- Press tool VW 408 A-
- Press tool VW 411-
- Tube VW 416 B-
- Thrust pad VW 447 H-
- Torque wrench V.A.G 1331-






◆ Torque wrench - V.A.G 1332-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

V.A.G 1332 W00-11165


♦ Clamp tensioner - V.A.G 1682A-



◆ Assembly tool - T10065-



♦ Multi-purpose tool - VW 771-






Assembly tool - T40018- for triple roller joint AAR 3300 i



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee of



with respect to the correctness of information in this document. Copyri Dismantling triple roller joint AAR 3300 \dot{i}

- Clamp drive shaft horizontally in vice.



Note

- Use jaw protectors for vice.
- Take care not to damage drive shaft.
- Mark position of joint body relative to drive shaft.

The joint may be noisy if these parts are not marked and reinstalled in their original positions.

Use a waterproof felt-tip pen for marking.

- Open hose clips -arrows-.
- Push back boot.

Determining which assembly tool to use for removal of joint body

- Measure dimension -A- as shown.
- Dimension -A- approx. 76 mm = drive shaft with triple roller joint AAR 3300 i; use assembly tool - T40018-




It is important to use the correct special tools for the different drive shafts.


- Insert assembly tool T40018- for triple roller joint AAR 3300 i behind joint body.
- Locating pin -1- must lie against outside of joint body.
- Bring assembly tool T40018- into contact with joint body by turning knurled screws -2-.




Note

- Joint body must be fixed in assembly tool T40018- without
- Tighten screws -2- only hand-tight.










- Screw multi-purpose tool VW 771- into removal and assembly tool - T40018-
- Remove joint body by knocking horizontally.
- Leave joint body clamped in assembly tool T40018- .

Protected by copyright. Copying for private or commercial purposes, in p permitted unless authorised by AUDI AG. AUDI AG does not guarantee of with respect to the correctness of information in this document. Copyri





Mark installation position of components -1- and -2- as shown.

The joint may be noisy if these parts are not marked and reinstalled in their original positions.

Use a waterproof felt-tip pen for marking.


- 1 Drive shaft
- 2 Triple roller spider
- Remove grease with a lint-free cloth.
- Remove circlip.
- 1 Pliers (commercial type)






Press triple roller spider off drive shaft.

- Use the special tools shown in the illustration.
- Assembly tool T10065/1-1 -
- Assembly tool T10065/5-, must make contact with base of triple roller spider
- 3 -Thrust plate - VW 401-
- Press tool VW 408 A-4 -
- Thrust plate VW 402-5 -
- Assembly tool T10065/5- must not rest on rollers (swivel the rollers aside if necessary).
- Press triple roller spider off drive shaft.
- Pull off boot.
- Remove grease from shaft splines.
- Check rollers and roller races for wear.
- Clean drive shaft and housing.




Assembling triple roller joint AAR 3300 i

- Push on small hose clip with joint boot and bring boot into position on drive shaft.
- Position boot between -arrows-.




Pressing triple roller spider onto drive shaft


- Grease splines -A- on drive shaft lightly with grease used in joint before fitting joint or triple roller spider onto drive shaft.
- Fit triple roller spider onto shaft so that markings are aligned and drive home onto stop.



Use assembly tool - T10065/6- and make sure it grips drive shaft at bottom seam -arrow-.


- Use the special tools shown in the illustration.
- 1 -Assembly tool - T10065/1-
- 2 -Assembly tool - T10065/6- (assembly tool must grip drive shaft at bottom seam -arrow-)
- 3 -Thrust plate - VW 401-
- Tube VW 416 B-4 -
- Thrust plate VW 447 H-5 -
- Press tool VW 411-6 -
- 7 -Thrust plate - VW 402-
- Assembly tool T10065/6- must not rest on rollers (swivel the rollers aside if necessary).
- Fit circlip.
- Circlip must engage audibly. Triple roller spider must lie directly against circlip (zero gap).
- 1 Pliers (commercial type)
- Press 70 g of drive shaft grease from repair kit into rear of triple roller joint.
- Lightly grease the rollersected by copyright. Copying for private or commercial purpose. permitted unless authorised by AUDI AG. AUDI AG does not guaran







- Use plastic-headed hammer to drive joint body over triple roller spider. Make sure rollers are aligned straight.
- Pack remaining quantity of grease into boot.
- Make sure boot is properly positioned on joint body.
- Boot must rest in groove and on contour of joint body.
- Install hose clip.






Note

To facilitate fitting of multi-point socket head bolts when installing drive shaft, fastener lug -2- on hose clip must be positioned between mounting flanges -1- on joint body.


Tighten hose clips on triple roller joint ⇒ page 133.



6.6 Servicing constant velocity joint

Removing outer constant velocity joint

- Clamp drive shaft in vice using protective jaw covers.
- Unfasten both clips and detach boot from outer joint.mmercial purp ses,
- Use hammer to tap copper or brass drift PAA against inner race t gua of constant velocity joint.
- Detach joint and boot.




Installing outer constant velocity joint

Boot and drive shaft must be free from grease.

- Always renew circlip -1-.
- Push on small hose clip with joint boot and bring boot into position on drive shaft.
- Position boot in outer groove -arrow B-.


Inner groove -arrow A- remains visible ("identification groove" for correct boot assembly).

Refer to table ⇒ page 122 and pack indicated quantity of grease inside joint body.







- Grease splines -A- on drive shaft lightly with grease used in joint before fitting joint body onto drive shaft.
- Fit circlip in groove on shaft.



- Slide on constant velocity joint as far as circlip.
- Align circlip so that opening faces upwards -arrows-.



- Screw old drive shaft bolt into joint body as shown.
- Use plastic hammer to drive joint onto drive shaft until circlip engages.
- Refer to table ⇒ page 122 and pack indicated quantity of grease into boot side of joint body.
- Push boot onto joint body.
- Vent air from boot.
- Make sure boot is properly positioned on joint body.
- Boot must rest in groove and on contour of joint body.
- Tighten hose clips on outer joint page 133 AUDI AG. AUDI AG does not guarantee or accept any liability



Checking outer constant velocity joint 6.7

The joint should be dismantled to renew dirty grease or for checking the balls and ball races for wear and damage.




Note


Ball hub and joint body are paired and must be marked before dismantling. Ensure that the balls run in the same races after assembly.

Dismantling

- Before dismantling, mark position of ball hub in relation to ball cage and joint body with an electric scriber or oil stone.
- Swivel ball hub and ball cage.
- Take out balls one after the other.



- Turn the cage until the two rectangular openings -arrow- are level with the joint body.
- Lift out cage together with hub.



- Swivel segment of hub with short lobe into square cage opening.
- Pivot hub out of cage.

Checking

The balls in each joint belong to one tolerance group. Check stub axle, hub, cage and balls for pitting and signs of seizure. Excessive backlash in the joint will cause knocking or jolts under load change; in such cases the joint must be renewed. Polished areas and visible tracks in the ball races do not justify renewal of the joint.





Note

- When assembling the joint, make sure that the individual components are refitted in their original positions.
- Make sure cage is inserted in correct position (i.e. sides facing in same direction as original position).
- Press in balls one after the other from opposite sides, taking care to re-establish original position of hub relative to cage and joint body.
- Pack required amount of grease into joint body ⇒ page 122.

6.8 Tightening hose clip on triple roller joint and outer joint


Use the following tools depending on type of hose clip:

Special tools and workshop equipment required


cept any liab (1710-0017

quarant

Locking pliers for Phaeton steering rack - VAS 6199-




Clamp tensioner - V.A.G 1682A-





Use clamp tensioner - V.A.G 1682- to fit and tighten stainless steel clips, as shown in illustration.

- Ensure jaws of tool grip niches -arrows B- on crimping ear.
- Tighten clip by turning spindle with torque wrench Cr (takenercial care to keep tool straight). authorised by AUDI AG. AUDI AG does no
- Due to the hard material of the CV joint boot (as opposed to rubber), a stainless steel hose clip is required; this can only be tightened using clamp tensioner - V.A.G 1682- .
- Tightening torque: 20 Nm.
- Use torque wrench with 5...50 Nm adjustment range (e.g. -V.A.G 1331-).
- Make sure thread of spindle on tool -A- turns freely. Lubricate with MoS2 grease if necessary.
- If the thread is stiff (e.g. due to dirt), the required clamping force will not be attained at the hose clip when the specified tightening torque is applied.




To facilitate fitting of multi-point socket-head bolts when installing drive shaft, fastener lug -2- on hose clip must be positioned between mounting flanges -1- on joint body.







- Engage hose clip by hand at first lug.
- Close hose clip using locking pliers for Phaeton steering rack - VAS 6199- -2-.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Rear suspension

Rear axle

⇒ "1.1 Overview - rear axle", page 136

1.1 Overview - rear axle

Part I

⇒ "2.1.1 Exploded view - subframe, front-wheel drive vehi-cles", page 138

⇒ "2.1.2 Exploded view - subframe, four-wheel drive vehi-cles", page 140


⇒ "3.1 Exploded view - anti-roll bar", page 200

⇒ "4.1 Exploded view - transverse links", page 203

٧-

⇒ "6.1.1 Exploded view - wheel bearing, front-wheel drive ve-hicles not including e-tron vehicles", page 240

⇒ "6.1.2 Exploded view - wheel bearing housing, four-wheel is drive vehicles and e-tron vehi-cles", page 242 to the correct



Part II



VII -

⇒ "5.1.1 Exploded view - suspension strut/shock absorber, coil spring", page 215


VIII -

⇒ "5.1.2 Exploded view - suspension strut/shock absorberying spring", page 217

permitted unless authorised by the structure of the stru

⇒ "5.113 Exploded view r suses pension strut/shock absorber, spring, shock absorber", page 218

X -⇒ "7.1 Exploded view - drive shaft", page 267



2 Subframe

- ⇒ "2.1 Exploded view subframe", page 138
- ⇒ "2.2 Fixing position of subframe", page 141
- ⇒ "2.3 Removing and installing subframe", page 146
- ⇒ "2.4 Servicing subframe", page 158

2.1 Exploded view - subframe

- ⇒ "2.1.1 Exploded view subframe, front-wheel drive vehicles", page 138
- ⇒ "2.1.2 Exploded view subframe, four-wheel drive vehicles", page 140

2.1.1 Exploded view - subframe, front-wheel drive vehicles



115 Nm +90° ◻

Always renew if removed

- 2 Bonded rubber bush (front)
- For subframe mounting
- Different versions ⇒ page 139; for correct
- with reversion referctor act Elec-o tronic parts catalogue
 - Oil stains on a hydraulic bonded rubber bush are a sign of wear
 - □ Renewing ⇒ page 158
 - Renew on both sides
- 3 Spacer
 - Different types depending on version; for correct type refer to ⇒ Electronic parts catalogue
- 4 Subframe
 - Removing and installing subframe with attachments ⇒ page 146
 - ☐ Fixing position of subframe ⇒ page 141.




Note

A four-wheel drive subframe is installed on hybrid vehicles; for correct version refer to ⇒ Electronic parts catalogue. This dies not af

fect repair work on the subframe.

5 - Spacer

- ☐ Different types depending on version; for correct type refer to ⇒ Electronic parts catalogue
- 6 Bonded rubber bush (rear)
 - For subframe mounting






☐ Different versions ⇒ page 139; for correct version refer to ⇒ Electronic parts catalogue Oil stains on a hydraulic bonded rubber bush are a sign of wear ☐ Renewing ⇒ page 166 Renew on both sides 7 - Brace ☐ Different types depending on version; for correct type refer to ⇒ Electronic parts catalogue 8 - Bolt ☐ 115 Nm +90° □ Always renew if removed 9 - Stone deflector (rear) ☐ Different types depending on version; for correct type refer to ⇒ Electronic parts catalogue 10 - Clips ☐ Different types depending on version; for correct type refer to ⇒ Electronic parts catalogue 11 - Stone deflector (front) ☐ Different types depending on version; for correct type refer to ⇒ Electronic parts catalogue 12 - Clip Protected (a) Different types depending on version; for correct type refer to (a) Electronic parts catalogue

with respect to the correctness of information in this document. Copyright by AUDI Bonded rubber bushes (front and rear)

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- A Hydraulic bonded rubber bush
- B Conventional bonded rubber bush

Equipment version with brace: Without stop plate




Training goal, from Whost unive

2.1.2 Exploded view - subframe, four-wheel drive vehicles

- 1 Clip
 - Depending on version
- 2 Stone deflector (centre)
 - Depending on version
- 3 Bolt
 - ☐ 115 Nm + 90°
 - Always renew if removed
- 4 Bolt
 - ☐ Tightening torque ⇒ Final drive; Rep. gr. 39; Final drive; Exploded view - final drive
- 5 Subframe
 - Removing and installing subframe with attachments ⇒ page 151
 - □ Fixing position of subframe ⇒ page 144.
- 6 Bonded rubber bush (front)
 - For rear final drive mounting
 - ☐ Renewing ⇒ page 189
- 7 Rear final drive
 - □ Removing and installing
 ⇒ Final drive; Rep. gr.
 39; Final drive; Removing and installing final drive
- 8 Bonded rubber bush (rear)
 - ☐ For rear final drive mounting
 - □ Renewing ⇒ page 196
- 9 Bolt
 - ☐ Tightening torque ⇒ Final drive; Rep. gr. 39; Final drive; Exploded view final drive
- 10 Bonded rubber bush (rear)
 - For subframe mounting
 - ☐ Different versions ⇒ page 141; for correct version refer to ⇒ Electronic parts catalogue
 - Oil stains on a hydraulic bonded rubber bush are a sign of wear
 - □ Renewing ⇒ page 182
 - Always renew on both sides
- 11 Bolt
 - ☐ 115 Nm + 90°
 - □ Always renew if removed
- 12 Bonded rubber bush (front)
 - ☐ For subframe mounting
 - □ Different versions ⇒ page 141; for correct version refer to ⇒ Electronic parts catalogue
 - Oil stains on a hydraulic bonded rubber bush are a sign of wear
 - Renewing ⇒ page 173 d unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

with respect to the correctness of information in this document. Copyright by AUDI AG.






- Always renew on both sides
- 13 Stone deflector (left-side)
 - Depending on version
- 14 Clip
 - Depending on version
- 15 Stone deflector (front left)
 - Depending on version

Bonded rubber bushes (front and rear)

- A Hydraulic bonded rubber bush
- B Conventional bonded rubber bush





2.2 Fixing position of subframe

⇒ "2.2.1 Fixing position of subframe, front wheel drive vehicles" ercial purposes, in part or in whole, is not page 141

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability ***2.2.2 Fixing position of subframe, four-wheel drive vehicles".****Dage 144**

with respect to the correctness of information in this document. Copyright by AUDI AG. page 144

2.2.1 Fixing position of subframe, front-wheel drive vehicles

Certain repairs require the removal of the subframe or the entire rear axle. The original position of the subframe relative to the body can be retained with the aid of the locating pins - T40242- . The locating pins - T40242- should always be screwed in just before lowering the subframe or the complete rear axle. Perform test drive after completing repair work. A wheel alignment check is required if the steering wheel has to be turned from the central position to stop the vehicle pulling to one side when driving in a straight line on a level surface ⇒ page 330.

Special tools and workshop equipment required



Torque wrench - V.A.G 1331-



W00-11166 Protected by copyright. Copying for private or commercial purp

♦ Torque WrenichedV!Al:Gs1332prised by AUDI AG. AUDI AG does not g with respect to the correctness of information in this document. $V.A.G._1332$ AUDI AG.



V.A.G 1331

◆ Engine and gearbox jack - VAS 6931-




Tensioning strap - T10038-





♦ Locating pins - T40242-




Procedure


- Remove rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view silencers
- Place engine and gearbox jack V.A.G 1383 A- under subframe.
- Protected by copyright. Copying for private or commercial purpose

 Support rear of subframe -1- with a suitable block of wood

 -2-permitted unless authorised by AUDI AG. AUDI AG does not guara
- Support front of subframe 4 with a suitable block of woodment. C
 -3-.
- Secure subframe with tensioning strap T10038- on engine and gearbox jack - V.A.G 1383 A- as shown in illustration.



- Remove bolts -arrows-.
- Equipment version with brace: Remove brace.




- Equipment version without brace: Pry stop plate -1- off hydraulic bonded rubber bush on alternate sides in area of retaining lugs.
- Screw in locating pins T40242- and tighten to 20 Nm.
- The position of the subframe is now fixed.

Removal of locating pins - T40242- is performed in reverse sequence.

Tightening torques

- ⇒ "2.1.1 Exploded view subframe, front-wheel drive vehi-
- ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view silencers



Certain repairs require the removal of the subframe or the entire rear axle. The original position of the subframe relative to the body can be retained with the aid of the locating pins - T40242- . The locating pins - T40242- should always be screwed in just before lowering the subframe or the complete rear axle. Perform test drive after completing repair work. Wheel alignment must be checked and adjusted if the steering wheel is not straight ⇒ page 330 .


Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1331-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Torque wrench - V.A.G 1332-









◆ Engine and gearbox jack - VAS 6931-




VAS 6931

◆ Tensioning strap - T10038Protected by copyright. Copying for private or commerce T10038 es, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or iability with respect to the correctness of information in this document. Copyright AG.




♦ Locating pins - T40242-




Procedure

- Place engine and gearbox jack V.A.G 1383 A- under subframe.
- Support rear final drive -1- with a suitable block of wood -2-.
- Support front of subframe with a suitable block of wood -4below cross member -3-.
- Secure subframe with tensioning strap T10038- on engine and gearbox jack - V.A.G 1383 A- .
- Tie tensioning strap T10038- around subframe roughly beneath drive shaft, feed strap past rear final drive and tighten as shown in illustration.






Remove bolts -arrows-.



- Pry stop plate -1- off hydraulic bonded rubber bush on alternate sides in area of retaining lugs.
- Screw in locating pins T40242- and tighten to 20 Nm.
- The position of the subframe is now fixed.

Removal of locating pins - T40242- is performed in reverse sequence.



2.3 Removing and installing subframe

⇒ "2.3.1 Removing and installing subframe - front-wheel drive vehicles", page 146

 \Rightarrow "2.3.2 Removing and installing subframe - four-wheel drive vehicles", page 151

2.3.1 Removing and installing subframe front-wheel drive vehicles

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1331-





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



W00-11607

♦ Torque wrench - V.A.G 1332-



VAS 6931

◆ Engine and gearbox jack - VAS 6931-



Protected by copyright. Copying for private or commercial purposes, in part of in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

◆ Tensioning strap - T10038-



♦ 2 blocks of wood

Removing

- Before starting work, measure distance from centre of wheel to lower edge of wheel housing
 - ⇒ "3.14 Lifting suspension to unladen position vehicles with coil springs", page 12 or
 - ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15.

Applies to e-tron vehicles



High voltage! Danger to life! Danger of severe or fatal injuries from electric shock.

 Observe safety precautions when working in the vicinity of high-voltage components ⇒ page 5.

Applies to all vehicles

 If the brake system has to be dismantled for subsequent repair work, note the following: Reset brake pistons ⇒ Brake system;



Rep. gr. 46; Rear brakes; Removing and installing brake pads .

- Remove rear wheels ⇒ page 329.
- Remove rear section of exhaust system ⇒ Engine; Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers.

Vehicles with coil springs:


Remove coil springs ⇒ page 230.

Vehicles with air suspension:

Remove air springs ⇒ page 238.

All vehicles (continued):

Detach shock absorber from wheel bearing housing (both sides); to do this unscrew bolt -arrow- and remove washer between wheel bearing housing and shock absorber.



- Secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-.
- Place a piece of rubber foam -1- or similar between side member and tensioning strap - T10038- and tighten tensioning strap - T10038-.



Note

Take care not to scratch side member.





CAUTION

If vehicle is not secured, there is a risk of it slipping off the lifting platform.

- Release and unplug connector -2- from rear left speed sensor G46- and rear right speed sensor - G44- .
- Remove bolt -1- on both sides and detach bracket with wiring from wheel bearing housing.


Protected by copyright. Copying for private or commercial purposes, permitted unless authorised by AUDI AG. AUDI AG does not guarante with respect to the correctness of information in this document. Cop









- If fitted, release and unplug connector -1- from rear left vehicle level sender - G76- and rear right vehicle level sender - G77-.
- Move wiring harness -2- clear -arrow-.



Remove underbody covers -1- and -2- ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing underbody trim.



- If fitted, remove centre cover -2- ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing underbody trim.
- Remove diagonal struts (if fitted) ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.




If fitted, remove stone deflectors -1 and 2-.



Protected by copyright. Copying for private or commercia

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

with respect to the correctness of information in this document. Copyright by AUDI AG.






Disconnect brake line -4- from brake hose -2- on both sides ⇒
Brake system; Rep. gr. 46; Rear brakes; Exploded view - rear
brake.



Note

Disregard item -1-.

Fix position of subframe ⇒ page 141.



- Remove bolt -arrow- on both sides.
- Carefully lower subframe with attachments, taking care not to damage disconnected pipes and wiring.


Installing

Installation is carried out in reverse sequence. Note the following:



Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- ♦ Raising suspension to unladen position (vehicles with coil springs) ⇒ page 12
- Raising suspension to reference position (vehicles with air suspension) ⇒ page 15





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Tighten bolt -arrow- on both sides.



Note

Do not install coil springs or air springs until subframe bolts have been tightened to specified torque.


- Remove locating pins T40242- ⇒ page 144.
- Install coil springs ⇒ page 230 or air springs ⇒ page 238.
- Reconnect brake hose (both sides) ⇒ Brake system; Rep. gr.
 46; Rear brakes; Exploded view rear brake.
- Secure shock absorbers page 223 ying for private or commercial purposes, in part or in whole, is not
- Install underbody covers
 General body repairs, exterior; does not guarantee or accept any liability Rep. gr. 66; Underbody frim; Exploded view underbody frim.
 with respect to the correctness of information in this document. Copyright by AUDI AG.
- If previously removed, install centre cover ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Exploded view - underbody trim.
- Install diagonal struts (if previously fitted) ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.
- Install rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers
- Bleed brake system ⇒ Brake system; Rep. gr. 47; Hydraulic system; Bleeding hydraulic system (normal bleeding procedure).
- Fit rear wheels ⇒ page 329.
- Check and adjust wheel alignment as required, see chart
 ⇒ page 344 .
- If the position of the subframe was not fixed prior to removal, the reference position must be re-adapted on vehicles with air suspension by starting the appropriate program on ⇒ Vehicle diagnostic tester in <u>Guided Functions</u>.
- If the vehicle level sender or the linkage for the vehicle level sender has been loosened during repair work, the reference position must be re-adapted on vehicles with air suspension by starting the appropriate program on ⇒ Vehicle diagnostic tester in <u>Guided Functions</u>.
- If the reference position has been re-adapted on vehicles with lane departure warning, the camera control unit - J852- must be recalibrated ⇒ page 365.

Tightening torques

⇒ "2.1.1 Exploded view - subframe, front-wheel drive vehicles", page 138

2.3.2 Removing and installing subframe - four-wheel drive vehicles

Special tools and workshop equipment required



an

◆ Torque wrench - V.A.G 1331-



◆ Torque wrench - V.A.G 1332-



◆ Engine and gearbox jack - VAS 6931-



♦ Tensioning strap - T10038-

Protected by copyright. Copying for private or commercial purposes, in part or in who permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document. Copyrights Advantage (Authorised by AUDI AG.)



Removing

Before starting work, measure distance from centre of wheel to lower edge of wheel housing
 ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or
 ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15





Note

- ♦ If the bolt securing the drive shaft to the wheel hub has to be slackened for subsequent operations, remember that this must be done with the vehicle standing on its wheels. Slacken bolt securing drive shaft to wheel hub ⇒ page 269.
- ◆ If the brake system has to be dismantled for subsequent repair work, note the following: Reset brake pistons ⇒ Brake system; Rep. gr. 46; Rear brakes; Removing and installing brake pads.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

- Remove rear wheels ⇒ page 329 DI AG. AUDI AG does not guarantee or accept any liability
- Install diagonal struts (if previously fitted)

 General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.
- Remove rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view silencers
- Disconnect propshaft from rear final drive and tie up ⇒ Final drive; Rep. gr. 39; Propshaft; Detaching and attaching propshaft at rear final drive.

Vehicles with coil springs:


Remove coil springs ⇒ page 230 .

Vehicles with air suspension:


Remove air springs ⇒ page 238.

All vehicles (continued):

- Unclip retaining tabs -1- and detach stone deflector -2-.



 Detach shock absorber from wheel bearing housing (both sides); to do this unscrew bolt -arrow- and remove washer between wheel bearing housing and shock absorber.



- Secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-.
- Place a piece of rubber foam -1- or similar between side member and tensioning strap - T10038- and tighten tensioning strap - T10038- .



Note

Take care not to scratch side member.




CAUTION

If vehicle is not secured, there is a risk of it slipping off the lifting platform.

If fitted, remove centre cover -2- ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing underbody trim.



Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does no with respect to the correctness of information in this docu








Note

To facilitate installation, mark electrical connectors -2- for oil pressure and oil temperature senders and at clutch valves.

- Unplug electrical connectors -2- from oil pressure and oil temperature senders and clutch valves.
- Then unplug connector -4- from four-wheel drive pump -V415- .
- Now unclip wiring harness -3- from final drive and subframe -items 5...7- and tie up.












- Release and unplug connector -1- from rear left speed sensor - G46- and rear right speed sensor - G44- .
- Move electrical wiring clear.
- Remove bolt -2- on both sides and move clear bracket -3- on subframe.




- Unplug electrical connectors on both sides:
- 1 For brake pad wear sender (rear)
- 2 For parking brake motor
- For DRC system (Audi RS 6)
- Move electrical wiring clear.




- Release and unplug electrical connector -1- for rear left vehicle level sender - G76- and rear right vehicle level sender - G77-.
- Move wiring harness -2- clear -arrow-.




- Remove underbody covers -1- and -2- ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing underbody trim .
- Remove diagonal struts (if fitted) ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.





If fitted, remove stone deflectors -1, 2 and 3-.




Disconnect brake line -4- from brake hose -2- on both sides ⇒ Brake system; Rep. gr. 46; Rear brakes; Exploded view - rear brake.



Note

Disregard item -1-.

Fix position of subframe ⇒ page 144.



- Remove bolt -arrow- on both sides.
- Carefully lower subframe with attachments, taking care not to damage disconnected pipes and wiring.


Installation is carried out in reverse sequence. Note the following:



Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to unladen position (vehicles with coil springs) ⇒ page 12
- Raising suspension to reference position (vehicles with air suspension) ⇒ page 15





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Tighten bolt -arrow- on both sides.



Note

Do not install coil springs or air springs until subframe bolts have been tightened to specified torque.


- Remove locating pins T40242- ⇒ page 144.
- Install coil springs ⇒ page 230 or air springs ⇒ page 238.
- Reconnect brake hose (both sides) ⇒ Brake system; Rep. gr.
 46; Rear brakes; Exploded view rear brake .
- Install shock absorber ⇒ page 223.
- Secure propshaft at rear final drive ⇒ Final drive; Rep. gr. 39; Propshaft; Detaching and attaching propshaft at rear final drive.
- Install underbody covers ⇒ General body repairs, exterior;
 Rep. gr. 66; Underbody trim; Exploded view underbody trim.
- If previously removed, install centre cover ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Exploded view - underbody trim.
- Install rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers
- Bleed brake system ⇒ Brake system; Rep. gr. 47; Hydraulic system; Bleeding hydraulic system (normal bleeding procedure).
- Fit rear wheels ⇒ page 329.
- Wheel alignment check may be required (perform road test)
 ⇒ page 141 .
- If the position of the subframe was not fixed prior to removal, the reference position must be re-adapted on vehicles with air suspension by starting the appropriate program on ⇒ Vehicle diagnostic tester in [Guided Functions].
- If the vehicle level sender or the linkage for the vehicle level sender has been loosened during repair work, the reference position must be re-adapted on vehicles with air suspension by starting the appropriate program on ⇒ Vehicle diagnostic tester in <u>Guided Functions</u>.
- If the reference position has been re-adapted on vehicles with lane departure warning, the camera control unit - J852- must be recalibrated ⇒ page 365.

Tightening torques

 = "2.1.2 Exploded view - subframe, four-wheel drive vehicles", page 140



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





2.4 Servicing subframe

- ⇒ "2.4.1 Renewing subframe bushes (front), front-wheel drive vehicles", page 158
- ⇒ "2.4.2 Renewing subframe bushes (rear), front-wheel drive vehicles", page 166
- ⇒ "2.4.3 Renewing subframe bushes (front), four-wheel drive vehicles", page 173
- \Rightarrow "2.4.4 Renewing subframe bushes (rear), four-wheel drive vehicles", page 182
- ⇒ "2.4.5 Renewing bonded rubber bush (front) for rear final drive, four-wheel drive vehicles", page 189
- ⇒ "2.4.6 Renewing bonded rubber bush (rear) for rear final drive, four-wheel drive vehicles", page 196

2.4.1 Renewing subframe bushes (front), front-wheel drive vehicles

Special tools and workshop equipment required

♦ Assembly tool - 3301-

Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does no with respect to the correctness of information in this docu



Torque wrench - V.A.G 1332-




Engine and gearbox jack - VAS 6931-







♦ Hydraulic cylinder - VAS 6178-




♦ Foot pump - VAS 6179-



♦ Assembly tool - T10205A-



♦ Assembly tool - T10263-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

Assembly tool - T40033-

T40033 /5

Assembly tool - T40185-



Assembly tool - T40253-



Protected by copyright. Copying for private or commercial purposes, in part or in permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Removing



Note

- ♦ If a bonded rubber bush on one side is defective, the bush on the other side must be renewed at the same time. For correct version refer to ⇒ Electronic parts catalogue.
- Also check the other bushes before renewing a defective bonded rubber bush.
- If cracks, oil stains or other damage is visible, these bonded rubber bushes must also be renewed.
- ◆ There are different versions of the bonded rubber bushes; for correct version refer to ⇒ Electronic parts catalogue.
- The front part of the subframe is lowered in order to renew the bonded rubber bushes. The subframe does not have to be removed.
- ♦ Do not lower the subframe more than 4 cm on one side.
- Mark the position of the bonded rubber bushes in relation to the subframe before removing them.
- Remove rear wheels ⇒ page 329.
- Remove rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view silencers

Vehicles with coil springs:

Remove coil springs ⇒ page 230 .

Vehicles with air suspension:

Bleed air springs of rear axle ⇒ page 284.

All vehicles (continued):

- Secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-.
- Place a piece of rubber foam -1- or similar between side member and tensioning strap - T10038- and tighten tensioning strap - T10038- .



Note


Take care not to scratch side member.



CAUTION


If vehicle is not secured, there is a risk of it slipping off the lifting platform.

Protected by copyright. Copying for private or comme permitted unless authorised by AUDI AG. AUDI AG do with respect to the correctness of information in this






Remove underbody covers -1- and -2- ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing underbody trim .






- Place engine and gearbox jack V.A.G 1383 A- under subframe -1-.
- Support subframe with a suitable block of wood 2-rcial purposes, permitted unless authorised by AUDI AG. AUDI AG does not guarante with respect to the correctness of information in this document. Copy



Remove bolt -arrow- on both sides.




- Using assembly tool 3301- and nut -T40253/1-, as shown in illustration, screw spindle -T40253- approx. 1.5 cm into body on side opposite bonded rubber bush to be renewed.
- Assembly tool 3301-1 -
- 2 -Nut -T40253/1-
- Spindle -T40253-



Note

Screw nut -T40253/1- onto spindle -T40253- until distance -areaches 4 cm.

Lower subframe not more than 4 cm.





Applies to hydraulic bonded rubber bush:


- Lift out plastic stop -1-, as shown in illustration.




Protected by copyright. Copying for private or commer permitted unless authorised by AUDI AG. AUDI AG doe


Applies to all versions:

 Pry stop plate -1- off bonded rubber bush on alternate sides in area of retaining lugs.






 To facilitate installation, mark position of bonded rubber bush or hydraulic bonded rubber bush in relation to subframe -arrows- using a felt-tip pen or similar.



 If necessary, unscrew small-diameter support -arrow- from hydraulic cylinder - VAS 6178- and screw in support -T10205/13- in its place.




- Apply special tools to front bonded rubber bush as shown in illustration.
- Nut T10263/5-1 -
- Thrust piece T40185/5- Recess faces towards bonded rubber bush.
- 3 -Subframe
- Support ring T40185/6- Tapered end faces upwards and projections engage in recesses in bonded rubber bush.
- 5 -Tube - T40033/3-
- 6 -Support ring - T10205/4-
- Hydraulic cylinder VAS 6178-
- 8 -Nut - T10263/5-
- Spindle T10263/4- . Pin on end of spindle faces downwards.



CAUTION

Hold hydraulic cylinder - VAS 6178- securely during pressing operation.


The bonded rubber bush will come loose suddenly. Injuries can be caused if the tools and the bonded rubber bush are allowed to drop.



Installing


Before installing bonded rubber bush, pry stop plate -1- off bonded rubber bush on alternate sides in area of retaining lugs -arrows-.

> Protected by copyright. Copying for private or comme permitted unless authorised by AUDI AG. AUDI with respect to the correctness of information in



Installation position of conventional bonded rubber bush:

Grooves -arrows- are in line with direction of travel.






Installation position of hydraulic bonded rubber bush:

· Grooves -arrows- are in line with direction of travel.

Protected by copyright. Copying for private or commercial pur permitted unless authorised by AUDI AG. AUDI AG does not go with respect to the correctness of information in this docume




- Apply special tools to front bonded rubber bush as shown in illustration.
- 1 Nut T10263/5-
- 2 Thrust piece T40185/4-
- 3 Subframe
- 4 Bonded rubber bush
- 5 Thrust piece T40185/3-
- 6 Support ring T10205/4-
- 7 Hydraulic cylinder VAS 6178-
- 8 Nut T10263/5-
- 9 Spindle T10263/4- . Pin on end of spindle faces downwards.
- Align bonded rubber bush with markings made earlier and press in at the correct position until collar is flush with subframe bushing.



Note

- ♦ If necessary, slacken cylinder and then press home again.
- Ensure that the bonded rubber bush remains straight during the first stage of installation; otherwise the outer ring may be damaged.





Ends of rubber beads on bonded rubber bush must align with markings -arrows- made earlier on subframe.




Note

After renewing the bushes, make good any paint damage on the subframe with anti-corrosion coating, primer and black topcoat.

Fit stop plate on bonded rubber bush.


The remaining installation steps are carried out in the reverse sequence. Note the following:

- Install coil springs ⇒ page 230.
- Install underbody covers ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Exploded view - underbody trim.
- Fit rear wheels ⇒ page 329.
- Install rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers
- Charge air springs of rear axle ⇒ page 284.



Special tools and workshop equipment required

Assembly tool - 3301-





Assembly tool - 3346-

Protected by copyright. Copying for private or commercial purposes, in pa permitted unless authorised by AUDI AG. AUDI AG does not gua with respect to the correctness of information in tl






◆ Torque wrench - V.A.G 1332-



◆ Engine and gearbox jack - VAS 6931-



♦ Hydraulic cylinder - VAS 6178-



Foot pump - VAS 6179




Protected by copyright. Copying for private or commercial purp permitted unless authorised by AUDI AG. AUDI AG does not g with respect to the correctness of information in this doc

Assembly tool - T10205A-


Protected by copyright. Copying for private or commercial purposes permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept with respect to the correctness of information in this document. Copyright by AU




Assembly tool - T10263-



Assembly tool - T40033-



Assembly tool - T40185-





Removing



Note

- Also check the other bushes before renewing a defective bonded rubber bush.
- If cracks, oil stains or other damage is visible, these bonded rubber bushes must also be renewed.
- The rear part of the subframe is lowered in order to renew the bonded rubber bushes. The subframe does not have to be removed.
- ♦ Do not lower the subframe more than 4 cm on one side.
- Mark the position of the bonded rubber bushes in relation to the subframe before removing them.
- Remove rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view silencers
- Secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-.
- Place a piece of rubber foam -1- or similar between side mem-Prber and tensioning strap of T10038- and tighten tensioning oses, in strap of 110038- authorised by AUDI AG. AUDI AG does not guarantee



respect to the correctness of information in this document. Copyri **Note**


Take care not to scratch side member.


A

CAUTION


If vehicle is not secured, there is a risk of it slipping off the lifting platform.

- Remove rear wheels ⇒ page 329.
- Place engine and gearbox jack V.A.G 1383 A- under subframe -1-.
- Support subframe with a suitable block of wood -2-.





- Remove bolts -arrows-.
- Equipment version with brace: Remove brace.




- Using assembly tool 3301- and nut -3346/3- , as shown in illustration, screw spindle -3346/2- approx. 1.5 cm into body on side opposite bonded rubber bush to be renewed.
- Assembly tool 3301-
- 2 -Nut -3346/3-
- Spindle -3346/2-



Note

Screw nut -3346/3- onto spindle -3346/2- until distance -a- reaches 4 cm.


Lower subframe not more than 4 cm.



Applies to hydraulic bonded rubber bush:

Prise plastic stop -1- upwards off bonded rubber bush.


Protected by copyright. Copying for private or commerc permitted unless authorised by AUDI AG. AUDI AG does with respect to the correctness of information in this do






Applies to all versions:

 Equipment version without brace: Pry stop plate -1- off bonded rubber bush on alternate sides in area of retaining lugs.




 To facilitate installation, mark position of hydraulic bonded rubber bush in relation to subframe -arrows- using a felt-tip pen or similar.



 If necessary, unscrew small-diameter support -arrow- from hydraulic cylinder - VAS 6178- and screw in support -T10205/13- in its place.



Protected by copyright. Copying for private or commercial purpose permitted unless authorised by AUDI AG. AUDI AG does not guara with respect to the correctness of information in this comment.




- Apply special tools to front bonded rubber bush as shown in illustration.
- Nut T10263/5-1 -
- Thrust piece T40185/5- Recess faces towards bonded rubber bush.
- 3 -Subframe
- Support ring T40185/6- Tapered end faces upwards and projections engage in recesses in bonded rubber bush.
- 5 -Tube - T40033/3-
- Support ring te $T_110205/4$ pyright. Copying for private or commercia 6 -
- 7 -Hydraulic_cylinder.d WAS 6178 or ised by AUDI AG. AUDI AG does n
- 8 -Nut - T10263/5espect to the correctness of information in this doc
- Spindle T10263/4- . Pin on end of spindle faces downwards.



CAUTION


Hold hydraulic cylinder - VAS 6178- securely during pressing operation.

The bonded rubber bush will come loose suddenly. Injuries can be caused if the tools and the bonded rubber bush are allowed to drop.




Installing

Equipment version without brace: Before installing bonded rubber bush, pry stop plate -1- off bonded rubber bush on alternate sides in area of retaining lugs -arrows-.




Installation position of conventional bonded rubber bush:

Grooves -arrows- are in line with direction of travel.



Installation position of hydraulic bonded rubber bush:

Grooves -arrows- are in line with direction of travel.



- Apply special tools to rear bonded rubber bush as shown in illustration.
- Nut T10263/5-1 -
- 2 -Thrust piece - T40185/4-
- 3 -Subframe
- 4 -Conventional or hydraulic bonded rubber bush
- 5 -Thrust piece - T40185/3-
- 6 -Support ring - T10205/4-
- 7 -Hydraulic cylinder - VAS 6178-
- 8 -Nut - T10263/5-
- Spindle T10263/4- . Pin on end of spindle faces downwards.
- Align bonded rubber bush with markings made earlier and press in at the correct position until collar is flush with subframe bushing. If necessary, slacken cylinder and then press home again. Ensure that the bonded rubber bush remains straight during the first stage of installation, otherwise the outer ring may be damaged.
- Ends of rubber beads on bonded rubber bush must align with markings -arrows- made earlier on subframe.




Note


After renewing the bushes, make good any paint damage on the subframe with anti-corrosion coating, primer and black topcoat.


Fit stop plate on bonded rubber bush.

The remaining installation steps are carried out in the reverse sequence. Note the following:

- Fit rear wheels ⇒ page 329.
- Install rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers







Protected by c **2.4.3** rposes, in part or in whole, is not Renewing subframe bushes (front),

Renewing subframe bushes (front), four-wheel drive vehicles this document. Copyright by AUDI AG.


Special tools and workshop equipment required



Assembly tool - 3301-

3301 W00-11427

Assembly tool - 3346-




Torque wrench - V.A.G 1332-



W00-11607

Engine and gearbox jack - VAS 6931-






Hydraulic cylinder - VAS 6178-


Protected by copyright. Copying for private or commercial purposes, in part or in whole, i permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept an with respect to the correctness of information in this document. Copyright by AUD




♦ Foot pump - VAS 6179-




♦ Assembly tool - T10205A-




◆ Assembly tool - T10263-



Assembly tool - T40033-



Assembly tool - T40185-



Removing



Note

- If a bonded rubber bush on one side is defective, the bush on the other side must be renewed at the same time. For correct version refer to ⇒ Electronic parts catalogue .
- Also check the other bushes before renewing a defective bonded rubber bush.
- If cracks, oil stains or other damage is visible, these bonded rubber bushes must also be renewed.
- There are different versions of the bonded rubber bushes; for correct version refer to ⇒ Electronic parts catalogue .
- Remove rear wheels ⇒ page 329.

Vehicles with coil springs:

Remove coil springs permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability page 230. With respect to the correctness of information in this document. Copyright by AUDI AG. Vehicles with air suspension:

Bleed air springs of rear axle ⇒ page 284.

All vehicles (continued):

Remove diagonal struts (if fitted) ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.





Note

- The front part of the subframe is lowered in order to renew the bonded rubber bushes. The subframe does not have to be removed.
- ♦ Do not lower the subframe more than 4 cm.
- Mark the position of the bonded rubber bushes in relation to the subframe before removing them.
- Secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-.
- Place a piece of rubber foam -1- or similar between side member and tensioning strap - T10038- and tighten tensioning strap - T10038- .




Note

Take care not to scratch side member.




CAUTION

If vehicle is not secured, there is a risk of it slipping off the lifting platform.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is no


Remove underbody covers -1- and -2- ⇒ General body repairs, exterior, Rep. gr. 66; Underbody trim, Removing and installing underbody trim the correctness of information in this documents.



- Place engine and gearbox jack V.A.G 1383 A- under subframe -1-.
- Insert a suitable block of wood -2- under subframe -1-.



Remove bolt -arrow- on both sides.




- Using assembly tool 3301- and nut -T40253/1- , as shown in illustration, screw spindle -T40253- approx. 1.5 cm into body on side opposite bonded rubber bush to be renewed.
- Assembly tool 3301-
- 2 -Nut -T40253/1-
- Spindle -T40253-



Note


Screw nut -T40253/1- onto spindle -T40253- until distance -areaches 4 cm.

Lower subframe not more than 4 cm.



Applies to hydraulic bonded rubber bush:

- Lift out plastic stop -1-, as shown in illustration.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Applies to all versions:

Pry stop plate -1- off bonded rubber bush on alternate sides in area of retaining lugs.


Protected by copyright. Copying for private or commercial purposes, in part or in permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept with respect to the correctness of information in this document. Copyright by AU

A42-10394

 To facilitate installation, mark position of bonded rubber bush or hydraulic bonded rubber bush in relation to subframe -arrows- using a felt-tip pen or similar.



 If necessary, unscrew small-diameter support -arrow- from hydraulic cylinder - VAS 6178- and screw in support -T10205/13- in its place.



- Apply special tools to front bonded rubber bush as shown in illustration.
- Nut T10263/5-
- Thrust piece T40185/5- Recess faces towards bonded rubber bush.
- 3 -Subframe
- Support ring T40185/6- Tapered end faces upwards and projections engage in recesses in bonded rubber bush.
- 5 -Tube - T40033/3-
- 6 -Support ring - T10205/4-
- Hydraulic cylinder VAS 6178-
- 8 -Nut - T10263/5-
- Spindle T10263/4- . Pin on end of spindle faces down-




Hold hydraulic cylinder - VAS 6178- securely during pressing operation.

The bonded rubber bush will come loose suddenly. Injuries can be caused if the tools and the bonded rubber bush are allowed to drop.

Installing


Before installing bonded rubber bush, pry stop plate -1- off bonded rubber bush on alternate sides in area of retaining lugs -arrows-.


Protected by copyright. Copying for private or commercial purposes, in part permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document. Copyr



Installation position of conventional bonded rubber bush:

Grooves -arrows- are in line with direction of travel.









Installation position of hydraulic bonded rubber bush:

· Grooves -arrows- are in line with direction of travel.



- Apply special tools to front bonded rubber bush as shown in illustration.
- Nut T10263/5-1 -
- Thrust piece T40185/4-2 -
- 3 -Subframe
- Bonded rubber bush 4 -
- 5 -Thrust piece - T40185/3-
- 6 -Support ring - T10205/4-
- 7 -Hydraulic cylinder - VAS 6178-
- Nut T10263/5-8 -
- Spindle T10263/4- . Pin on end of spindle faces downwards.
- Align bonded rubber bush with markings made earlier and press in at the correct position until collar is flush with subframe bushing.





- If necessary, slacken cylinder and then press home again.
- ♦ Ensure that the bonded rubber bush remains straight during Protect**the first stage of installation; otherwise the outer ring may be** part or in whole, is not damaged. ted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Ends of rubber beads on bonded rubber bush must align with markings -arrows- made earlier on subframe.



Note

After renewing the bushes, make good any paint damage on the subframe with anti-corrosion coating, primer and black topcoat.

Fit stop plate on bonded rubber bush.

The remaining installation steps/are carried out in the reverse se-comm quence. Note the following:

- Install diagonal struts (if previously fitted)
 pairs, exterior; Rep. gr. 66°, Underbody trim, Removing and in this document. Copyright by AUDI AG. installing diagonal struts.
- Install coil springs ⇒ page 230.
- Install underbody covers ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Exploded view - underbody trim.
- Fit rear wheels ⇒ page 329.
- Charge air springs of rear axle ⇒ page 284.


Renewing subframe bushes (rear), four-2.4.4 wheel drive vehicles


Special tools and workshop equipment required

Assembly tool - 3301-



Assembly tool - 3346-







◆ Torque wrench - V.A.G 1332-



VAS 6931

◆ Engine and gearbox jack - VAS 6931-




W00-11607 Protected by copyright. Copying for private or commercial purposes, in part or

♦ Hydraulic cylinder teVAS 6478 thorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this docum




♦ Foot pump - VAS 6179-




Assembly tool - T10205A-


Assembly tool - T10263-

Protected by copyright. Copying for private or c permitted unless authorised by AUDI AG. AUDI with respect to the correctness of information i






Assembly tool - T40033-



Assembly tool - T40185-







- Also check the other bushes before renewing a defective bon-Proteded rubber bush. Copying for private or commercial purposes, in part or in whole, is not
- permitted unless authorised by AUDI AC. ALDI AC. does not quarantee or accept any liability with *rubber bushes must also be renewed* in in this document. Copyright by AUDI AG.
 - The rear part of the subframe is lowered in order to renew the bonded rubber bushes. The subframe does not have to be removed.
 - ♦ Do not lower the subframe more than 4 cm.
 - Mark the position of the bonded rubber bushes in relation to the subframe before removing them.
 - Secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-.
 - Place a piece of rubber foam -1- or similar between side member and tensioning strap - T10038- and tighten tensioning strap - T10038- .



Note


Take care not to scratch side member.




CAUTION


If vehicle is not secured, there is a risk of it slipping off the lifting platform.

- Remove rear wheels ⇒ page 329.
- Unscrew nuts on both brackets for rear section of exhaust system as far as end of thread.
- Place engine and gearbox jack V.A.G 1383 A- under subframe -1-.
- Insert a suitable block of wood -2- under subframe -1-.





Remove bolts -arrows-.




- Using assembly tool 3301- and nut -3346/3-, as shown in illustration, screw spindle -3346/2- approx. 1.5 cm into body on side opposite bonded rubber bush to be renewed.
- Assembly tool 3301-
- 2 -Nut -3346/3-
- Spindle -3346/2-



Note

Screw nut -3346/3- onto spindle -3346/2- until distance -a- reaches 4 cm.

Lower subframe not more than 4 cm.




Applies to hydraulic bonded rubber bush:

Prise plastic stop -1- upwards off bonded rubber bush.




Protected by copyright. Copying for private or comme permitted unless authorised by AUDI AG. AUDI AG do with respect to the correctness of information in this






Applies to all versions:

- Pry stop plate -1- off bonded rubber bush on alternate sides in area of retaining lugs.



 To facilitate installation, mark position of hydraulic bonded rubber bush in relation to subframe -arrows- using a felt-tip pen or similar.




If necessary, unscrew small-diameter support -arrow- from hydraulic cylinder - VAS 6178- and screw in support -T10205/13- in its place.





with respect to the correctness of information in this document. Copyright by AUDI AG.



- Apply special tools to front bonded rubber bush as shown in illustration.
- Nut T10263/5-
- Thrust piece T40185/5- Recess faces towards bonded rubber bush.
- 3 -Subframe
- Support ring T40185/6- Tapered end faces upwards and projections engage in recesses in bonded rubber bush.
- 5 -Tube - T40033/3-
- 6 -Support ring - T10205/4-
- Hydraulic cylinder VAS 6178-
- 8 -Nut - T10263/5-
- Spindle T10263/4- . Pin on end of spindle faces down-



Hold hydraulic cylinder - VAS 6178- securely during pressing operation.

The bonded rubber bush will come loose suddenly. Injuries can be caused if the tools and the bonded rubber bush are allowed to drop.

3

5

6

9 A42-10275

A42-10333


Installing

Before installing bonded rubber bush, pry stop plate -1- off bonded rubber bush on alternate sides in area of retaining lugs -arrows-.

Protected by copyright. Copying for private or commercial purposes, in page 1975. permitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyrig

Installation position of conventional bonded rubber bush:


Grooves -arrows- are in line with direction of travel.





Installation position of hydraulic bonded rubber bush:

· Grooves -arrows- are in line with direction of travel.



- Apply special tools to rear bonded rubber bush as shown in illustration.
- 1 Nut T10263/5-
- 2 Thrust piece T40185/4-
- 3 Subframe
- 4 Conventional or hydraulic bonded rubber bush
- 5 Thrust piece T40185/3-
- 6 Support ring T10205/4-
- 7 Hydraulic cylinder VAS 6178-
- 8 Nut T10263/5-
- 9 Spindle T10263/4- . Pin on end of spindle faces downwards.
- Align bonded rubber bush with markings made earlier and press in at the correct position until collar is flush with subframe bushing. If necessary, slacken cylinder and then press home again. Ensure that the bonded rubber bush remains straight during the first stage of installation, otherwise the outer ring may be damaged.
- Ends of rubber beads on bonded rubber bush must align with markings -arrows- made earlier on subframe.




After renewing the bushes, make good any paint damage on the subframe with anti-corrosion coating, primer and black topcoat.


rotected by copyright. Copying for private or commercial purposes, in pari — **Fit stop plate on bonded rubber bush.** ermitted unless authorised by AUDI AG. AUDI AG does not guarantee or a


The remaining installation steps are carried out in the reverse sequence. Note the following: of information in this document. Copyr

- Install bracket for exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers.
- Fit rear wheels ⇒ page 329 .




Special tools and workshop equipment required







Assembly tool - 3301-



Assembly tool - 3346-



3346 W00-11689

Protected by copyright. Copying for private or commercial purposes, in part or

Torque wrenchtt VIAIG-1332thorised by AUDI AG. AUDI AG does not guarantee or accept any trability with respect to the correctness of information in this docum



Engine and gearbox jack - VAS 6931-






♦ Hydraulic cylinder - VAS 6178-



♦ Foot pump - VAS 6179-



T10205A

Assembly tool - T10205A-



Protected by copyright. Copying for private or commercial purposes, in parl or permitted unless authorised by AUDI AG. AUDI AG does not guarantee or a cept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

♦ Assembly tool - T10254-



W00-10142





Assembly tool - T40033-



Protected by copyright. Copying for private or commercial purposes permitted unless authorised by AUDI AG. AUDI AG does not guarant

Assembly tool 140186-ctness of information in this document. Cop





Removing



Note

- The front part of the subframe is lowered in order to renew the bonded rubber bush. The subframe does not have to be removed.
- Do not lower the subframe more than 4 cm.

Vehicles with coil springs:


Remove coil springs ⇒ page 230 .

Vehicles with air suspension:

Bleed air springs of rear axle ⇒ page 284.

All vehicles (continued):

- Remove underbody covers -1- and -2- ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing underbody trim .
- Remove diagonal struts (if fitted) ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.






If fitted, remove stone deflector -2-.




Note

Protected by copyright. Copying for private or comme permitted unless authorised by AUDI AG. AUDI AG do with respect to the correctness of information in this


Disregard items -1 and 3-.



- Place engine and gearbox jack V.A.G 1383 A- under subframe -1-.
- Insert a suitable block of wood -2- under subframe -1-.



- Remove bolt -arrow- on both sides.




- Using assembly tool 3301- and nut -T40253/1-, as shown in illustration, screw spindle -T40253- approx. 1.5 cm into body on side opposite bonded rubber bush to be renewed.
- 1 Assembly tool 3301-
- 2 Nut -T40253/1-
- 3 Spindle -T40253-



Note

Screw nut -T40253/1- onto spindle -T40253- until distance -a-reaches 4 cm.



- Remove bolt -2-.
- Lower subframe not more than 4 cm.
- Push final drive upwards by means of propshaft-1-. At the same time, insert thrust piece - T40186/1- and spindle - T10254/5- with nut - T10254/4- (2nd mechanic required).
- 4 Spindle T10254/5- . Pin on end of spindle faces downwards.
- 5 Nut T10254/4-
- 6 Thrust piece T40186/1-
- When removing and installing bonded rubber bush, make sure that spindle -4- does not contact threaded hole -3- in final drive.

If spindle - T10254/5- cannot be pushed through access hole in inner core of bonded rubber bush, access hole will have to be drilled out.



Note

- Drill bits of different diameters should be used to drill out in several stages.
- During the drilling procedure, ensure that the threaded hole -3- in the final drive is not damaged by the drill bit (if necessary cover the hole with a suitable object).




CAUTION

Safety goggles must be worn when drilling.


Apply drill -1- to bonded rubber bush -2-, as shown in illustration, and drill out access hole in several stages.


Step 1: drill bit, 11 mm Ø Step 2: drill bit, 11.5 mm Ø Step 3: drill bit, 12 mm Ø



If necessary, unscrew support - T10205/13- from hydraulic cylinder - VAS 6178- and screw in support with small internal diameter -arrow- in its place.

> Protected by copyright. Copying for private or commercial purposes permitted unless authorised by AUDI AG. AUDI AG does i with respect to the correctness of information in this doc







- Apply special tools to front bonded rubber bush as shown in illustration.
- 1 -Nut - T10254/4-
- Thrust piece T40186/1-
- 3 -Subframe
- 4 -Tube - T40033/3-
- Support ring T10205/4-5 -
- 6 -Hydraulic cylinder - VAS 6178-
- 7 -Nut - T10254/4-
- Spindle T10254/5- . Pin on end of spindle faces downwards.



Hold hydraulic cylinder - VAS 6178- securely during pressing operation.

Protected by copyright. Copying for private or commercial purpose

The bonded rubber bush will come loose suddenly. Injuries can

provided uploate authorized by AUDI AC charge cat be caused if the tools and the bonded rubber bush are allowed uarantee or accept any liability

to $drop_{th}$ respect to the correctness of information in this document. Copyright by AUDI AG.



Installing

Installation is carried out in reverse sequence. Note the following:


Before installing bonded rubber bush, check that spindle -T10254/5- can be pushed through access hole in inner core of bonded rubber bush. If spindle - T10254/5- cannot be pushed through access hole in inner core of bonded rubber bush, access hole will have to be drilled out.


CAUTION

Safety goggles must be worn when drilling.

- Lightly clamp new bonded rubber bush -2- horizontally in jaws of vice, as shown in illustration (use protective jaw covers -1and take care not to damage outer shell of bonded rubber bush).
- Apply drill -3- to bonded rubber bush -2-, as shown in illustration, and drill out access hole in several stages.

Step 1: drill bit, 11 mm Ø Step 2: drill bit, 11.5 mm Ø Step 3: drill bit, 12 mm Ø







Apply a continuous marking -arrow- at 90° to the grooves.
 a = 90°




Note

- This marking is required for aligning the bush with the subframe.
- The slots are concealed by the tools when the bush is being installed.
- Before installing, apply assembly lubricant to bonded rubber bush where it contacts subframe; for lubricant refer to ⇒ Electronic parts catalogue.
- Position bonded rubber bush in subframe so that previously made marking -arrow- points exactly in direction of travel.
- Apply special tools to front bonded rubber bush as shown in illustration.
- 1 Nut T10254/4-
- 2 Thrust piece T40033/7-
- 3 Subframe
- 4 Bonded rubber bush
- 5 Thrust plate T40186/2-
- 6 Support ring T10205/4-
- 7 Hydraulic cylinder VAS 6178-
- 8 Nut T10254/4-
- 9 Spindle T10254/5- . Pin on end of spindle faces downwards.
- Pull bush into subframe as far as stop.
 Protected by copyright. Copying for private or commercial purposes,

permitted unless authorised by AUDI AG. AUDI AG does not guarant

with respect to the correctness of information in this document. Copyright by AUDI AG.





The remaining installation steps are carried out in the reverse sequence.

- Install underbody covers ⇒ General body repairs, exterior;
 Rep. gr. 66; Underbody trim; Exploded view underbody trim.
- Install diagonal struts (if previously fitted) ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.
- Install coil springs ⇒ page 230 .
- Charge air springs of rear axle ⇒ page 284.

2.4.6 Renewing bonded rubber bush (rear) for rear final drive, four-wheel drive vehicles

Special tools and workshop equipment required








Assembly tool - 3301-



♦ Assembly tool - 3346-



♦ Torque wrench - V.A.G 1332-



◆ Engine and gearbox jack - VAS 6931-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Assembly tool - T40185- with spindle -T40185/9-



Removing



Note


The rear bonded rubber bush for the rear final drive can only be pulled out and installed from the rear.


- Remove rear final drive ⇒ Final drive; Rep. gr. 39; Final drive; Removing and installing final drive .
- Set up tools on subframe as shown in illustration.
- 1 Nut - 3346/3-
- 2 Pressure bearing - 3301-
- 3 -Tube - T40185/2- . Side "A" must face towards subframe.
- 4 -Subframe
- ected by copyright. Copying for private or commercial purposes, in **Tube T40185/1- . Side "A" must face towards subframe.** nitted unless authorised by AUDI AG. AUDI AG does not guarantee 5 -
- ect to the correctness of information in this document. Copyr Spindle -T40185/9-
- Pull bush out of subframe by turning nut 3346/3- and counterholding spindle -T40185/9- .

Installing

Installation is carried out in reverse sequence. Note the following: Installation position of rear bonded rubber bush:

Arrows on rear side of bonded rubber bush should face vertically upwards or downwards.







- Set up tools and bonded rubber bush on subframe as shown in illustration.
- 1 Nut 3346/3-
- 2 Pressure bearing 3301-
- 3 Tube T40185/1- . Side "B" must face towards subframe.
- 4 Bonded rubber bush
- 5 Subframe
- 6 Tube T40185/2- . Side "B" must face towards subframe.
- 7 Nut
- 8 Spindle T40185/9-
- Pull bush into subframe as far as stop by turning nut 3346/3and counterholding spindle - T40185/9- .




Note

If the paint on the subframe has been damaged when renewing the bushes, make good the damage with anti-corrosion coating, primer and black topcoat.

- Install rear final drive ⇒ Final drive; Rep. gr. 39; Final drive; Removing and installing final drive.
- Wheel alignment check may be required (perform road test)
 ⇒ page 141.

Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

3 Anti-roll bar

- ⇒ "3.1 Exploded view anti-roll bar", page 200
- ⇒ "3.2 Removing and installing anti-roll bar", page 200

3.1 Exploded view - anti-roll bar

1 - Bolt ☐ 40 Nm +90° ☐ Always renew if removed Vehicle must be in unladen position when tightening ⇒ page 12 6 2 - Coupling rod Removing and installing ⇒ page 200 3 - Bolt ☐ 40 Nm +90° □ Always renew if removed Vehicle must be in unladen position when tightening ⇒ page 12 4 - Nut □ Always renew if removed 5 - Lower transverse link 6 - Subframe 7 - Anti-roll bar □ Removing and installing ⇒ page 200 □ Rubber bush and clamp must not be separated from anti-roll bartess aut 8 - Bolt with respect to the cor

A42-10490

3.2 Removing and installing anti-roll bar

Special tools and workshop equipment required


☐ 25 Nm +90°

moved Tighten evenly

□ Always renew if re-



◆ Torque wrench - V.A.G 1331-



◆ Engine and gearbox jack - VAS 6931-





Before starting work, measure distance from centre of wheel to lower edge of wheel housing

⇒ "3.14 Lifting suspension to unladen position revehicles with urposes, in part or in whole, is not coil springs", page 12 or

"3.45 Lifting suspension to reference position (vehicles with guarantee or accept any liability air suspension) page 15 rectness of information in this document. Copyright by AUDI AG.




Take care not to damage paintwork on anti-roll bar during removal and installation.

Remove bolt -1-.



Note

- The bolt connection between the coupling rod and lower transverse link is under tension.
- ♦ Press the lower transverse link slightly downwards when removing bolt -1- for the reason above.
- Remove nut -3- and detach bolt -2- and coupling rod -4-.
- Remove rear section of exhaust system ⇒ Engine; Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers.





Remove bolts -1- on both sides and take out anti-roll bar -2towards left.



Note

The anti-roll bar -2- is removed and installed complete with the rubber bushes and clamps. Do not detach clamps and rubber bushes.


Installing

Installation is carried out in reverse sequence. Note the following:



Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Raising suspension to unladen position (vehicles with coil springs) to page 12 authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
- Raising suspension to reference position (vehicles with air ment. Copyright by AUDI AG. suspension) ⇒ page 15
- Install anti-roll bar from left to right.
- Screw in bolts -1- loosely on both sides and then tighten evenly.




1

A42-10373

- Install coupling rod -4- and bolt -2-.
- Tighten nut -3- on both sides.
- Tighten bolt -1- on both sides.
- Install rear section of exhaust system ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers

Tightening torques

⇒ "3.1 Exploded view - anti-roll bar", page 200







4 Suspension links, track rod

- ⇒ "4.1 Exploded view transverse links", page 203
- ⇒ "4.2 Removing and installing upper transverse link", page 205
- ⇒ "4.3 Removing and installing lower transverse link", page 207
- ⇒ "4.4 Removing and installing track rod", page 212


4.1 Exploded view - transverse links

- 1 Track rod
 - Removing and installing ⇒ page 212
 - Different versions and installation position ⇒ page 205 and ⇒ page 205 ; for correct version refer to ⇒ Electronic parts catalogue
- 2 Eccentric bolt
 - □ Always renew if removed
 - Tighten in unladen position ⇒ page 12 or reference position ⇒ page 15
- 3 Eccentric washer
- 4 Nut
 - □ 95 Nm
 - ☐ Always renew if removed
- 5 Bolt
 - ☐ 70 Nm +180°
 - □ Always renew if removed
 - ☐ Tighten in unladen position ⇒ page 12 or reference position ⇒ page 15
- 6 Nut
 - Always renew if removed
- 7 Bracket
 - ☐ For rear left vehicle level sender G76- / rear right vehicle level sender G77-
- 8 Bolt
 - ☐ 70 Nm +180°
 - Always renew if removed
 - ☐ Tighten in unladen position ⇒ page 12 or reference position ⇒ page 15
- 9 Subframe

nt. Copying for private or commercial purposes, in part or in whole, is not

10 - Nut unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability Always renew if removed

with respect to the correctness of information in this document. Copyright by AUDI AG.



□ Always renew if removed



Note

Protection of the protection o perr**nut is slackened** or ised by AUDI AG. AUDI AG does not guarantee or accept any liability

- 22 Bolt respect to the correctness of information in this document. Copyright by AUDI AG.
 - □ 90 Nm +90°
 - Always renew if removed
 - ☐ Tighten in unladen position ⇒ page 12 or reference position ⇒ page 15



Track rod for vehicles with coil springs


- A Track rod (pressed steel)
- B Track rod (aluminium casting)
- 1 Installation position: the marking must be on the outside and the tip of the triangle must point upwards




Protected by copyright. Copying for private or commercial purpose: permitted unless authorised by AUDI AG. AUDI AG does not guarar with respect to the correctness of information in this document. C

Track rod for vehicles with air suspension

- Installation position: the marking must be on the outside and the vertical line must point upwards
- Track rod (aluminium casting) 2 -






4.2 Removing and installing upper transverse link



Note

As inner bolt -1- is inaccessible, upper transverse link can only be removed after taking out subframe.



Special tools and workshop equipment required

Torque wrench - V.A.G 1332-





- Before starting work, measure distance from centre of wheel Prtodowerbedge of wheel housing private or commercial purposes, in ⇒ "3.14 Lifting suspension to unladen position - vehicles with pecoll springs"; page 12 of by AUDI AG. AUDI AG does not guarar wi 3.15 Lifting suspension to reference position (vehicles with pyriair suspension)", page 15.
- Remove subframe: front-wheel drive vehicles ⇒ page 146, four-wheel drive vehicles ⇒ page 151
- Mark installation position of adjuster screw -2- relative to wheel bearing housing.
- Unscrew bolted connections -1- and -2-.
- Take out upper transverse link -3-.

Installing





Note

Renew bolts and self-locking nuts.

Installation position of upper transverse link on subframe


Bolt upper transverse link -3- loosely to subframe at mounting -1-.







- Lay straight steel bar -1- flat on highest points of subframe -arrows-.
- Position upper transverse link -2- so dimension a = 11 mm is attained between steel bar -1- and burr of upper transverse link -2-.



- Secure upper transverse link -3- to subframe in this position.
- Attach wheel bearing housing to transverse link and tighten new nut to 20 Nm. Note position of eccentric washer -2-.
- Install subframe: front-wheel drive vehicles ⇒ page 146, fourwheel drive vehicles ⇒ page 151





- Raise suspension to unladen position ⇒ page 12 or reference position ⇒ page 15 and tighten nut -4-.
- Fit rear wheel ⇒ page 329.
- Check and adjust wheel alignment as required, see chart ⇒ page 344 .


Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.


Tightening torques

♦ ± "4.1 Exploded view - transverse links", page 203


4.3 Removing and installing lower transverse link

Special tools and workshop equipment required





Torque wrench - V.A.G 1331-



Torque wrench - V.A.G 1332-



Engine and gearbox jack - VAS 6931-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Tensioning strap - T10038-






♦ Support - T10149-



♦ Bit XZN 16 - T10198-



Removing

- Before starting work, measure distance from centre of wheel to lower edge of wheel housing

 ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or

 ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15.
- Remove rear wheel ⇒ page 329 ing for private or commercial purposes, in part or in whole, is not Vehicles with coil springs: with respect to the correctness of information in this document. Copyright by AUDI AG. \Rightarrow page 230.

Vehicles with air suspension:

Bleed air springs of rear axle ⇒ page 284.



All vehicles (continued):

- Secure vehicle to arms of lifting platform -arrow B- by attaching tensioning strap - T10038- to striker -arrow A-.
- Place a piece of rubber foam -1- or similar between side member and tensioning strap - T10038- and tighten tensioning strap - T10038-.



Note


Take care not to scratch side member.




CAUTION

If vehicle is not secured, there is a risk of it slipping off the lifting platform.

- Remove diagonal strut ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.
- When removing the lower transverse link on the left side, the rear section of the exhaust system must be removed for the previous step ⇒ Rep. gr. 26; Exhaust pipes/silencers; Exploded view - silencers .
- Unscrew bolt -2- for vehicle level sender -1-.






Remove bolt -1-.



Note

Disregard -items 2, 3, 4-.





Protected by copyright. Copying for private or commercial purper permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Unscrew nut -3-.
- Remove bolt -1- and take off spacer -2-.



Protected by copyright. Copying for private or commercial pu permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this docum

- Remove bolt -1-.
- Unscrew nut -3- and remove bolt -2-.
- Detach lower transverse link; to do this push wheel bearing housing away to the side and upwards (second mechanic required).



Note


When pushing away the wheel bearing housing, take care not to damage the electrical wiring and brake hose. The joints of the drive shafts on a four-wheel drive vehicle must not be allowed to bend to such an extent that they contact the end stop.


Installation is carried out in reverse sequence. Note the following:




Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to unladen position (vehicles with coil springs) ⇒ page 12
- Raising suspension to reference position (vehicles with air suspension) ⇒ page 15
- Fit lower transverse link and screw in bolt -1- loosely initially.
- Fit bolt -2- and screw on nut -3- loosely.









Fit bolt -1- with spacer -2- and screw on nut -3- loosely.



The bolted connection must not be tightened by the nut.

- Tighten bolt -1-.
- Tighten remaining bolts.
- Install coil spring ⇒ page 230.
- Fit rear wheel ⇒ page 329.
- Charge air springs of rear axle ⇒ page 284.
- Check and adjust wheel alignment as required, see chart ⇒ page 344 .

Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.

- On vehicles with automatic headlight range control, perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights .
- If the vehicle level sender has been removed and refitted or the linkage detached on vehicles with electronic damping control, the reference position must be re-adapted; start appropriate program on ⇒ Vehicle diagnostic tester in Guided Functions.
- If the reference position has been re-adapted on vehicles with lane departure warning, the lane departure warning control unit - J759- must be recalibrated ⇒ page 365.

Tightening torques


⇒ "4.1 Exploded view - transverse links", page 203

Removing and installing track rod

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1332-


Protected by copyright. Copying for private or commercial purposes, in part or in wh permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any training with respect to the correctness of information in this document. Copyright by AUDI AG.







Socket - T40183-



Removing



Note

The procedure is described for a vehicle with air suspension; the procedure for other vehicles is basically the same are or commercial purposes, in part or in whole, is not

- permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability Before starting work, measure distance from centre of wheel to lower edge of wheel housing ectness of information in this document. Copyright by AUDI AG. ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or ⇒ "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15.
- Remove rear wheel ⇒ page 329.
- Detach front section of wheel housing liner and push to one side ⇒ General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Removing and installing wheel housing liner (rear) .

- am
- First remove bolt -4-.
- Mark installation position of eccentric bolt -1- relative to subframe -2-.
- Unscrew nut and take out eccentric washer and eccentric bolt
 -1-.
- Detach track rod -5-.



Note

Disregard -item 3-.

Installing

Installation is carried out in reverse sequence. Note the following:



Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to unladen position (vehicles with coil springs) ⇒ page 12
- Raising suspension to reference position (vehicles with air suspension) ⇒ page 15 tected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability


Fit track rod -5-.
 with respect to the correctness of information in


- Observe marking -3- ⇒ page 205 or ⇒ page 205.
- First insert eccentric bolt -1- fully and align it with marking made on removal.
- Insert bolt -4- and tighten.
- Fit eccentric washer and new nut for eccentric bolt -1- handtight. Do not tighten nut to specified torque until wheel alignment has been checked and adjusted.
- Fit rear wheel ⇒ page 329.
- Check and adjust wheel alignment as required, see chart
 ⇒ page 344 .

Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.

Tightening torques

♦ = "4.1 Exploded view - transverse links", page 203







5 Suspension strut/shock absorber, spring


- ⇒ "5.1 Exploded view suspension strut/shock absorber, spring", page 215
- ⇒ "5.2 Modifying spring compressing system", page 220
- ⇒ "5.3 Removing and installing shock absorber", page 223
- ⇒ "5.4 Servicing shock absorber", page 227
- ⇒ "5.5 Removing and installing spring", page 230

5.1 Exploded view - suspension strut/shock absorber, spring

- ⇒ "5.1.1 Exploded view suspension strut/shock absorber, coil spring", page 215
- ⇒ "5.1.2 Exploded view suspension strut/shock absorber, air spring", page 217
- ⇒ "5.1.3 Exploded view suspension strut/shock absorber, spring, shock absorber", page 218

5.1.1 Exploded view - suspension strut/shock absorber, coil spring

- 1 Wheel bearing housing
- 2 Stone deflector
- 3 Bottom spring plate
 - Note installation position ⇒ page 216.
- 4 Coil spring
 - Note installation position \Rightarrow page 216.
- 5 Top spring plate
 - □ Some versions have eccentric top spring plate ⇒ page 216 ; for allocation refer to ⇒ Electronic parts catalogue
- 6 Spacer
 - Not fitted on all vehicles: for allocation refer to ⇒ Electronic parts cata-











Installation position of bottom spring plate

Centring pin -3- on bottom spring plate must engage in hole -2- in stone deflector and in hole -1- in wheel bearing housing. permitted unless authorised by AUDI AG. AUDI AG does not gua with respect to the correctness of information in this document




Installation position of coil spring

- Coloured marking -arrow- at the bottom.
- Rotate end of spring so it lies against stop on bottom spring plate.



Installation position of eccentric top spring plate


- -Arrow- points in direction of travel
- Centring pin -1- must engage in longitudinal member -2-.





5.1.2 Exploded view - suspension strut/shock absorber, air spring


- 1 Spring washer
- 2 Wheel bearing housing
- 3 Stone deflector
- 4 Air spring
 - Removing and installing ⇒ page 238
 - Note installation position ⇒ page 217.
- 5 Air pipe
 - □ Tightening torque for connection piece ⇒ Item 3 (page 294)




Installation position of air spring

- Locating pin -3- on air spring must engage in hole -5- in stone deflector and in hole -4- in wheel bearing housing.
- Retaining catches -2- must engage under wheel bearing hous-
- Spring washer -1- must be pushed on parallel as far as base of air spring.
- Locating pin -6- on air spring must engage correctly in body.

Protected by copyright. Copying for private or commercial pur permitted unless authorised by AUDI AG. AUDI AG does not g with respect to the correctness of information in this docume



5.1.3 Exploded view - suspension strut/shock absorber, spring, shock absorber Shock absorber (conventional)




Shock absorber with electronic damping control



- 1 Stone deflector
- - ☐ 150 Nm 4180 ed unless au
 - ☐ Always renew iffere-to the prrectness of information moved
 - Vehicle must be in unladen position when tightening ⇒ page 12
- 3 Shock absorber
 - Removing and installing ⇒ page 223
 - Servicing ⇒ page 227
- 4 Wiring
- 5 Protective cap
- 6 Seal
 - □ For electrical connector
- 7 Connector housing
 - Do not kink or twist wire when attaching connec-
- 8 Protective cap
- 9 Nut
 - □ 50 Nm
 - ☐ Always renew if removed
- 10 Shock absorber mounting (top)
- 11 Bolt
 - □ 50 Nm +90°
 - □ Always renew if removed
- 12 Bump stop
- 13 Protective sleeve
- 14 Washer
 - □ For corrosion protection
 - Always use

Shock absorber with DRC system







- 1 Bump stop
- 2 Protective sleeve
- 3 Shock absorber mounting
- 4 Nut
 - □ 35 Nm
 - ☐ Always renew if removed
- 5 Protective cap
- 6 Bolt
 - ☐ 50 Nm +90°
 - □ Always renew if removed
- 7 Protective sleeve
- 8 Drain/charge valve with hose
 - Install so that it is free of perntension nless authorised b
- 9 Nutrespect to the correctness
 - □ 9 Nm
- 10 Clip
- 11 Union screw
 - □ 14 Nm
- 12 Shock absorber
 - □ For DRC system
 - Removing and installing ⇒ page 223
 - □ Servicing ⇒ page 227
- 13 Stone deflector
- 14 Bolt
 - ☐ 150 Nm +180°
 - Always renew if removed
 - □ Vehicle must be in unladen position when tightening ⇒ page 12

5.2 Modifying spring compressing system

Special tools and workshop equipment required


Spring compressing system - VAS 6274-







♦ Supplementary set - VAS 6274/10-







Note

The equipment only needs to be modified once. It is not necessary to convert the equipment back to its original condition.

- Remove nuts -arrows- (6x) from spring compressor.
- Detach plate and pull rods out of spring compressor.



Remove bolt -arrow- and detach existing spring retainer -1with non-countersunk hole -2-.







Protected by copyright. Copying for private or commercial purpose permitted unless authorised by AUDI AG. AUDI AG does n with respect to the correctness of information in this doc

Insert new retainer with threaded holes from supplementary set into plate so/that markings "R" and "L" are aligned hori-poses, i zontally on plate.


permitted unless authorised by AUDI AG. AUDI AG does not guarantee




- Tighten new retainer with new bolt -arrow- from supplementary set. Do not turn retainer when doing so.
- Fit new spring retainer -1- with countersunk bore -3- from supplementary set.
- Fit new spring retainer -1- so that stop -2- is opposite marking
- Tighten new spring retainer -1- with new bolt from supplementary set.
- Detach spring retainer at hydraulic cylinder end.



- Remove plate -2- and replace with new plate from supplementary set.
- Tighten new plate -2- with new bolts -1- from supplementary
- Screw spring retainer very lightly onto spring compressor as far as stop and then slacken off slightly again.



- Insert new rods with long taper -1- into plate on spring compressor.
- While doing so, insert upper rod through plate -2-.
- Fit spring retainer plate onto rods.






Fit sleeves -2- and -3- from supplementary set and lightly tighten nuts -1-.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, permitted unless authorised by AUDI AG. AUDI AG does not guarantee or acc with respect to the correctness of information in this document. Copyright by AUDI AC

— Place spring compressor down on a flat surface and tighten

nuts -arrows-.






5.3 Removing and installing shock absorber



Special tools and workshop equipment required



- Torque wrench V.A.G 1331-
- Torque wrench V.A.G 1332-
- Engine and gearbox jack VAS 6931- or -V.A.G 1383 A-
- Support T10149-

Removing

- Before starting work, measure distance from centre of wheel to lower edge of wheel housing ⇒ "3.14 Lifting suspension to unladen position - vehicles with coil springs", page 12 or \Rightarrow "3.15 Lifting suspension to reference position (vehicles with air suspension)", page 15 .
- Remove rear wheel ⇒ page 329.
- Remove wheel housing liner > General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Removing and installing wheel housing liner (rear).
- Turn the wheel hub until one of the bores for the wheel bolts **is at the top** by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




- Attach support T10149- with wheel bolt, as shown in illustra-
- Fit support T10149- in engine and gearbox jack -V.A.G 1383 A- and raise wheel bearing housing slightly.



Note

Dimension -a- can be disregarded.




- Discharge DRC system ⇒ page 318.
- If vehicle is equipped with driver-adjustable DRC and variable damping, detach electrical connector -1- (on additional element with integral DC motor) from bracket, unplug connector and move clear.
- Remove union screw -2- and move hose clear.
- Protect open connections from dirt.

Vehicles with electronic damping control:

If fitted, release and unplug electrical connector -1-.


All vehicles (continued):


Remove bolts -arrows-.







Protected by copyright. Copying for private or commercial purposes permitted unless authorised by AUDI AG. AUDI AG does not guarant with respect to the correctness of information in this document. Co









- Remove bolt -arrow- and detach washer between wheel bearing housing and shock absorber.
- Compress shock absorber as far as possible and guide out mercial from above permitted unless authorised by AUDI AG. AUDI AG does no

Installing

with respect to the correctness of information in this docu

Installation is carried out in reverse sequence. Note the following:




Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to unladen position (vehicles with coil springs) ⇒ page 12
- Raising suspension to reference position (vehicles with air suspension) ⇒ page 15
- Install wheel housing liner ⇒ General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Exploded view - wheel housing liner (rear) .
- Fit rear wheel ⇒ page 329.

Tightening torques

⇒ "5.1 Exploded view - suspension strut/shock absorber, spring", page 215





5.4 Servicing shock absorber

⇒ "5.4.1 Servicing shock absorber, conventional version / vehicles with DRC system", page 227


⇒ "5.4.2 Servicing shock absorber, version with variable damping", page 228


5.4.1 Servicing shock absorber, conventional version / vehicles with DRC system

Special tools and workshop equipment required

Torque wrench -V.A.G 1332-







Unscrewing and tightening nut


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

- 1 available ratchet unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
- Tool insert Copyright by AUDI AG. 2 -T10001/9-
- 3 -Ratchet -T10001/11-
- 4 -Tool insert -T10001/1-



Installation position of shock absorber mounting (top)

Bolt on top shock absorber mounting at a 90° angle to bottom shock absorber mounting.




5.4.2 Servicing shock absorber, version with

variable damping Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Special tools and workshop equipment required by AUDI AG. AUDI AG does not guarantee or accept any liability


◆ Torque wrench - V.A.G_{wi1332}spect to the correctness of information



Shock absorber tool set - T10001-




Counterhold tool -T40255-





Procedure


- Release and detach protective cap ⇒ Item 5 (page 219).
- Move clear electrical wire -arrow- and detach protective cap -1- from shock absorber mounting (top).
- Release contacts and detach connector housing from electrical wire ⇒ Electrical system; Rep. gr. 97; Releasing and dismantling connector housings.



Unscrewing and tightening nut


- 1 Tool insert T10001/3-
- 2 Ring spanner insert V.A.G 1332/7-
- 3 -Tool insert - T40255-
- 4 -Wiring
- Ring spanner (commercially available type) 5 -
- Torque wrench V.A.G 1332-
- 7 -Shock absorber mounting

Protected by copyright. Copying for private or commercial purposes, in part or permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accep with respect to the correctness of information in this document. Copyright by




Installation position of shock absorber mounting (top)

Bolt on top shock absorber mounting at a 90° angle to bottom shock absorber mounting.



Installation position of electrical wiring on shock absorber with electronic damping control

- The marking -arrow- on the electrical wiring must engage in the protective cap -1-, as shown in the illustration.
- Do not kink or twist wire when attaching connector.






5.5 Removing and installing spring


- ⇒ "5.5.1 Removing and installing coil spring", page 230
- ⇒ "5.5.2 Removing and installing air spring", page 238
- 5.5.1 Removing and installing coil spring rivate or commercial purposes, in part or in whole, is not Special tools and workshop equipment requireded by AUDI AG. AUDI AG does not guarantee or accept any liability
- ◆ Foot pump VAS 61.79 respect to the correctness of information in



♦ Spring compressing system - VAS 6274-



♦ Supplementary set - VAS 6274/10-





Before removing and installing the coil spring, the spring compressing system - VAS 6274- must be modified with supplementary set - VAS 6274/10- .

Modifying spring compressing system - VAS 6274- with supplementary set - VAS 6274/10- \Rightarrow page 220.





Note

In the following operations the remaining tools from the supplementary set - VAS 6274/10- are required.

- 1 -Thrust plate with swivel mounting - VAS 6274/10-1-
- 2 -Thrust plate with securing plate - VAS 6274/10-2-
- 3 -Bolts for locating bracket
- 4 -Spindle - VAS 6274/10-4-
- 5 -Sleeve

Removing

- Remove rear wheel ⇒ page 329.
- If necessary, push back locking lever in opposite direction of -arrow-.




Note


For greater clarity, the stone deflector is removed in the following illustrations.


- Working from the outside, insert new thrust plate with securing plate - VAS 6274/10-2- with locating bracket from supplementary set.
- 1 Thrust plate with securing plate VAS 6274/10-2-
- Insert plunger -2- with T-bar -3- into thrust plate. To do so, push back locking lever on thrust plate outwards (to open) as necessary.


Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does

- Press locking lever-in-direction-of-varrow-sto-secure plunger, this do
- Rotate thrust plate with securing plate all the way up.









te or

- Insert new thrust plate with swivel mounting VAS 6274/10-1with locating bracket from supplementary set from the inside.
- Thrust plate with swivel mounting VAS 6274/10-1-

Locating bracket -2- must be bolted on at front, as seen in direction of travel.


Rotate thrust plate with swivel mounting all the way down.



Before removing and installing any of the springs, always lubricate the front of the spindle lightly with the grease supplied formation


Lubricate the spindle only with the grease supplied. If other greases are used the spindle will be damaged.

- Lubricate the front of the new spindle VAS 6274/10-4- lightly with the grease supplied.
- Grease tube from spring compressing system VAS 6274or from supplementary set - VAS 6274/10-
- Spindle VAS 6274/10-4-



Copyright by A42/10/189\

- Hand-tighten new spindle VAS 6274/10-4- using socket -VAS 6274/6- .
- Spindle VAS 6274/10-4-
- Socket VAS 6274/6-



A42-10191



- Bolt the locating brackets -1- and -2- of the two thrust plates together.
- Screw in new bolts -3- hand-tight to do so.



CAUTION

The coil spring must be compressed or released only when the two locating brackets -1- and -2- are joined together by the two bolts -3-.

- First pre-tension thrust plates slightly using new spindle VAS 6274/10-4-.
- Check that coil spring is correctly seated in thrust plates.



Note

When compressing the coil spring, the locating brackets must be pointing forwards (in direction of travel).

- Compress coil spring with socket VAS 6274/6- (use counterhold tool VAS 6274/7t.). opying for private or commercial purpos
- Counterhold toors VAS 6274/74 AUDI AG. AUDI AG does not guarantee of
- Socket VAS 6274/6-





(I) NOTICE


Do not use impact wrenches to compress the coil spring.

Use a standard commercially available ratchet to compress the spring.

Compress coil spring -1- until stone deflector -3- and bottom spring plate -2- can be taken out. Compress coil spring -1further if necessary.










When compressing the coil spring, make sure the bolts -arrows A- do not make contact with the stop on the thrust plate


Similarly, the locating bracket on the thrust plate -2- must not make contact with the stop -arrow B- on the thrust plate -1-.

Remove coil spring downwards and forwards.


Slackening coil spring in spring compressing system - VAS 6274-

Slacken off spindle -1- slightly if necessary. Spindle -1- must not protrude beyond end of coil spring -2-.






- Insert left coil spring in spring retainer -1- so that stop -2- is opposite marking "L". This only applies to coil spring on left side of vehicle.
- For coil spring on right side of vehicle, stop -2- must be opposite marking "R".



- Position underside of end of left coil spring in spring compressing system - VAS 6274- at marking "L" -arrow-.
- Position underside of end of right coil spring in spring compressing system - VAS 6274- at marking "R".

Protected by copyright. Copying for private or commercial purposes, in p permitted unless authorised by AUDI AG. AUDI AG does not guarantee o with respect to the correctness of information in this document. Copyrig






Apply marking -1- using a felt-tip pen or similar.




Note

The marking -1- is required when compressing the spring during installation.


- Locating element -2- faces upwards.
- Lightly hand-tighten bolts -1-.
- 2 Socket VAS 6274/6-
- Slacken coil spring using socket VAS 6274/6- . At the same time slacken coil spring via spring compressing system - VAS 6274- and foot pump - VAS 6179- .








- When coil spring has been slackened, unscrew spindle -2-.
- Remove bolts -1- from locating bracket and take out thrust Prplate with swivel mounting yVAS 6274/10-1 mmercial purposes, in permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document. Copyr



- Push back locking lever -1-.
- Remove plunger -2- with T-bar -3-.
- Release coil spring completely.




Installing


Installation is carried out in reverse sequence. Note the following:

- Insert bottom of coil spring into spring compressing system -VAS 6274- ; installation position ⇒ page 216 .
- Position end of left coil spring in spring compressing system -VAS 6274- at marking "L" -arrow-.
- Position end of right coil spring in spring compressing system - VAS 6274- at marking "R".




Secure plunger +24 with locking lever +13 for private or commercial p permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this docur





- Fit thrust plate with swivel mounting VAS 6274/10-1-.
- Screw in bolts for locating bracket -1- loosely.
- Insert spindle -3-.
- Insert sleeve -2- as far as it will go.






A42-10195

- Lightly hand-tighten bolts -1- for locating bracket. Locating element must be pointing upwards when compressing coil spring.
- Compress coil spring using socket VAS 6274/6-, At the same time apply pressure via spring compressing system - VAS 6274- and foot pump - VAS 6179- .
- 2 Socket VAS 6274/6-

NOTICE


When compressing the coil spring, make sure the bolts on the locating bracket do not make contact with the stop on the thrust plate with swivel mounting - VAS 6274/10-1-.

Similarly, the locating bracket on the thrust plate with securing plate - VAS 6274/10-2- must not make contact with the stop on the thrust plate with swivel mounting - VAS 6274/10-1-.




When using spindle -3- to compress coil spring, make sure that Protected sleeve -4- does not slip out of thrust plate with swivel mounting permitted uMeSs6274610self by AUDI AG. AUDI AG does not guarantee or accep

with respeRelease spring compressing system - VAS 6274- and take out by A coil spring together with spring compressor.




VAS 6274/10-1

- If necessary, use spindle -1- to compress coil spring -2- further.
- Spindle -1- must not protrude too far beyond coil spring -2otherwise it will not be possible to position top spring plate properly on coil spring.




- Position coil spring with bottom spring plate -3- and stone deflector -1- on wheel bearing housing -2-; installation position ⇒ page 216 .
- Check that top spring plate is installed; installation position of eccentric spring plate ⇒ page 216. Install if necessary.



- Screw coil spring -1- into bottom spring plate -2- as far as stop.
- Then release coil spring.
- Fit rear wheel ⇒ page 329
- Check and adjust wheel alignment as required, see chart ⇒ page 344 Protected by copyright. Copying for private or comme

Wheel alignment must always be checked and adjusted if neclassical AG do essary using VW/Audi-approved equipment.


with respect to the correctness of information in this



5.5.2 Removing and installing air spring

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1331-



Torque wrench - V.A.G 1332-





Removing



Note

- Make sure that no dirt enters the compressed air system.
- Clean the affected area before detaching connection pieces for air pipes or components of the compressed air system.
- Cover or seal off open air pipes and connections of the compressed air system immediately with a plug.
- Bleed air springs of rear axle ⇒ page 284.
- Remove wheel ⇒ page 329.
- Remove diagonal strut (if fitted) ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.
- Unscrew connection piece -arrow- on rear air spring.
- Detach stone deflector ⇒ Item 3 (page 217).
- Take out air spring from below.

Installing

Installation is carried out in reverse sequence. Note the following:

- Install diagonal struts (if previously fitted) ⇒ General body repairs, exterior; Rep. gr. 66; Underbody trim; Removing and installing diagonal struts.
- Charge air springs of rear axle ⇒ page 284.




Note

- The vehicle must not be lowered from the lifting platform until the system has been recharged ⇒ page 18.
- ◆ Before charging air spring, check that locating pin on air spring is engaged correctly in body. At the same the retainers on the air spring must be correctly engaged under the wheel bearing housing ⇒ page 217.

Tightening torques

Protected by copyright. Copying for private of commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



6 Wheel bearing, trailing arm


- ⇒ "6.1 Exploded view wheel bearing", page 240
- ⇒ "6.2 Removing and installing wheel bearing housing", page 243
- ⇒ "6.3 Removing and installing wheel bearing unit", page 250
- ⇒ "6.4 Servicing wheel bearing unit", page 254
- ⇒ "6.5 Renewing bonded rubber bushes for wheel bearing housing", page 258

6.1 Exploded view - wheel bearing

- ⇒ "6.1.1 Exploded view wheel bearing, front-wheel drive vehicles not including e-tron vehicles", page 240
- ⇒ "6.1.2 Exploded view wheel bearing housing, four-wheel drive vehicles and e-tron vehicles", page 242

6.1.1 Exploded view - wheel bearing, front-wheel drive vehicles not including etron vehicles

- 1 Bolt
 - □ 10 Nm
- 2 Splash plate
 - For brake disc
- 3 Bonded rubber bush
 - □ Renewing ⇒ page 262
- 4 Wheel bearing housing
 - Removing and installing ⇒ page 243
- 5 Rear speed sensor
 - ☐ Left-side: Rear left speed sensor - G46-
 - □ Right-side: Rear right speed sensor - G44-
- 6 Bolt
 - □ Tightening torque ⇒ Brake system; Rep. gr. 45; Sensors; Exploded view - rear wheel speed sensor
- 7 Additional seal
- 8 Wheel hub
 - Removing and installing wheel bearing unit page 253
 - Servicing wheel bearing unit ⇒ page 254
- - □ v200rNmet180the correctn
 - Always renew if removed





- ☐ Observe instructions for loosening and tightening ⇒ page 269
- 11 Grease cap
- 12 Bolt
 - ☐ Tightening torque ⇒ Brake system; Rep. gr. 46; Rear brakes; Exploded view rear brake

Avoiding dirtying or damaging the seal when laying it down or placing it in storage

- The wheel bearing -1- must always be pointing upwards.
- Always put down the wheel bearing unit with the wheel hub -2- facing downwards.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

6.1.2 Exploded view - wheel bearing housing, four-wheel drive vehicles and etron vehicles


- 1 Bolt
 - □ 10 Nm
- 2 Splash plate
 - For brake disc
- 3 Bonded rubber bush
 - □ Renewing ⇒ page 262
- 4 Wheel bearing housing
 - Removing and installing ⇒ page 246
- 5 Bolt
 - 80 Nm +90°
 - ☐ Always renew if removed
- 6 Drive shaft
 - Different versions available ⇒ Electronic parts catalogue
 - e-tron: constant velocity joint instead of drive shaft
- 7 Rear speed sensor
 - ☐ Left-side: Rear left speed sensor - G46-
 - Right-side: Rear right speed sensor - G44mitte
- 8 Bolt
 - □ Tightening torque ⇒ Brake system; Rep. gr. 45; Sensors; Exploded view - rear wheel speed sensor
- 9 Wheel bearing
 - □ Removing and installing wheel bearing unit ⇒ page 253
 - ☐ Servicing wheel bearing unit ⇒ page 254
- 10 Wheel hub
 - □ Removing and installing wheel bearing unit ⇒ page 253
 - Servicing wheel bearing unit ⇒ page 254
- 11 Brake disc
- 12 Bolt
 - ☐ Tightening torque ⇒ Item 14 (page 268)
- - ☐ Tightening torque ⇒ Brake system; Rep. gr. 46; Rear brakes; Exploded view rear brake






Avoid dirtying or damaging the seal when picking up, laying down or storing the wheel bearing

- Wheel bearing -1- must always face upwards.
- Always put down the wheel bearing unit with the wheel hub -2- facing downwards.



- Do not touch the inside of the wheel bearing when you pick it
- · Always take hold of the outside of the wheel bearing.

The same procedure applies to the wheel bearing without wheel





Protected by copyright. Copying for private or commercial purposes, in part or in whol

- Removing and installing wheel bearing to es not guarantee or accept any liability 6.2 $\textbf{housing}_{\texttt{ect to the correctness of information in this document. Copyright by AUDI AG.}$
- ⇒ "6.2.1 Removing and installing wheel bearing housing, frontwheel drive vehicles not including e-tron vehicles", page 243
- \Rightarrow "6.2.2 Removing and installing wheel bearing housing, four-wheel drive and e-tron vehicles", page 246
- 6.2.1 Removing and installing wheel bearing housing, front-wheel drive vehicles not including e-tron vehicles

Special tools and workshop equipment required

Torque wrench - V.A.G 1332-



Torque wrench - V.A.G 1410-



Lubricating paste

Removing

- Remove rear wheel ⇒ page 329.
- Release and unplug connector -2- at rear speed sensor.
- Remove bolt -1- and detach bracket with wiring from wheel bearing housing.


NOTICE


After detaching brake caliper, secure caliper to body so that weight of caliper does not stretch or damage brake hose or brake pipe.

Do not press brake pedal after brake caliper has been removed.

- Unbolt brake caliper and brake disc, guide caliper past suspension and secure to body ⇒ Brake system; Rep. gr. 46; Rear brakes; Removing and installing brake disc .
- Remove bolt -1- and take off rear speed sensor -2-.

- Vehicles with coil springs: Protected by copyright. Copying for private or commercial purpo Remove coil spring ⇒ page 230 by AUDI AG. AUDI AG does not guar Vehicles with air suspension:
- Remove air spring ⇒ page 238.










All vehicles (continued):


- Mark installation position of adjuster screw -1- relative to wheel bearing housing -2-.
- Unscrew nut -4- and take off shim -3-.
- Remove adjuster screw.







Remove bolt -arrow- and detach washer between wheel bearing housing and shock absorber.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Unscrew nut -3-.
- Pull out bolt -1- and detach spacer -2-.
- Take off wheel bearing housing.

Installing

Installation is carried out in reverse sequence. Note the following:



Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to unladen position (vehicles with coil springs) ⇒ page 12
- Raising suspension to reference position (vehicles with air suspension) ⇒ page 15
- Fit wheel bearing housing.
- Fit bolt -1- with spacer -2- and screw on nut -3- loosely.



The bolted connection must not be tightened by the nut -3-.


- Tighten bolt -1-.
- Install coil spring ⇒ page 230 or air spring ⇒ page 238.
- Install brake caliper and brake disc ⇒ Brake system; Rep. gr. 46; Rear brakes; Removing and installing brake disc.
- Install track rod ⇒ page 212.
- Install upper transverse link ⇒ page 205.
- Install lower transverse link ⇒ page 207.
- Install speed sensor (rear) ⇒ Brake system; Rep. gr. 45; Sensors; Removing and installing rear speed sensors -G44-/ -G46- .
- Fit rear wheel ⇒ page 329.
- Check and adjust wheel alignment as required, see chart ⇒ page 344 .


Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.

Tightening torques

- ⇒ "6.1.1 Exploded view towheel bearing, front wheel drive ver commercial purposes, in part or in whole, is not hicles not including e-tron vehicles" page 240 y AUDI AG. AUDI AG does not guarantee or accept any liability
- Removing and installing wheel bearing 6.2.2 housing, four-wheel drive and e-tron vehicles

Special tools and workshop equipment required







◆ Torque wrench - V.A.G -




♦ Torque wrench - V.A.G 1410-





- Vehicles with four-wheel drive: Loosen bolt securing drive shaft to wheel hub page 269 pying for private or commercial purposes, in part or in whole, is not
- e-tron: Release constant velocity joint/wheet hub connection of guarantee or accept any liability ⇒ page 269 pect to the correctness of information in this document. Copyright by AUDI AG.
- Remove rear wheel ⇒ page 329.
- Release and unplug connector -1- from rear left speed sensor - G46- or rear right speed sensor - G44- .
- If fitted, remove bolt -2- and detach bracket -3- with wiring.




Remove bolt -2- and take off rear speed sensor -1-.



After detaching brake caliper, secure caliper to body so that weight of caliper does not stretch or damage brake hose or brake pipe.

Do not press brake pedal after brake caliper has been removed.

Unbolt brake caliper and brake disc from wheel bearing housing, guide past suspension and secure to body ⇒ Brake system; Rep. gr. 46; Rear brakes; Removing and installing brake disc .



Remove bolts -1- and detach splash plate -2-.


Vehicles with coil springs:

Remove coil spring ⇒ pag

Vehicles with air suspension:


Remove air spring ⇒ page 238.

Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG d with respect to the correctness of information in thi



All vehicles (continued):

- Mark installation position of adjuster screw -1- relative to wheel bearing housing -2-.
- Unscrew nut -4- and take off shim -3-.
- Remove adjuster screw.




Remove bolt -4-.




Note

Disregard -items 1, 2, 3, 5-.



Remove bolt -arrow- and detach washer between wheel bearing housing and shock absorber.





- Unscrew nut -3-.
- Pull out bolt -1- and detach spacer -2-.
- Pivot wheel bearing housing to the side and pull drive shaft out of wheel bearing housing.
- Take out wheel bearing housing.

Installing

Installation is carried out in reverse sequence. Note the following:



Note

- Bonded rubber bushes can only be turned to a limited extent. The suspension mountings must therefore only be tightened when the suspension is in the unladen position or reference position.
- Raising suspension to unladen position (vehicles with coil springs) ⇒ page 12
- Raising suspension to reference position (vehicles with air suspension) ⇒ page 15
- Fit wheel bearing housing.
- Fit bolt -1- with spacer -2- and screw on nut -3- loosely.

NOTICE


The bolted connection must not be tightened by the nut -3-.


- Tighten bolt -1-.
- Install coil spring ⇒ page 230 or air spring ⇒ page 238.
- Install brake disc and brake caliper ⇒ Brake system; Rep. gr. 46; Rear brakes; Removing and installing brake disc.
- Install track rod ⇒ page 212.
- Install upper transverse link ⇒ page 205.
- Install lower transverse link ⇒ page 207.
- Install speed sensor (rear) is Brake system, Rep. gr. 45; mercial purposes, in part or in whole, is not Sensors; Removing and installing rear speed sensors: G44-ols not guarantee or accept any liability -G46- .
- with respect to the correctness of information in this document. Copyright by AUDI AG. ⇒ page 329.
- Tighten bolt securing drive shaft to wheel hub ⇒ page 269.
- Check and adjust wheel alignment as required, see chart ⇒ page 344 .

Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.

Tightening torques

⇒ "6.1.2 Exploded view - wheel bearing housing, four-wheel drive vehicles and e-tron vehicles", page 242







6.3 Removing and installing wheel bearing

⇒ "6.3.1 Removing and installing wheel bearing unit, front-wheel drive vehicles not including e-tron vehicles", page 250

 \Rightarrow "6.3.2 Removing and installing wheel bearing unit, four-wheel drive and e-tron vehicles", page 253


6.3.1 Removing and installing wheel bearing unit, front-wheel drive vehicles not including e-tron vehicles

Special tools and workshop equipment required

♦ Hub grease cap puller - VW 637/2-



Fitting sleeve - 3241/4-



Torque wrench - V.A.G 1332-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee o with respect to the correctness of information in this document. Copyright by AUDI AG.






◆ Torque wrench - V.A.G 1410-




♦ Lubricating paste

Removing

- Remove rear wheel ⇒ page 329.
- Loosen grease cap by tapping lightly on hub grease cap puller VW 637/2- -1-.



- Lever off grease cap with hub grease cap puller VW 637/2-
- Loosen bolt for wheel bearing unit.




Unbolt brake caliper and brake disc from wheel bearing housing, guide past suspension and secure to body ⇒ Brake system; Rep. gr. 46; Rear brakes; Removing and installing brake disc .



After detaching brake caliper, secure caliper to body so that weight of caliper does not stretch or damage brake hose or brake pipe.

Do not press brake pedal after brake caliper has been removed.

Remove bolts -1- from splash plate -2-.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Reach behind additional seal -arrow-. Use additional seal -arrow- to pull off wheel bearing unit (not shown in illustration).




Do NOT detach the wheel bearing unit by pulling on the outer bearing race (wheel hub).



Note

If the wheel bearing unit can be pulled off the wheel bearing housing by hand, the wheel bearing unit is OK and does not have to be renewed.



NOTICE

Avoid dirtying or damaging the seal when laying down or storing the wheel bearing.


- rotected by copyright. Copying for private or commercial purposes, in The wheel bearing -1- must always be pointing upwards.
- Always put down the wheel bearing unit with the wheel hub wil2-Ifacing downwards ctness of information in this document. Copyr

Installing

Installation is carried out in reverse sequence. Note the following:



- Clean additional seal.
- Fit additional seal and lubricate stub axle -arrow- lightly with lubricating paste.
- Install brake caliper and brake disc ⇒ Brake system; Rep. gr. 46; Rear brakes; Removing and installing brake disc.





M42-10031

Drive in new grease cap using fitting sleeve - 3241/4- -1-.



Note

- Always renew used grease caps.
- A used grease cap will allow moisture to enter the bearing. For this reason it is important to use the tool shown in the illustration.
- Tighten bolt for wheel bearing unit.
- Fit rear wheel ⇒ page 329.

Tightening torques

♦ ⇒ "6.1.1 Exploded view - wheel bearing, front-wheel drive vehicles not including e-tron vehicles", page 240

6.3.2 Removing and installing wheel bearing unit, four-wheel drive and e-tron vehicles

Removing

- Remove wheel bearing housing ⇒ page 246.
- Clamp wheel bearing housing in a vice with protective aluminium jaws.
- Remove bolts -1- and detach wheel bearing unit -2-.




Avoid dirtying or damaging the seal when laying down or storing the wheel bearing.

- A42-10215
- The wheel bearing -1- must always be pointing upwards.
- Always put down the wheel bearing unit with the wheel hub -2- facing downwards.



Protected by copyright. Copying for private or commercial purp permitted unless authorised by AUDI AG. AUDI AG does not gu with respect to the correctness of information in this documer



A42-10264

- Do not touch the inside of the wheel bearing when you pick it up.
- Always take hold of the outside of the wheel bearing.

The same procedure applies to the wheel bearing without wheel hub.

Installing

Installation is carried out in reverse sequence.

Tightening torques

- ⇒ "6.1.2 Exploded view wheel bearing housing, four-wheel drive vehicles and e-tron vehicles", page 242
- Check and adjust wheel alignment as required, see chart ⇒ page 344 .



6.4 Servicing wheel bearing unit

Special tools and workshop equipment required

♦ Thrust plate - VW 401-

Protected by copyright. Copying for private or commercia permitted unless authorised by AUDI AG. AUDI AG does not guarant



Thrust plate - VW 402-





Press tool - VW 412-



♦ Assembly tool - T10230-



Protected by copyright. Copying for private or commercial purpose permitted unless authorised by AUDI AG. AUDI AG does not guarante with respect to the correctness of information in this document. C




- ♦ Workshop press VAS 6654- , not illustrated
- Puller set for inner bearing races VAS 701 003- (not illustrated)

Procedure

Wheel bearing unit removed ⇒ page 250


Pressing wheel hub out of wheel bearing

- Set up special tools as shown in illustration.
- Press tool VW 412-1 -
- Sleeve -T10230/3-2 -
- 3 Thrust piece -T10230/8-
- 4 -Wheel bearing unit
- 5 -Thrust plate - VW 402-
- Thrust plate VW 401-
- Press wheel hub out of wheel bearing.




Pressing inner bearing race off wheel hub

- Prepare puller from puller set for inner bearing races a VAS rooses 701 003- as follows: thorised by AUDI AG. AUDI AG does not guarant
- Screw clamping sleeve VAS 701 003/1- onto clamp tensioner VAS 701 003/7 le correctness of information in this document
- Screw threaded spindle VAS 701 003/2- into clamping sleeve and fit thrust piece - VAS 701 003/3-.




Inner bearing race version 1:

- Remove ball cage from inner bearing race -2-.
- Apply puller -1- to ball raceways -arrow- of inner race, as shown.



Inner bearing race version 2:


- Apply puller -1- to groove -arrow- of inner race -2-.





All versions (continued):

- Clamp puller in place on inner race -2-; to do so, use spanner - VAS 701 003/7- to turn clamp tensioner - VAS 701 003/5- in direction of -arrow- and counterhold clamping sleeve - VAS 701 003/1- with tensioner handle - VAS 701 003/4- .
- Use threaded spindle VAS 701 003/2- to detach inner bearing race from wheel hub -1-.




Pressing wheel hub into wheel bearing




Avoid dirtying or damaging the seal when laying down or storing the wheel bearing.

- The wheel bearing -1- must always be pointing upwards.
- Always put down the wheel bearing unit with the wheel hub -2- facing downwards.



Do not touch the inside of the wheel bearing when you pick it

Protect Always take hold of the outside of the wheel bearing oses, in part of permitted unless authorised by AUDI AG. AUDI AG does not guarantee or acce with respect to the correctness of information in this document. Copyright by




- Set up special tools as shown in illustration.
- Press tool VW 412-
- 2 -Thrust plate - VW 402-
- 3 -Wheel hub
- Wheel bearing
- Thrust plate VW 401-
- The machined surface of the wheel bearing outer race faces downwards.



Take precautions not to damage or dirty the wheel bearing.

Make sure no dirt gets between thrust plate - VW 401- and wheel bearing when pressing in the hub or when the parts are placed on a workbench, etc. copyright. Copying for private or co

permitted unless authorised by AUDI AG. AUDI A



- Press wheel hub into wheel bearing the correctness of information in this document. Copyright by AUDI AG
- Install wheel bearing unit ⇒ page 113.

6.5 Renewing bonded rubber bushes for wheel bearing housing

⇒ "6.5.1 Renewing bonded rubber bushes for wheel bearing housing, front-wheel drive vehicles not including e-tron vehicles", page 258

⇒ "6.5.2 Renewing bonded rubber bushes for wheel bearing housing, four-wheel drive and e-tron vehicles", page 262

6.5.1 Renewing bonded rubber bushes for wheel bearing housing, front-wheel drive vehicles not including e-tron vehicles

Special tools and workshop equipment required

♦ Thrust plate - VW 401-






♦ Thrust plate - VW 402-



♦ Press tool - VW 408 A-




♦ Press tool - VW 411-



Workshop press - V.A.G 1290 A-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabil with respect to the correctness of information in this document. Copyright by AUDI AG.




Assembly tool - T40184-

Protected by copyright. Copying for private or commercial purposes, in p permitted unless authorised by AUDI AG. AUDI AG does not guarantee o with respect to the correctness of information in this document. Copyrig



Removing

- Remove wheel bearing housing ⇒ page 243.
- To press out front bonded rubber bush, thrust plate -T40184/2--3- must be positioned on front bonded rubber bush so that studs -2- engage in grooves -4-.



Apply tools to front bonded rubber bush and wheel bearing housing as shown in illustration.




Note


When positioning the wheel bearing housing on the sleeve -T40184/1-, make sure the rubber sleeve of the rear bonded rubber bush is not damaged / moved.

- Press tool VW 411-1 -
- 2 -Thrust plate - T40184/2- .
- 3 -Wheel bearing housing
- Sleeve T40184/1- Side with groove must face wheel bearing housing. If bonded rubber bush has a "positioning lug", this fits into groove on sleeve - T40184/1-.
- Press out front bonded rubber bush.



- Insert front bonded rubber bush into sleeve T40184/3-. Thin collar -arrow- must face upwards.
- To press in front bonded rubber bush, position thrust plate -T40184/2- -3- on front bonded rubber bush so that studs -2engage in grooves -4-.





2

3




4 5 6

A42-10291


- Press in front bonded rubber bush until it makes contact with thrust plates -1- and -6-.
- 1 -Thrust plate - VW 401- . Position as shown in illustration.
- Sleeve T40184/3-
- 3 -Bonded rubber bush (front)
- Press tool VW 408 A-
- Thrust plate T40184/2-5 -
- Thrust plate VW 402- . Position as shown in illustration. 6 -
- Then pull thrust plates -1- and -6- apart slightly.
- Press front bonded rubber bush approx. 2 mm out of sleeve -T40184/3-.

a = 2 mm

- Detach press tool VW 408 A- and insert press tool VW 411-.
- Position wheel bearing housing on workshop press V.A.G 1290 A- .



- Position front bonded rubber bush (not visible in illustration). thrust plate -3- and sleeve -1- on wheel bearing housing.
- Sleeve T40184/3-1 -
- 2 -Press tool - VW 411-
- 3 -Thrust plate - T40184/2- . Note installation position on front bonded rubber bush.




Apply tools to front bonded rubber bush and wheel bearing housing -3- as shown in illustration.



Note

When positioning the wheel bearing housing on the sleeve -T40184/1-, make sure the rubber sleeve of the rear bonded rubber bush is not damaged / moved.

- Slowly press in front bonded rubber bush (not visible in illustration) until sleeve -2- can be lifted off.
- Press tool VW 411-1 -
- Sleeve T40184/3-2 -
- 3 -Wheel bearing housing
- ight. Copying for private or co Sleeve - T40184/1- Side with groove must face wheel bearing housing. If bonded rubber bush has a positioning lug'oes no this fits into groove on sleeve - T40184/1 formation in this docu
- Thrust plate VW 402-






Slowly press in front bonded rubber bush -2- until it is flush with edge of wheel bearing housing -arrow-.



Note

Disregard -item 3-.

Install wheel bearing housing ⇒ page 243.



6.5.2 Renewing bonded rubber bushes for wheel bearing housing, four-wheel drive and e-tron vehicles

Special tools and workshop equipment required

♦ Thrust plate - VW 401-



Thrust plate - VW 402-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




♦ Press tool - VW 408 A-




♦ Press tool - VW 411-



♦ Workshop press - V.A.G 1290 A-



♦ Assembly tool - T40184-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

Removing

- Remove wheel bearing housing ⇒ page 243.
- To press out front bonded rubber bush, thrust plate -T40184/2--3- must be positioned on front bonded rubber bush so that studs -2- engage in grooves -4-.



Apply tools to front bonded rubber bush and wheel bearing housing as shown in illustration.



Note


Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AC


When positioning the wheel bearing housing on the sleeve mation in T40184/1-, make sure the rubber sleeve of the rear bonded rubber bush is not damaged / moved.

- Press tool VW 411-1 -
- Thrust plate T40184/2-
- 3 -Wheel bearing housing
- Sleeve T40184/1- Side with groove must face wheel bearing housing. If bonded rubber bush has a "positioning lug", this fits into groove on sleeve - T40184/1-.
- Press out front bonded rubber bush.




- Insert front bonded rubber bush into sleeve T40184/3-. Thin collar -arrow- must face upwards.
- To press in front bonded rubber bush, position thrust plate -T40184/2- -3- on front bonded rubber bush so that studs -2engage in grooves -4-.





- Press in front bonded rubber bush until it makes contact with thrust plates -1- and -6-.
- 1 -Thrust plate - VW 401- . Position as shown in illustration.
- Sleeve T40184/3-2 -
- Bonded rubber bush (front) 3 -
- Press tool VW 408 A-
- 5 -Thrust plate - T40184/2-
- Thrust plate VW 402- . Position as shown in illustration.
- Then pull thrust plates -1- and -6- apart slightly.







Press front bonded rubber bush approx. 2 mm out of sleeve -T40184/3- .

a = 2 mm

- Detach press tool VW 408 A- and insert press tool VW 411-.
- Position wheel bearing housing on workshop press V.A.G 1290 A- .



- Position front bonded rubber bush (not visible in illustration), thrust plate -3- and sleeve -1- on wheel bearing housing.
- Sleeve T40184/3-
- 2 -Press tool - VW 411-
- 3 -Thrust plate - T40184/2- . Note installation position on front bonded rubber bush.




Apply tools to front bonded rubber bush and wheel bearing housing -3- as shown in illustration.



Note

When positioning the wheel bearing housing on the sleeve -T40184/1-, make sure the rubber sleeve of the rear bonded rubber bush is not damaged / moved.

- Slowly press in front bonded rubber bush (not visible in illustration) until sleeve -2- can be lifted off.
- Press toole Vw 4pyright. Copying for private or commercial purpose
- Sleeve 1740184/3s authorised by AUDI AG. AUDI AG does not gua 2 -
- Wheel bearing housing 3 -
- Sleeve T40184/1- Side with groove must face wheel bearing housing. If bonded rubber bush has a "positioning lug", this fits into groove on sleeve - T40184/1-.
- Thrust plate VW 402-






Slowly press in front bonded rubber bush -2- with thrust plate - T40184/2- -item 1- until it is flush with edge of wheel bearing housing -arrow-.



Note

Disregard -item 3-.

Install wheel bearing housing ⇒ page 243.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



7 Drive shaft


- ⇒ "7.1 Exploded view drive shaft", page 267
- ⇒ "7.2 Removing and installing drive shaft", page 269
- ⇒ "7.3 Loosening and tightening bolt securing drive shaft", page 269
- ⇒ "7.4 Renewing constant velocity joint", page 271
- ⇒ "7.5 Checking outer constant velocity joint", page 279
- ⇒ "7.6 Checking inner constant velocity joint", page 279

7.1 Exploded view - drive shaft private or commercial purposes, in part or in whole, is not

- horised by AUDI AG. AUDI AG does not guarantee or accept any liability 1 - Cover correctness of information in this document. Copyright by AUDI AG. □ Drive cover off carefully with drift; renew if damaged Sealing surfaces between cover and inner CV joint must be free from grease on assembly
- 2 Circlip
 - Use normal commercial circlip pliers when removing and installing

□ Before attaching to constant velocity joint, apply sealant to sealing surface ⇒ page 277

- □ Always renew if removed
- 3 Inner constant velocity joint
 - Renew only as complete unit
 - ☐ Checking ⇒ page 279
 - Grease quantity and type ⇒ page 268
 - Adhesive surfaces must be free of oil and grease
 - Grease splines on drive shaft lightly with grease used in joint when fitting joint onto drive shaft
- 4 Boot with cap for inner constant velocity joint
 - Without vent hole
 - ☐ Drive cap off carefully with drift; renew if damaged
 - □ Check inner constant velocity joint if boot is damaged ⇒ page 279
 - Sealing surfaces between cap and inner constant velocity joint must be free from grease on assembly
- 5 Lock plate
- 6 Bolt
 - □ M10
 - □ 70 Nm



	Always renew if removed
7 - Ho	ose clip
	Always renew if removed
	Tightening ⇒ page 279
8 - Dr	rive shaft
	Removing and installing <u>⇒ page 269</u>
9 - Ho	ose clip
	Always renew if removed
	Tightening ⇒ page 273
10 - E	Boot for outer constant velocity joint
	Without vent hole
	Check for splits and chafing, renew if necessary
	Check outer constant velocity joint if boot is damaged ⇒ page 279
	Sealing surfaces between boot and outer metal cap must be free from grease on assembly
	Sealing surfaces between boot and drive shaft must be free from grease on assembly
11 - F	Hose clip
	Always renew if removed
	Tightening ⇒ page 273
12 - 0	Circlip
	Renew
	For correct version refer to ⇒ Electronic parts catalogue
	Fit into annular groove on shaft before installing (no longer visible once joint is installed)
	Before fitting the constant velocity joint, align the circlip centrally with the opening facing upwards
13 - C	Outer constant velocity joint
	Renew only as complete unit opying for private or commercial purposes, in part or in whole, is not
	Cnecking ⇒ page 2/9 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
	Driving off ⇒ page 271 Installing: drive onto shaft with plastic hammer until compressed circlip seats
	Circlip must fit in chamfer on joint when installing; guide with pliers if necessary
	Grease quantity and type <u>⇒ page 268</u> Sealing surfaces between boot and outer CV joint must be free from grease on assembly
	Grease splines on drive shaft lightly with grease used in joint when fitting joint onto drive shaft
14 - E	
	200 Nm +180°
	Always renew if removed
_	Observe instructions for loosening and tightening ⇒ page 269
_	- page 200
0	
	se quantity and type
-	ease joint when renewing boot.
For re	equired grease filling of joints, refer to ⇒ Electronic parts ogue .
$oldsymbol{i}$	Note
Note	that different types of grease are required for outer and inner

joints.



	Grease quantity	of which in:		
Outer joint	Total quantity	Joint	Boot	
[mm]	[g]	[g]	[g]	
94	80	40	40	
Inner joint				
107	120	Put in grease through ball bearing races		

7.2 Removing and installing drive shaft

Removing


- Slacken bolt securing drive shaft to wheel hub ⇒ page 269.
- Remove rear wheel ⇒ page 329.

Vehicles with coil springs:

Remove coil spring ⇒ page 230 .

Vehicles with air suspension:

- Bleed air springs of rear axle ⇒ page 284.
- Secure tensioning strap -1- by fitting bolt -2- hand-tight.
- Remove rear final drive ⇒ Final drive; Rep. gr. 39; Final drive; Removing and installing final drive .



- Remove bolt -2- and take off rear speed sensor -1-.
- Take out drive shaft from the inside.

Installing

Installation is carried out in reverse sequence. Note the following:


- Install rear final drive ⇒ Final drive; Rep. gr. 39; Final drive; Removing and installing final drive .
- Install speed sensor (rear) ⇒ Brake system; Rep. gr. 45; Sensors; Removing and installing rear speed sensors -G44- / -G46- .
- Fit rear wheel ⇒ page 329.
- Charge air springs of rear axle = page 284
- Tighten bolt securing drive shaft to wheel hub \Rightarrow page 269 .

ct to the correctness of information in this document. Copyright by AUDI AG. Tightening torques

♦ "7.1 Exploded view - drive shaft", page 267


7.3 Loosening and tightening bolt securing drive shaft

Special tools and workshop equipment required






Torque wrench - V.A.G 1576-



Loosening bolt securing drive shaft to wheel hub

- To avoid damage to wheel bearing, slacken off bolt no further than 90° with vehicle standing on its wheels.
- Remove rear wheel ⇒ page 329.
- Raise vehicle so that wheels are off the ground.
- Have a second mechanic press brake pedal.
- Remove bolt -arrow-.



A40-10419

Tightening bolt securing drive shaft to wheel hub

Renew bolt -arrow-.



Note

- Before securing, clean the threads in the CV joint using a thread tap
- The wheels must not be in contact with the ground when initially tightening the drive shaft bolt; otherwise the wheel bearing can be damaged.
- Have a second mechanic press brake pedal.
- Tighten bolt to 200 Nm.
- Lower vehicle onto its wheels.

Turn bolt 180° further.
Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Renewing constant velocity joint 7.4

⇒ "7.4.1 Renewing outer constant velocity joint", page 271

⇒ "7.4.2 Renewing inner constant velocity joint", page 273


7.4.1 Renewing outer constant velocity joint

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1331-



♦ Clamp tensioner - V.A.G 1682 A-




- ◆ Circlip pliers (commercially available)
- ♦ Sealant ⇒ Electronic parts catalogue

Removing outer constant velocity joint


- Clamp drive shaft in vice using protective jaw covers.
- Open hose clips.
- Push back boot.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Use hammer to tap copper or brass drift -A- against inner race of constant velocity joint.
- Detach joint and boot.




Detach circlip -1-.




Installing outer constant velocity joint

- Push boot with new hose clip onto drive shaft.
- Boot and drive shaft must be free from grease.
- Position boot between garrows in groove 42-e or commercial purpos
- 1 Circlip (always renew) uthorised by AUDI AG. AUDI AG does not guar
- 2 Positioning groove (push on boot until it engages in groove) ment.
- Pack 80 g of drive shaft grease evenly into inside of joint body.
- 2 A42-10311
- Grease splines -A- on drive shaft lightly with grease used in joint before fitting joint body onto drive shaft.
- Fit circlip in groove on shaft.




- Slide on constant velocity joint as far as circlip.
- Align circlip so that opening faces upwards -arrows-.

Protected by copyright. Copying for private or commercial purposes permitted unless authorised by AUDI AG. AUDI AG does not guarant with respect to the correctness of information in this document. Co




- Screw old bolt into CV joint as shown.
- Use plastic hammer to drive joint onto drive shaft until circlip engages.
- Fit boot on metal cap.
- Vent air from boot.
- Make sure boot is properly positioned on joint body.
- Boot must rest in groove and on contour of joint body.



Tightening hose clip on outer joint

- Apply clamp tensioner V.A.G 1682- as shown. Ensure jaws of tool make contact with lugs -arrows B- on hose clip.
- Tighten clip by turning spindle with torque wrench -C- (take care to keep tool straight).
- ◆ Due to the hard material of the CV joint boot (as opposed to rubber), a stainless steel hose clip is required; this can only be tightened using clamp tensioner - V.A.G 1682- .
- Tightening torque: 20 Nm.
- Use torque wrench with 5...50 Nm adjustment range (e.g. -V.A.G 1331-).
- Make sure thread of spindle on tool -A- turns freely. Lubricate with MoS₂ grease if necessary.
- If the thread is stiff (e.g. due to dirt), the required clamping force will not be attained at the hose clip when the specified tightening torque is applied.



7.4.2 Renewing inner constant velocity joint

Special tools and workshop equipment required



Thrust plate - VW 401-



♦ Thrust plate - VW 402-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not



Press tool - VW 409-




Press tool - VW 412-






♦ Support sleeve - VW 522-



♦ Clamp - 40 - 204 A-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



◆ Torque wrench - V.A.G 1331-




◆ Clamp tensioner - V.A.G 1682 A-




Circlip pliers (commercially available)

Removing inner constant velocity joint


- Clamp drive shaft in vice using protective jaw covers.
- Drive off cover with a copper or brass drift.




- Drive off cap with a copper or brass drift.
- Unfasten and detach only the small hose clip.



Remove circlip.



- Press inner constant velocity joint off drive shaft using special tools shown in illustration.
- Pull boot off drive shaft copyright. Copying for private or commercial purposes, in part permitted unless authorised by AUDI AG. AUDI AG does no with respect to the correctness of information in this document






40-204A

VW 401

Installing inner constant velocity joint

- Push boot with small hose clip onto drive shaft.
- Grease splines -A- on drive shaft lightly with grease used in joint before fitting joint body onto drive shaft.



VW 522

VW 402

- Press on joint as far as stop.
- Chamfer on internal diameter of ball hub (splines) must face contact collar of drive shaft.
- Tensioner 40-204 A- and clamping surface on drive shaft must be free of grease.


Note

tected by copyright. Copying for private or commercial purpos


- Use the special tools shown in the illustration. UDI AG does not guar
- Always renew circlip a correctness of information in this document.



- Check that circlip is properly seated.
- Before fitting boot, pack half the drive shaft grease provided into joint from boot side of joint.
- Degrease contact surface for cover.



- Apply sealant (hatched area) to clean surface on inside of cap on CV joint boot.
- Apply a continuous sealant bead of Ø 2 3 mm.
- Route sealant bead around inside of holes -arrow-.
- Use sealant as listed in ⇒ Electronic parts catalogue.
- Boot and contact surface of cap must be free of grease.




- Using bolts -arrows-, align new cover in relation to bolt holes.




Note

The alignment must be very accurate, because no further alignment is possible once the part has been hammered on.

- Drive on cover using a plastic hammer.
- Remove surplus sealant immediately as it is pressed out.
- Pack remainder of drive shaft grease into constant velocity joint through ball races.
- Degrease contact surface for cover and for constant velocity joint.
- Apply sealant -hatched area- to clean inner surface of cover.
- Apply a continuous sealant bead of Ø 2 3 mm.
- Route sealant bead around inside of holes -arrow-.
- Use sealant as listed in ⇒ Electronic parts catalogue .






Using bolts -arrows-, align new cover in relation to bolt holes.

The alignment must be very accurate, because no further alignment is possible once the part has been hammered on.

- Drive on cover using a plastic hammer.
- Remove surplus sealant immediately as it is pressed out.



Boot and drive shaft must be free from grease.


- Position boot between -arrows- in groove -2-.
- 1 Disregard
- 2 Positioning groove (push on boot until it engages in groove)



Note

The inner joint is not shown in the illustration.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability



Fitting and tightening hose clips on inner joint

- Apply clamp tensioner V.A.G 1682- as shown. Ensure jaws of tool make contact with lugs -arrows B- on hose clip.
- Tighten clip by turning spindle with torque wrench -C- (take care to keep tool straight).
- ◆ Due to the hard material of the CV joint boot (as opposed to rubber), a stainless steel hose clip is required; this can only be tightened using clamp tensioner - V.A.G 1682- .
- Tightening torque: 20 Nm.
- Use torque wrench with 5...50 Nm adjustment range (e.g. -V.A.G 1331-).
- Make sure thread of spindle on tool -A- turns freely. Lubricate with MoS₂ grease if necessary.
- If the thread is stiff (e.g. due to dirt), the required clamping force will not be attained at the hose clip when the specified tightening torque is applied.



Outer constant velocity joint with cap cannot be dismantled.

Only a visual inspection can be performed on outer constant velocity joint with cap.

Grease remaining in joint must be free from water and dirt.

If the visual inspection reveals wear or damage on the balls or ball races, the complete outer constant velocity joint with cap must be renewed.

Quantities and type of grease for drive shaft with outer constant velocity joint ⇒ page 268

Checking inner constant velocity joint

The joint should be dismantled to renew dirty grease or for checking the balls and ball races for wear and damage.

Dismantling

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability





Note

with respect to the correctness of information in this document. Copyright by AUDI AG.

Ball hub and joint body are paired and must be marked before dismantling. Ensure that the balls run in the same races after assembly.

- Swivel ball hub and ball cage.
- Press out joint body in direction of -arrow-.
- Push balls out of cage.





- Align ball hub with cage as shown -arrows- and pivot hub out of cage.
- Check joint, ball hub, ball cage and balls for pitting and signs of seizure.





Note

Excessive backlash in the joint will cause knocking or jolts under load change. In such cases the joint must be renewed. Polished areas and visible tracks in the ball races are not a reason for renewing the joint.

Assembling

- Insert hub into cage via the two chamfers. No specific installation position is required. Push balls into cage.
- Insert hub with cage and balls at a right angle to the joint body.






- When inserting, ensure that the wide spacing -a- on the joint body is aligned with the narrow spacing -b- on the hub after swivelling in.
- Chamfer on internal diameter of ball hub (splines) must face drive shaft.

Protected by copyright. Copying for private or commercial purpo permitted unless authorised by AUDI AG. AUDI AG does not guar with respect to the correctness of information in this document.

V40-0012

Swivel the hub into the joint body; at the same time the hub must be swivelled out of the cage -arrows- far enough to allow the balls to fit into the ball races.






Swivel in the hub with balls by applying firm pressure on the cage -arrow-.

Checking function of constant velocity joint

The constant velocity joint has been correctly assembled if the ball hub can be moved by hand backwards and forwards over its entire axial range of movement.

- Pack required amount of grease into joint body.

Quantities and type of grease for drive shaft with inner constant velocity joint ⇒ page



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Self-levelling suspension

Electronic damping control

- ⇒ "1.1 Overview of fitting locations electronic damping control", page 282
- ⇒ "1.2 Re-adapting reference position (default position)", page 283
- ⇒ "1.3 Bleeding or charging system", page 284

1.1 Overview of fitting locations - electronic damping control

- 1 Front left vehicle level sender - G78-
 - Removing and installing ⇒ page 286
 - □ Re-adapting reference position (default position) following disconnection ⇒ page 283
 - □ Checking ⇒ Vehicle diagnostic tester in Guided Fault Finding
- 2 Air spring (front left)
 - With front left shock absorber damping adjust-ment valve - N336-
 - Removing and installing ⇒ page 238
 - □ Charging ⇒ page 284
- 3 Front right vehicle level pyr sender - G289-
 - Removing and installing ⇒ page/286 espect to the
 - □ Re-adapting reference position (default position) following disconnection ⇒ page 283
 - □ Checking ⇒ Vehicle diagnostic tester in Guided Fault Finding
- 4 Air spring (front right)
 - With front right shock absorber damping adjustment valve - N337-
 - Removing and installing ⇒ page 238
 - □ Charging ⇒ page 284
- 5 Air spring (rear right)
 - □ Removing and installing ⇒ page 223
 - □ Charging ⇒ page 284
- 6 Adaptive suspension control unit J197-
 - □ Removing and installing ⇒ page 295
 - ☐ For correct version refer to ⇒ Electronic parts catalogue





/ - 176	ear right verlicle level serider - G77-					
	Removing and installing ⇒ page 287					
	Re-adapting reference position (default position) following disconnection ⇒ page 283					
	Checking ⇒ Vehicle diagnostic tester in Guided Fault Finding					
8 - Solenoid valve block						
	⇒ page 306					
9 - Accumulator						
	Removing and installing ⇒ page 309					
10 - A	10 - Air supply unit					
	⇒ "3.2 Exploded view - air supply unit", page 291					
	If air supply unit is renewed, adaptive suspension compressor relay - J403- must also be renewed. Fitting location \Rightarrow Current flow diagrams, Electrical fault finding and Fitting locations					
11 - Rear left vehicle level sender - G76-						
	Removing and installing ⇒ page 287					
	Re-adapting reference position (default position) following disconnection ⇒ page 283					
	Checking ⇒ Vehicle diagnostic tester in Guided Fault Finding					
12 - A	Air spring (rear left)					
	Removing and installing ⇒ page 223					
	Charging ⇒ page 284					

1.2 Re-adapting reference position (default position)



Note

The reference position (default setting) of the suspension must always be adapted and the basic headlight setting must always be checked when:

- Lower transverse link has been removed and installed or renewed,
- Subframe has been renewed, Permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
 Work has been performed on the vehicle level sender,
- tness of information in this document. Copyright by AUDI AG.
- Vehicle level sender has been renewed,

Door right vehicle level conder C77

- ♦ Coupling rod for vehicle level sender has been unbolted from lower transverse link,
- ♦ Adaptive suspension control unit J197- has been renewed.

Requirements:

- The vehicle must be standing on a level surface.
- The vehicle must be unladen.

Adaption of the reference position (default position) is performed using the vehicle diagnostic tester:

VAS PC

Connect up ⇒ Vehicle diagnostic tester.

- Select Guided Functions mode.
- Select "34 Adaptive suspension control unit".



 Select "J197 - Re-adapting reference position" and follow instructions on screen.

ODIS - Offboard Diagnostic Information System

Connect up ⇒ Vehicle diagnostic tester.

- Select Diagnosis mode and begin diagnosis.
- Select Control units tab.
- Select "34 Adaptive suspension control unit".
- Select "J197 Re-adapting reference position" and follow instructions on screen.



Note

- ♦ If the 'reference position has been re-adapted', the camera control unit - J852- must be recalibrated on vehicles with lane departure warning function ⇒ page 365.
- ◆ Perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights.

1.3 Bleeding or charging system

Bleeding and charging the air spring system is performed using the vehicle diagnostic tester :

VAS PC

Connect up ⇒ Vehicle diagnostic tester.

- Select Guided Functions mode.
- Select "34 Adaptive suspension control unit".
- Select "J197 Bleeding or charging system" and follow instructions on screen.

ODIS - Offboard Diagnostic Information System

Connect up ⇒ Vehicle diagnostic tester.


- Select Diagnosis mode and begin diagnosis mercial purposes, in part or in whole, is not
- |Select | Control aunits tabby AUDI AG. AUDI AG does not guarantee or accept any liability
- Select 34^{t-t}Adaptive suspension control unit. this document. Copyright by AUDI AG.
- Select "J197 Bleeding or charging system" and follow instructions on screen.



2 Vehicle level senders

- ⇒ "2.1 Exploded view vehicle level senders", page 285
- "2.2 Removing and installing front vehicle level senders G78 / G289 ", page 286
- ⇒ "2.3 Removing and installing rear vehicle level senders G76 / G77 ", page 287

Exploded view - vehicle level senders 2.1



General notes:

11 - Bolt □ 5 Nm

Vehicles with adaptive suspension and/or gas discharge headlights have automatic headlight range control fitted as standard



equipment ⇒ Electrical system; Rep. gr. 94; Automatic headlight range control; Exploded view - automatic headlight range control.

The adaptive suspension and the automatic headlight range control functions require information on the compression and rebound travel at the front and rear suspension.

For this purpose, the position of the left/right transverse link in relation to the body is transferred to the rear left vehicle level sender - G76- and the rear right vehicle level sender - G77- via a coupling rod. The senders then transmit electrical signals to the adaptive suspension control unit - J197- .

On the front axle these signals are sent by the front left vehicle level sender - G78- and front right vehicle level sender - G289- to the adaptive suspension control unit - J197-.

These signals are required for calculating the current attitude of the vehicle.

The automatic headlight range control reacts to changes in the cial purposes, in part or in whole, is not suspension height (attitudes of the vehicle) AUDI AG. AUDI AG does not guarantee or accept any liability

The following situations may produce a change in the suspension cument. Copyright by AUDI AG. height:

- Towing mode
- Different loads (vehicle unladen, partly laden or fully laden)



Note

The reference position (default setting) of the suspension must always be adapted and the basic headlight setting must always be checked when:

- Lower transverse link has been removed and installed or renewed.
- Subframe has been renewed.
- Work has been performed on the vehicle level sender,
- Vehicle level sender has been renewed,
- Coupling rod for vehicle level sender has been unbolted from transverse link.

2.2 Removing and installing front vehicle level senders -G78- / -G289-

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1410-





A40-10396

Removing

- Unplug connector -2-.
- Unscrew nut (not visible in illustration) on mounting -3-.
- Remove bolt -1-.
- Detach vehicle level sender -4-.

Installing

Installation is carried out in reverse sequence. Note the following:

- · Lever of sender must face forwards.
- Locating hook on sender bracket must engage on subframe.
- Re-adapt reference position copyright. Copying for private or commercial purposes, in part or in whole, is not "1.2 Re-adapting reference position (default position)". page AG does not guarantee or accept any liability
- with respect to the correctness of information in this document. Copyright by AUDI AG.

 Perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights.

Tightening torques

♦ ± "4.1 Exploded view - transverse links", page 203

2.3 Removing and installing rear vehicle level senders -G76- / -G77-

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1410-



Removing

- Remove wheel.
- Unplug electrical connector -2-.
- Unscrew bolt -1- for coupling rod.
- Remove bolts -3- and detach vehicle level sender.

Installing


Installation is carried out in reverse sequence. Note the following:

- Lever of sender must face forwards.
- Re-adapt reference position ⇒ page 283.
- Perform basic setting of headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights.

Tightening torques

♦ 3 "4.1 Exploded view - transverse links", page 203







3 Air suspension

- ⇒ "3.1 Overview of fitting locations electrical components", page
- ⇒ "3.2 Exploded view air supply unit", page 291
- ⇒ "3.3 Exploded view air pipes", page 293
- ⇒ "3.4 Removing and installing adaptive suspension control unit J197 ", page 295
- ⇒ "3.5 Servicing air pipe", page 296
- ⇒ "3.6 Renewing connection piece", page 300
- ⇒ "3.7 Removing and installing air supply unit", page 301
- ⇒ "3.8 Removing and installing adaptive suspension drain valve N111 ", page 304
- ⇒ "3.9 Removing and installing solenoid valve block", page 306
- ⇒ "3.10 Removing and installing intake pipe with filter", page 308
- ⇒ "3.11 Removing and installing accumulator", page 309

3.1 Overview of fitting locations - electrical components




Note

- The air pipes to the air springs/air spring struts are incorporated into the electrical wiring harness.
- Servicing air pipes ⇒ page 296
- Renewing connection piece ⇒ page 300





- 1 Air spring strut (front left)
- 2 Air pipe "red"
 - From solenoid valve block to air spring strut (front left)
 - Routing of air pipe (front) ⇒ page 290
- 3 Air pipe "green"
 - □ From solenoid valve block to air spring strut (front right)
 - Routing of air pipe (front) ⇒ page 290
- 4 Air spring strut (front right)
- 5 Air pipe "blue"
 - From solenoid valve block to air spring (rear right)
- □ Routing of air pipe (rear Protectedeft) <u>⇒ page 291</u> pying fo
- permitteRouting of air pipe (rear right) ⇒ page 291. ess of i
 - 6 Air spring (rear right)
 - 7 Air pipe "brown"
 - ☐ From air supply unit to solenoid valve block
 - Routing of air pipe to solenoid valve block ⇒ page 290 .
 - 8 Solenoid valve block
 - Identification of pipes on solenoid valve block ⇒ page 290
 - 9 Accumulator
 - □ 6 Nm
 - 10 Air pipe "purple"
 - □ From solenoid valve block to accumulator
 - □ Routing of air pipe ⇒ page 291.
 - 11 Air supply unit
 - 12 Air intake pipe with filter and silencer
 - □ Removing and installing ⇒ page 308
 - 13 Air pipe "black"
 - ☐ From solenoid valve block to air spring (rear left)
 - □ Routing of air pipe (rear) ⇒ page 291.
 - 14 Air spring (rear left)





Identification of pipes on solenoid valve block



Note

The air pipes are incorporated into the wiring harness before the opening leading to the interior.

The air pipes are colour-coded:

- Air pipe "brown": from air supply unit
- 2 -Air pipe "green": to air spring strut (front right)
- Air pipe "blue": to air spring (rear right)
- Air pipe "black": to air spring (rear left)
- Air pipe "red": to air spring strut (front left)
- Air pipe "purple": to accumulator

Servicing cutting location for air pipe > page 29

Tightening torques

◆ ⇒ "3.3 Exploded view - air pipes", page 293

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

Routing of air pipe from air supply unit to exterior solenoid valve DI AC block

with respect to the correctness of information in Air pipe -4- goes from air supply unit -6- to solenoid valve block, and is incorporated into wiring harness -1-.

- 2 Pipe connection piece
- 3 Bracket
- 5 Clip

Tightening torques

♦ 3.3 Exploded view - air pipes", page 293

Routing of air pipe to air spring strut (front)


Air pipe is incorporated into wiring harness at clip -arrow-.

Residual pressure valve -2- must not be loosened.


Servicing cutting location for air pipe ⇒ page 294

Tightening torques

⇒ "3.3 Exploded view - air pipes", page 293



A43-10199






Routing of air pipe to air spring (rear left)

- Air spring (rear)
- 2 -Air pipe
- 3 Clip

Tightening torques

◆ ⇒ "3.3 Exploded view - air pipes", page 293




Routing of air pipe to air spring (rear right) Air spring (rear)

- 2 Clip
- 3 Air pipe
- 4 Cable ties

Tightening torques

♦ 3.3 Exploded view - air pipes", page 293




Routing of air pipe from air supply unit to valve block

Air pipe -2- goes to solenoid valve block -1-, and is incorporated into wiring harness -3-.

Tightening torques

◆ ⇒ "3.3 Exploded view - air pipes", page 293



3.2 Exploded view - air supply unit






- 1 Bolt
 - □ 9 Nm
- 2 Bracket
 - □ For securing complete air supply unit to spare wheel well unless autho
 - □ Removing and installing ⇒ page 30°
- 3 Clip
- 4 Air intake pipe with filter
 - Removing and installing ⇒ page 308
- 5 Air pipe

- 6 Pipe connector
- 8 Air supply unit with adaptive suspension drain valve - N111-

pension compressor relay - J403- must also be renewed. Fitting location ⇒ Current flow diagrams, Electrical fault finding and Fitting locations

A43-10166




9 - Sleeve screw

- □ 4x
- □ 7.5 Nm
- 10 Spring
 - □ 4x
- 11 Rubber mounting
 - □ 4x
- 12 Bracket
- 13 Bolt
 - For securing air supply unit to bracket
 - □ 3x
 - □ 9 Nm
- 14 Nut
 - □ 9 Nm




Tightening torque - stone deflector

- Tighten nuts -arrows- to 9 Nm.




Tightening torque - adaptive suspension drain valve - N111-Tighten bolts -1- to 5 Nm.



3.3 Exploded view - air pipes Air pipes



- 1 Pipe connector
- 2 Connection piece on air spring strut (front)
 - □ 3 Nm
- 3 Connection piece on air spring (rear)
 - □ 2.5 Nm
- 4 Connection piece on air supply unit
 - □ 3 Nm
- 5 Connection pieces on sole-noid valve block
 - □ 2x, 12 mm
 - □ 3.5 Nm
- 6 Connection pieces on solenoid valve block
 - □ 2x, 10 mm
 - □ 2 Nm
- 7 Connection pieces on solenoid valve block
 - □ 2x, 12 mm
 - □ 3.5 Nm
- 8 Connection piece on accumulator
 - □ 5 Nm




Connection points





- A Cutting location on air pipe for air spring strut (front)
- 1 New air pipe
- 2 Sheathed pipe connector
- 3 Original air pipe
- 4 Wiring harness
- B Cutting location on air pipe for air spring (rear)
- 5 New air pipe
- 6 Sheathed pipe connector
- C Cutting location on air pipe for solenoid valve block in interior
- 7 New air pipe
- 8 Wiring harness
- 9 Sheathed pipe connector
- 10 Original air pipe



3.4 Removing and installing adaptive suspension control unit - J197-

The adaptive suspension control unit - J197- is located behind the side trim in the luggage compartment (right-side).

Removing


- When renewing control unit, select "Replace" function for relevant control unit using ⇒ Vehicle diagnostic tester in Guided Functions mode.
- Follow the instructions on the screen.
- Switch off ignition yright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Remove storage area in luggage compartment (right-side).
- Release relay and fuse holder and place to one side.



Protected by copyright. Copying for private or commercial purposes, in permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document. Copyr




- Unplug electrical connectors -2-.
- Using a long screwdriver -1-, release catches on both sides -arrow- and detach adaptive suspension control unit - J197--item 3-.

Installing

Installation is carried out in reverse sequence. Note the following:


Re-adapt reference position ⇒ page 283.



3.5 Servicing air pipe



Special tools and workshop equipment required



- ◆ Torque wrench V.A.G 1783-
- ♦ Open end spanner insert (10 mm) V.A.G 1783/1-

◆ Cutting pliers - VAS 6228-Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Procedure permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

If the air pipe is damaged the damaged section can be renewed a document. Copyright by AUDI AG.

In the event of leakage at the connection, the air pipe can be shortened by 10 mm and a new connection piece fitted ⇒ page 300 .



- The air pipes between the solenoid valve block and the accumulator and between the solenoid valve block and the air supply unit are replaced completely with new pipes (same as original equipment).
- ♦ Clean the area around the cutting point before cutting the air
- Any dirt entering the connections can cause malfunctions or failure of the system.



Clean sections in vicinity of connection piece and relevant cutting location.

Overview of cutting locations ⇒ page 294

- Cut through air pipe at cutting location (at a right angle) using cutting pliers VAS 6228- .
- Unscrew connection piece and remove air pipe.
- Then use waterproof pen to mark end of air pipe in vehicle and both ends of new air pipe.



Note

Use 17 mm/22 mm marks to check whether air pipe has been properly inserted in connection piece.


- Fit sponge rubber insulation to both pipes.
- Fit new pipe connector.



Note

The connection pieces in the pipe connector are already tightened to torque. The air pipes only need to be pushed in.

Remove transport protection cap.







- Push old air pipe through seals -1- and -2-.
- Then push air pipe through sealing edges -3- and -4- of cutting ring in pipe connector as far as stop -5-, exerting more force as required.
- Fit sponge rubber insulation over connection pieces.
- Repeat this procedure with the new pipe.
- Renew connection piece ⇒ page 300.

Cutting location on air pipe for air spring strut (front) ⇒ Item A (page 295)

- Release original air pipe from wiring harness.
- Sheathe wiring harness again in the proper manner.
- Service air pipe.
- Secure sheathed pipe connector and new air pipe to wiring harness with cable ties.

Cutting location on air pipe for air spring (rear) ⇒ Item B (page 295)



Note

Route new air pipe ⇒ Item 5 (page 295) as shown in illustration.

- Service air pipe.
- Secure sheathed pipe connector and new air pipe with cable

Cutting location on air pipe for solenoid valve block in interior ⇒ Item C (page 295)



Note

If air pipes are damaged at the solenoid valve block, the cutting location must be positioned in the vehicle interior (spare wheel well) because of the short pipe lengths.


- Release original air pipe from wiring harness.
- Sheathe wiring harness again in the proper manner.
- Service air pipe.
- Secure sheathed pipe connector and new air pipe to wiring harness with cable ties.



- The vehicle must not be lowered from the lifting platform until Protected by the part or in whole, is not
- permRefore charging the air spring system, check that the locating e or accept any liability pin on the air spring is engaged correctly in the body. At the with same the retainers on the air spring must be correctly engaged right by AUDI AG. under the wheel bearing housing ⇒ page 217.

Tightening torques


⇒ "3.3 Exploded view - air pipes", page 293





3.6 Renewing connection piece

Special tools and workshop equipment required



- Torque wrench V.A.G 1783-
- Open end spanner insert (10 mm) V.A.G 1783/1-
- ♦ Cutting pliers VAS 6228-


In the event of leakage at the connection, the air pipe can be shortened by 10 mm (if sufficient length is available) and a new connection piece fitted.




- Clean the area around the cutting point before cutting the air pipe.
- Any dirt entering the connections can cause malfunctions or failure of the system.
- Clean area around connection piece.
- Unscrew connection piece and detach air pipe. private or commercial purposes, in part or in whole, is not
- Detach cutting ring from air pipe.
 by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Use cutting tool VAS 6228- to cut through the air pipe at a right angle behind the impression made by the cutting ring.
- Then use waterproof pen to mark end of air pipe in vehicle.
- Protected by copyright. Copying for private or commercial purposes, in Note d unless authorised by AUDI AG. AUDI AG does not guarantee
- Use 17 mm/22 mm marks to check whether air pipe has been properly inserted in connection piece.
- Always renew connection piece.
- Important: Always keep to specified tightening torque.
- Screw in and tighten new connection piece by hand ⇒ "3.3 Exploded view - air pipes", page 293
- Only remove transport protection caps -2- and -3- immediately prior to attachment of air pipe -4-.
- Install and secure air pipe in vehicle with appropriate clips and/ or grommets. If necessary, renew cable ties that have been cut open.
- Detach transportation caps -2- and -3-.
- Exerting moderate pressure, push air pipe -4- all the way into connection piece -1-.
- Air pipes have been properly fitted if only one of the two marks is visible -arrow A-.





3.7 Removing and installing air supply unit

⇒ "3.7.1 Removing and installing air supply unit with bracket",

⇒ "3.7.2 Removing and installing air supply unit", page 303

3.7.1 Removing and installing air supply unit with bracket


Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1783-





Open end spanner insert (10 mm) - V.A.G 1783/1-



Removing




Note

The air supply unit is bolted to the underbody (spare wheel well) via the bracket.

- Bleed air spring system ⇒ page 284.
- When renewing control unit, select "Replace" function for relevant control unit using > Vehicle diagnostic tester in Guided Functions mode.
- Switch off ignition.
- Remove nuts -arrows-.
- Detach stone deflector -1-.



- Make sure that no dirt enters the compressed air system.
- Clean the affected area before detaching connection pieces for air pipes or components of the compressed air system.
- Cover or seal off open air pipes and connections of the commercial purposes, in part or in whole, is not pressed air system immediately with a plug. permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





- Detach electrical connectors -2- and -4- from bracket and unplug.
- Release clamp -5- and detach intake pipe.
- Release air pipe -3- at bracket and detach.
- Remove nut -1- and bolts -arrows-.
- Take out bracket with air supply unit -5-.

Installation is carried out in reverse sequence. Note the following:



Note

- The vehicle must not be lowered from the lifting platform until the system has been recharged ⇒ page 18.
- ♦ Before charging the air spring system, check that the locating pin on the air spring is engaged correctly in the body. At the same the retainers on the air spring must be correctly engaged under the wheel bearing/housing wpage 217 vate or commercial purposes, in part or in whole, is not

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability Charge air spring system > page 284. ess of information in this document. Copyright by AUDI AG.

If air supply unit has been renewed, adaptive suspension compressor relay - J403- must also be renewed. Fitting location ⇒ Current flow diagrams, Electrical fault finding and Fitting locations

Tightening torques

- ♦ 3.2 Exploded view air supply unit", page 291
- ♦ 3.3 Exploded view air pipes", page 293
- ♦ ⇒ Fig. ""Tightening torque stone deflector"", page 293

3.7.2 Removing and installing air supply unit


Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1783-



Removing

Remove bracket with air supply unit ⇒ page 301.







Note

- Make sure that no dirt enters the compressed air system.
- Clean the affected area before detaching connection pieces for air pipes or components of the compressed air system.
- Cover or seal off open air pipes and connections of the compressed air system immediately with a plug.
- Release air pipe and electrical wiring from clip -1-.
- Remove sleeve screws -arrows- and detach air supply unit -2-.

Installing

Installation is carried out in reverse sequence. Note the following:



Note

- The vehicle must not be lowered from the lifting platform until the system has been recharged ⇒ page 18.
- ◆ Before charging the air spring system, check that the locating pin on the air spring is engaged correctly in the body. At the same the retainers on the air spring must be correctly engaged under the wheel bearing housing ⇒ page 217.

If air supply unit has been renewed, adaptive suspension compressor relay - J403- must also be renewed. Fitting location ⇒ Current flow diagrams, Electrical fault finding and Fitting locations

Tightening torques

- ♦ 3.2 Exploded view air supply unit", page 291
- ♦ ⇒ "3.3 Exploded view air pipes", page 293


3.8 Removing and installing adaptive suspension drain valve - N111-

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1783-









Removing



Note


The adaptive suspension drain valve - N111- is located at the air supply unit.

Remove air supply unit ⇒ page 303.



Note

- Make sure that no dirt enters the compressed air system.
- Clean the affected area before detaching connection pieces for air pipes or components of the compressed air system.
- ♦ Cover or seal off open air pipes and connections of the compressed air system immediately with a plug.
- Unplug electrical connector -3- at adaptive suspension drain valve - N111- -item 2-.
- Remove bolts -1-.







Take out adaptive suspension drain valve - N111--5- together with O-rings -1- and -4-, spring -3- and armature -2-.



Note


O-ring -1- may have remained in the housing of the air supply unit.

Installation is carried out in reverse sequence. Note the following:



Note

- The vehicle must not be lowered from the lifting platform until the system has been recharged ⇒ page 18.
- Before charging the air spring system, check that the locating pin on the air spring is engaged correctly in the body. At the same the retainers on the air spring must be correctly engaged under the wheel bearing housing ⇒ page 217.





Note

Always renew O-rings.

- Lubricate new O-rings -1- and -4- with grease provided.
- Make sure armature -2- is installed in correct position. Chamfered end faces spring -3-.
- Adaptive suspension drain valve N111- must be kept straight while installing and tightening bolts.
- Charge air spring system ⇒ page 284.

Tightening torques

- ⇒ "3.2 Exploded view air supply unit", page 291
- ⇒ "3.3 Exploded view air pipes", page 293
- ⇒ Fig. ""Tightening torque adaptive suspension drain valve N111- "", page 293

3.9 Removing and installing solenoid valve block

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1410-








◆ Torque wrench - V.A.G 1783-



Open end spanner insert (10 mm) - V.A.G 1783/1-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Removing



Note

Solenoid valve block is located at air supply unit.

- Position vehicle on lifting platform ⇒ page 18.
- Bleed system ⇒ page 284.
- Switch off ignition.
- Remove luggage compartment floor covering or take out spare wheel ⇒ General body repairs, interior; Rep. gr. 70; Luggage compartment trim panels; Exploded view - luggage compartment floor.



- Make sure that no dirt enters the compressed air system.
- Clean the affected area before detaching connection pieces for air pipes or components of the compressed air system.
- Cover or seal off open air pipes and connections of the compressed air system immediately with a plug.

- Unplug electrical connector -2-.
- Unscrew air pipes -arrows- and protect immediately from dirt.
- Detach solenoid valve block -1-.

Installation is carried out in reverse sequence. Note the following:



Note

- The vehicle must not be lowered from the lifting platform until the system has been recharged ⇒ page 18.
- ♦ Before charging the air spring system, check that the locating pin on the air spring is engaged correctly in the body. At the same the retainers on the air spring must be correctly engaged under the wheel bearing housing ⇒ page 217.
- Charge air spring system ⇒ page 284.

Tightening torques

- ⇒ "3.2 Exploded view air supply unit", page 291
- ⇒ "3.3 Exploded view air pipes", page 293

3.10 Removing and installing intake pipe with filter

Special tools and workshop equipment required

Torque wrench - V.A.G 1783-



Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG d with respect to the correctness of information in thi




W00-11189

Removing

Remove rear left wheel housing liner ⇒ General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Removing and installing wheel housing liner (rear) .



- Make sure that no dirt enters the compressed air system.
- Clean the affected area before detaching connection pieces for air pipes or components of the compressed air system.
- Cover or seal off open air pipes and connections of the compressed air system immediately with a plug.






- Remove nuts -arrows-.
- Release clamp -1-, move clear intake pipe with filter and detach.

Installation is carried out in reverse sequence. Note the following:

Install rear left wheel housing liner ⇒ General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Exploded view wheel housing liner (rear).



3.11 Removing and installing accumulator

Special tools and workshop equipment required

♦ Torque wrench - V.A.G 1783-

Protected by copyright. Copying for private or commercial purposes, in part or in wh permitted unless authorised by AUDI AG. AUDI AG does not guarantee or a with respect to the correctness of information in this document. Copy



♦ Vehicle diagnostic tester

Removing



Note

The accumulator is installed in the spare wheel well.

- Switch on ignition.
- Bleed accumulator ⇒ page 284.
- Detach cover for tool box.
- Detach solenoid valve block from tool box and take out tool box.



- Make sure that no dirt enters the compressed air system.
- Clean the affected area before detaching connection pieces for air pipes or components of the compressed air system.
- ◆ Cover or seal off open air pipes and connections of the compressed air system immediately with a plug.




- Slowly loosen air pipe -1- at accumulator to dissipate air pressure. Unscrew air pipe when air pressure has been dissipated.
- Detach solenoid valve block -2- and move to one side.
- Unscrew nuts -arrows- and take out accumulator.

Installation is carried out in reverse sequence. Note the following:

Charge accumulator ⇒ page 284.

Tightening torques

- ♦ Nuts for accumulator: 6 Nm
- ⇒ "3.3 Exploded view air pipes", page 293







4 Dynamic Ride Control (DRC)

- ⇒ "4.1 System description DRC", page 311
- ⇒ "4.2 Overview of fitting locations DRC", page 312
- ⇒ "4.3 Exploded view central valve", page 314
- ⇒ "4.4 Removing and installing central valve", page 315
- ⇒ "4.5 Removing and installing electronically controlled damping control unit J250 ", page 315
- ⇒ "4.6 Checking DRC system", page 316
- ⇒ "4.7 Checking DRC system pressure", page 317
- ⇒ "4.8 Discharging and charging DRC system", page 318

4.1 System description - DRC

The DRC wheel damping system counteracts the pitch and roll of the body about the longitudinal and transverse axes to permit optimum handling. A driver-adjustable DRC with variable damping is installed on the Audi RS models.

In addition to the suppression of pitch and roll (comparable to the purely hydraulic DRC), the driver-adjustable DRC with variable damping offers the further option of setting different levels of damper stiffness by way of the Audi drive select controls. To achieve this, each shock absorber is provided with an additional element with integrated DC motor. The DC motors are activated by the electronically controlled damping control unit - J250-.

The driver can select several different damper settings:

- "COMFORT"
- "DYNAMIC"
- "AUTO"
- ◆ "INDIVIDUAL"

Use only the approved type of fluid when charging and topping up the system. Please refer to ⇒ Electronic parts catalogue.



- The "COMFORT" damper setting must be activated when discharging, evacuating and charging the DRC system on vehicles with variable damping.
- To discharge, evacuate and charge the DRC system, select address word 14 in "Guided Functions" and start the function Charge DRC ⇒ Vehicle diagnostic tester.
- When this function is activated, the system switches to COMFORT" mode and cannot be switched back manually. The yellow warning lamp in the instrument cluster lights up while the charging function is activated.



Charging may only be performed at room temperature (approx. 20° Celsius).

Replacement shock absorbers and pipes are supplied empty.

Pipes/shock absorbers and central valves may only be discharged, evacuated and charged when they are installed in the vehicle and connected.

The vehicle must never be lowered onto its wheels when the DRC system is separated from the individual components (e.g. connection between pipe/shock absorbers/central valve).

When charging the DRC system, the gas accumulator leading to the pressure chambers at the piston in the central valve is automatically checked for leaks.

If the pressure of 22 bar could not be obtained, or if the pressure drops continuously when charging the DRC system, check all the separating couplings and connections for leaks and damage. If no irregularities are visible on the outside, the piston of the gas accumulator inside the central valve leading to the pressure chambers is leaking, so the central valve must be renewed.

Discharging, evacuating or charging the DRC system can only be performed at the drain/charge valve (front) and at the drain/ charge valve (rear) of the shock absorbers in the relevant section of the system. Note the following:



CAUTION

Safety goggles must be worn for all procedures.

Discharge the relevant section of the system completely before removing or disconnecting any DRC components.

Shock absorbers may only be charged when they are installed in the vehicle and connected.

Pipes must not be bent.

When connecting and disconnecting pressure gauge -V.A.S 6209/2-, a small amount of fluid will always escape at the connection, but this is not critical. Repeated measurements should be avoided because the system loses a small amount of fluid every time the pressure tester -V.A.S 6209/2- is connected. The pressure reading will be about 0.3 bar lower than the previous value when the tester is reconnected. Several repeated measurements will thus cause the pressure in the system to drop below the minimum limit, or can cause failure of the system.


4.2 Overview of fitting locations - DRC






- 1 Front suspension strut with drain/charge valve
- ⇒ page 314
 - Additional element with integrated DC motor on vehicles with variable damping
- 2 Warning lamp
 - On vehicles with variable damping
- 3 Operating unit for Audi drive select
 - On vehicles with variable damping
- 4 Electronically controlled damping control unit - J250-
 - On vehicles with variable damping
 - Removing and installing ⇒ page 315
- 5 Central valves
 - Removing and installing ⇒ page 315
 - □ The DRC system comprises two separate hydraulic systems. The central valves are connected diagonally in relation to the corresponding shock absorbers.
- 6 Rear shock absorber with drain/charge valve
- ⇒ page 315
 - Additional element with integrated DC motor on vehicles with variable damping
- 7 Connecting piece to front suspension strut (right/left)
 - □ 14 Nm






4.3 Exploded view - central valve

- 1 Bolt
 - □ 20 Nm
- 2 Bracket
- 3 Central valve
 - ☐ The DRC system comprises two separate hydraulic systems. The central valves are connected diagonally in relation to the corresponding shock absorbers.
 - Removing and installing ⇒ page 315 permitted
- 4 DRC pipe to shock absorber (rear)
 - ☐ Green marking (left-side)
 - □ Blue marking (rightside)
 - □ 14 Nm
- 5 DRC pipe to shock absorber (front)
 - Yellow marking (leftside)
 - ☐ White marking (right-side)
 - □ 14 Nm
- 6 Bolt
 - □ 20 Nm



Suspension strut (front)


- 1 Drain/charge valve with hose; ensure strain-free installation
- 2 Bracket
- 3 Clip
- 4 Union nut, 14 Nm
- 5 Additional element with control motor, fitted on vehicles with variable damping
- 6 DRC shock absorber
- 7 Union nut, 14 Nm
- 8 Clip





Shock absorber (rear)

- Additional element with control motor, fitted on vehicles with variable damping
- Drain/charge valve with hose; ensure strain-free installation
- 3 -
- Union nut, 14 Nm
- Bracket 5 -
- 6 -Clip
- 7 -Union nut, 14 Nm
- DRC shock absorber



4.4 Removing and installing central valve

Removing

The central valves are bolted on the impact bar under the rear bumper cover.

Remove bumper cover (rear) ⇒ General body repairs, exterior; Rep. gr. 63; Bumper (rear); Removing and installing

bumper cover d by copyright. Copying for private or commercial purposes, in part or in whole, is not



CAUTION

accept any liability

Safety goggles must be worn for all procedures ument. Copyright by AUDI AG.



Note

- Before disconnecting the DRC pipes from the central valve, the relevant section of the system must be discharged *⇒ page 318 .*
- This step must be repeated for both sets of pipes connected to the relevant central valve.
- Unscrew union screws -2-.
- Remove bolts -1 and 3- and detach central valve -4-.

Installing

- Installation is carried out in reverse sequence. Note the following:
- Connect DRC pipes to relevant central valve.


Fill DRC system ⇒ page 318.

Tightening torques

♦ "4.3 Exploded view - central valve", page 314

4.5 Removing and installing electronically controlled damping control unit - J250-

Replacement of the control unit does not require encoding and adaption. For this reason the "Replacement" function cannot be





performed in the "Guided Fault Finding" routine using the vehicle diagnostic tester.

The new electronically controlled damping control unit - J250- can be started up directly.




Note

Electronically controlled damping control unit - J250- is located behind side trim in luggage compartment (right-side)

Removing

- Switch off ignition.
- Remove storage area in luggage compartment (right-side).
- Release relay and fuse holder and place to one side.


Protected by copyright. Copying for private or commercial purpos permitted unless authorised by AUDI AG. AUDI AG does not guar with respect to the correctness of information in this document.



- Unplug electrical connectors -2-.
- Using a long screwdriver -1-, release catches on both sides -arrow- and detach adaptive suspension control unit - J197--item 3-.

Installing

Installation is carried out in reverse sequence.



4.6 Checking DRC system

Start						
Rattling noise coming from suspension or rear of vehicle when driving over rough surfaces			Excessive body roll when entering a bend			
→	Visible fluid leakage?		←			
	↓	↓				
 Check components Check unions at central valves, shock absorbers and pipe connections Renew leaking shock absorbers 	← Yes	No →	Check all unions at central valves, shock absorbers and pipe connections			
↓			↓			
1		Problem eliminated?				
<u></u>		↓	<u></u>			
↓		No ↓	Yes ↓			



1		Check system pressure in both sections of system. (Central valves must be closed when connecting and disconnecting pressure tester.)	1			
↓		↓	↓			
↓			↓			
↓		Yes ↓	↓			
Discharge, evacuate and charge ent tem using filling device for DRC sy 6544- ; check for leakage ⇒ pa	ire DRC sys- stem - VAS ge 318	†	†			
↓		↓	↓			
	↓		↓			
↓						
End						

4.7 Checking DRC system pressure

Special tools and workshop equipment required

- Pressure tester -V.A.S 6209/2-
- ♦ Hand vacuum pump VAS 6213-

Bleeding pressure tester -V.A.S 6209/2-

Use only the approved type of fluid for this bleeding procedure.

Please refer to ⇒ Electronic parts catalogue.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- The pressure tester -V.A.S 6209/2- must always be bled before it is used for the first time.
- ♦ Bleeding is not required if the pressure tester -V.A.S 6209/2still indicates a residual pressure in excess of 0.5 bar (e.g. from a previous measurement).
- Set up special tools as illustrated in order to bleed pressure gauge -B- and connecting line -A-.



Note

The illustration shows the bleeding method involving drawing in hydraulic fluid with hand vacuum pump - VAS 6213- .

- Continue bleeding until no more air bubbles are visible in hose
- Disconnect hoses -C- and -D- and perform system pressure test.





The system pressure test is carried out at the front shock absorber of the section of the DRC system that is to be tested.

- Unscrew dust cap from drain/charge valve and connect pressure tester -V.A.S 6209/2- .
- Read off system pressure at pressure tester < VAIS 6209/2-poses,

permitted unless authorised by AUDI AG. AUDI AG does not guarant



Note pect to the correctness of information in this document. Cop

The pressure at pressure tester -V.A.S 6209/2- only builds up gradually, the process takes approx. 2 minutes. Do not read off the DRC system pressure until the gauge needle of -V.A.S 6209/2- has finally come to rest.

Disconnect pressure tester -V.A.S 6209/2- and screw on dust



Note

When connecting and disconnecting pressure gauge -V.A.S 6209/2- , a small amount of fluid will always escape at the connection, but this is not critical. Repeated measurements should be avoided because the system loses a small amount of fluid every time the pressure tester -V.A.S 6209/2- is connected. The pressure reading will be about 0.3 bar lower than the previous value when the gauge is reconnected. Several repeated measurements will thus cause the pressure in the system to drop below the minimum limit, or can cause failure of the system.

If the pressure is not OK, trace the cause of the fault and repair the system.

DRC system pressure figures

These pressure figures are based on a reference temperature of 20 °C.

- 16 bar = Operating pressure
- 15 bar 16 bar = Central valve new or in as-new condition
- 14 bar 15 bar = Normal working range; system OK
- < 14 bar = System leaking or not fully charged; air trapped in system; central valve depressurised/empty.


4.8 Discharging and charging DRC system



Note


Discharging, evacuating and charging the complete DRC system (pipes/shock absorbers and central valve) is performed using the filling device for DRC system - VAS 6544- . Depending on the equipment available in your workshop for the DRC system, it may be necessary to modify/convert the existing equipment with the appropriate supplementary, upgrade or retrofit kits to meet the standard of the filling device for DRC system - VAS 6544- . The following equipment is available:

Special tools and workshop equipment required






Upgrade kit, filling device DRC system - VAS 6209/4-




- ♦ The upgrade kit, filling device DRC system VAS 6209/4- is used as an upgrade kit for the charging device for Audi RS 6 DRC system - VAS 6209- already available in the workshop.
- ♦ Retrofit kit, filling device DRC system VAS 6209/5-




- The retrofit kit, filling device DRC system VAS 6209/5- is required by workshops equipped with the central valve filler, Audi RS 4/RS 6 - VAS 6209/3- wishing to upgrade this to the technical standard of the filling device for DRC system - VAS 6544- . The supplementary kit, DRC system - VAS 6209/6must also be obtained.
- Supplementary kit, filling device DRC system VAS 6209/6-




Protected by copyright. Copying for private or commercial private permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this docum







Filling device for DRC system - VAS 6544-





Note

The equipment for the DRC system only needs to be modified once in your workshop. It is not necessary to convert the equipment back to its original condition. The further procedure for discharging and charging the entire DRC system is described for the filling device for DRC system - V.A.S 6544-.

Use only the approved type of fluid when charging and topping up the system. Please refer to ⇒ Electronic parts catalogue .

Replacement shock absorbers and pipes are supplied empty.

Charging may only be performed at room temperature (approx. 20° Celsius).

Pipes/shock absorbers and central valves may only be discharged, evacuated and charged when they are installed in the vehicle and connected.

NOTICE

- The "COMFORT" damper setting must be activated when discharging, evacuating and charging the DRC system on vehicles with variable damping.
 Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not
- ◆ To discharge, evacuate and charge the DRC system, select address word 14 in "Guided Functions" and start the function

 Charge DRC

 Vehicle diagnostic tester mation in this document. Copyright by AUDI AG.
- When this function is activated, the system switches to "COMFORT" mode and cannot be switched back manually. The yellow warning lamp in the instrument cluster lights up while the charging function is activated.

When charging the DRC system, the gas accumulator leading to the pressure chambers at the piston in the central valve is automatically checked for leaks.



CAUTION

Safety goggles must be worn for all procedures.

The valves on the workshop equipment are open when the cutoff lever is in line with the direction of flow.



Note


The valves must be kept closed for transport and storage of the filling device for DRC system - VAS 6544-.



Pipes must not be bent.

Workshop equipment required

- 1 Not required
- 2 Not required
- 3 Charging lines with quickrelease couplings in less authoris
- 4 Venturi nozzle with air outlet hose
 - ☐ From charging device for Audi RS 6 DRC system - VAS 6209-
- 5 Connecting hose
 - ☐ From charging device for Audi RS 6 DRC system - VAS 6209-
- 6 Filling device for DRC system - VAS 6544-
- 7 Used fluid container
 - Empty before starting work
 - □ Identified by red dot






Note

- Before starting to charge the DRC system, it is important to ensure that the fluid container of the filling device for DRC system - VAS 6544- and the connecting line between the pressure pump and the fluid container are filled with fluid.
- The used fluid container of the filling device for DRC system -VAS 6544- must be empty and must be drained after each extraction.


Draining used fluid container

- Unscrew the cap -arrow- on the used fluid container -1- and dispose of the used fluid.
- Screw the cap -arrow- onto the used fluid container -1-.



Filling and bleeding filling device for DRC system - VAS 6544-


Fill up fluid container -2- with fresh fluid as far as the mark and position O-ring in line with fluid level ⇒ Electronic parts catalogue .





- Close shut-off valves -A- and -C- of filling device for DRC system PrvAS 6544 copyright. Copying for private or commercial purposes, in part or in whole,
- Close needle valves Buthorised by AUDI AG. AUDI AG does not guarantee or acce

with respect to the correctness of information in this document. (







Connect hose -2- to used fluid container -arrow- and quickrelease coupling -4- of filling device for DRC system - VAS 6544-.




Protected by copyright. Copying for private or commercial purposes, in part or permitted unless authorised by AUDI AG. AUDI AG does not guarant with respect to the correctness of information in this document. Co



- Connect venturi nozzle -3- with air outlet hose to used fluid container -arrow- as shown in illustration.
- Connect compressed air line to venturi nozzle -3-.



- Open shut-off valve -C-.




- Open shut-off valve -A- briefly (for about 1-2 seconds) until line -1- between fluid tank -2- and pressure pump is filled with bubble-free fluid.
- Close shut-off valve -C-. Disconnect compressed air line from venturi nozzle.

Discharging/evacuating

NOTICE

- The "COMFORT" damper setting must be activated when discharging, evacuating and charging the DRC system on vehicles with variable damping.
- To discharge, evacuate and charge the DRC system, select address word 14 in "Guided Functions" and start the function **Charge DRC** ⇒ Vehicle diagnostic tester.
- When this function is activated, the system switches to "COMFORT" mode and cannot be switched back manually. The yellow warning lamp in the instrument cluster lights up while the charging function is activated.



CAUTION

Safety goggles must be worn for all procedures.

- On vehicles with variable damping, select address word 14 in "Guided Functions" and start the function Charge DRC ⇒ Vehicle diagnostic tester.
- Turn the front wheel outwards on the side to be discharged.




The DRC system comprises two separate hydraulic systems. The central valves are connected diagonally in relation to the corresponding shock absorbers.

Discharge DRC system as follows:


Central valve	Shock absorber
1 - left-side	Front left/rear right
2 - right-side	Front right/rear left

- Unscrew dust cap from drain/charge valve (front).
- Connect charging line with quick-release coupling -1- of filling device for DRC system - VAS 6544- ⇒ Item 3 (page 321) to drain/charge valve (front) on the pipe connection to be discharged.
- Remove the rear wheel on the side of the pipe connection to **be**p**discharged.**Copyright. Copying for private or commercial purposes
- Move clear wheel housing liner at drain/charge valve (rear).
- Unscrew dust cap from drain/charge valve (rear) this document. Co






Connect charging line with quick-release coupling -1- of filling device for DRC system - VAS 6544- ⇒ Item 3 (page 321) to drain/charge valve (rear) on the pipe connection to be discharged.




Connect charging lines ⇒ Item 3 (page 321) to connections -A- and -B- of the filling device for DRC system - VAS 6544- .



Shut-off valves -A- and -C- of filling device for DRC system - VAS 6544- closed.

Needle valve -B- closed.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Hose -2- connected to used fluid container -arrow- and to filling device for DRC system - VAS 6544- -4-.






Venturi nozzle -3- with air outlet hose connected to used fluid container -arrow- of filling device for DRC system - VAS 6544-

Compressed air connected to venturi nozzle -3- does not guarantee or

with respect to the correctness of information in this document. Copyrigh





- Open valve -C- until fluid is discharged from DRC system down to the smallest possible remainder. (This is visible at return hose -2- going to used fluid container).
- At a pressure gauge reading of approximinus 0.9 bar; close ercial valve -C- and disconnect compressed air line from venturi nozzle.
- Check for leakage pect to the correctness of information in this docu



Note

Vacuum must be maintained stable at minus 0.9 bar for at least 2 minutes.

Check fluid level in fluid container, fill up fluid container with fresh fluid as far as the mark (if necessary) and position O-ring in line with fluid level ⇒ Electronic parts catalogue.



The "COMFORT" damper setting must be activated when discharging, evacuating and charging the DRC system on vehicles with variable damping.

Charging



Note


The DRC system comprises two separate hydraulic systems. The central valves are connected diagonally in relation to the corresponding shock absorbers.

Charge DRC system as follows:

Central valve	Shock absorber
1 - left-side	Front left/rear right
2 - right-side	Front right/rear left

NOTICE

- The "COMFORT" damper setting must be activated when discharging, evacuating and charging the DRC system on vehicles with variable damping.
- To discharge, evacuate and charge the DRC system, select address word 14 in "Guided Functions" and start the function Charge DRC ⇒ Vehicle diagnostic tester.
- When this function is activated, the system switches to "COMFORT" mode and cannot be switched back manually. The yellow warning lamp in the instrument cluster lights up while the charging function is activated.





Open needle valve -B- about two turns, allowing fluid to be drawn out of fluid container of filling device for DRC system -VAS 6544- and into evacuated DRC system.

The fluid will flow out of the fluid container and into the connected DRC system. This can be seen from the dropping fluid level in the fluid container. This process may take several minutes, depending on the quantity of fluid remaining after discharging. The rate at which the fluid level drops decreases as system charging progresses. When the fluid level stops dropping, the first step in the charging process is complete.

- Close needle valve -B-.
- Open valve -A- and charge DRC system to 22 bar by repeatedly pumping lever of hand-operated pump -1-.



Note

Make sure the fluid container of the filling device for DRC system - VAS 6544- does not run empty when charging. Top up the fluid container with fresh fluid if necessary ed by AUDI AG. AUDI AG does no

When a pressure of 22 bar has been reached, close valve -A- and stop pumping lever of hand-operated pump.



Note

- The quality of the filling process is not improved if the maximum pressure of 22 bar is exceeded. Caution: this can damage the DRC system components and filling device for DRC system - VAS 6544-!
- If the pressure of 22 bar cannot be reached, or if the pressure drops continuously, check all the separating couplings and connections for leaks and damage. If no irregularities are visible on the outside, the piston of the gas accumulator inside the central valve leading to the pressure chambers is leaking, so the central valve must be renewed.
- Open needle valve -B- slightly and allow pressure to drop to 16 bar.
- When needle on pressure gauge reaches 16 bar mark, close valve -B-.





Note

On some versions of the pressure gauge, the 16 bar graduation has a green marking. This marking is irrelevant to the application described here and must be ignored.

DRC system is charged.

- Disconnect charging line with quick-release coupling of filling device for DRC system - VAS 6544- ⇒ Item 3 (page 321) from drain/charge valves (front and rear).
- Fit rear wheel.
- Screw on dust cap for drain/charge valves (front and rear).
- On vehicles with variable damping, exit function Charge DRC on ⇒ Vehicle diagnostic tester.







Wheels, tyres, vehicle geometry

Wheels, tyres

This information is contained in the Workshop Manual on Wheels and tyres ⇒ Wheels and tyres; Rep. gr. 44; Fitting wheels / tyres / Tyre Pressure Monitoring System / Tyre Pressure Loss Indicator.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



2 Wheel alignment

- ⇒ "2.1 Notes on wheel alignment", page 330
- ⇒ "2.2 Test requirements", page 331
- ⇒ "2.3 Preparations for measurement", page 332
- ⇒ "2.4 Wheel alignment specifications", page 334
- ⇒ "2.5 Wheel alignment procedure", page 343
- ⇒ "2.6 When does wheel alignment have to be checked?", page 344
- ⇒ "2.7 Explanatory notes on production control numbers (PR numbers)", page 345
- ⇒ "2.8 Adjusting camber at front wheels", page 346
- ⇒ "2.9 Adjusting camber at rear wheels", page 349
- ⇒ "2.10 Adjusting toe setting at rear wheels", page 349
- ⇒ "2.11 Adjusting toe setting at front wheels", page 350
- ⇒ "2.12 Wheel runout compensation", page 350
- ⇒ "2.13 Checking full steering lock", page 350
- ⇒ "2.14 Checking reference position for wheel alignment (vehicles with air suspension)", page 351

2.1 Notes on wheel alignment

Wheel alignment must always be performed using wheel alignment equipment approved by VW/Audi.

The alignment check must always include both the front and the purposes, in part or in whole, is not rear axles.

This is important to achieve proper handling and road behaviour.

with respect to the correctness of information in this document. Copyright by AUDI AG.



Note

- ♦ To allow running gear to fully settle, wheel alignment should not be checked before the vehicle has completed 1000 to 2000 km.
- When making adjustments, try to obtain the specified settings as accurately as possible.

Before checking the wheel alignment on vehicles with air suspension, the reference position/unladen position must be checked and, if necessary, re-adapted ⇒ page 351.



If adjustments are made to the suspension geometry, the steering angle sender - G85- must be calibrated on vehicles with ESP or ABS \Rightarrow Vehicle diagnostic tester.



CAUTION

Risk of damage to running gear components.

Never place the vehicle on its wheels if the subframe mounting steering rack or subframe cross brace is not correctly installed!

The vehicle must not be supported on the subframe or the subframe cross brace (e.g. using a trolley jack or similar)!



CAUTION

All bolts and nuts must be fully tightened according to specifications before the vehicle is driven on public roads.



WARNING

Risk of injury due to automatic engine start on vehicles with start/stop system.

- On vehicles with activated start/stop system (indicated by a message in the instrument cluster), the engine may start automatically if it needs to.
- Therefore it is important to ensure that the start/stop system is deactivated when performing repairs (switch off ignition, if required switch on ignition again).

Test requirements

Please refer to general information on wheel alignment

Prote → Page 330 right. Copying for private or commercial purposes, in part or in whole, is not

permitte Allow the wehicle to cool down. AUDI AG does not guarantee or accept any liability

- with resp**Check suspension, steering and steering linkage for excessive** t by AUDI AG. play or damage and service if necessary.
 - Tread depth difference of no more than 2 mm on one axle.
 - Tyres inflated to correct pressures.
 - Vehicle accurately aligned, suspension bounced and rocked several times.
 - Drive vehicle onto wheel alignment unit and ensure that suspension is not under stress, if necessary by moving vehicle backwards and forwards several times.
 - Before starting the initial measurement and before making any adjustments, make sure that the steering is returned correctly to the centre position by turning the steering wheel uniformly in both directions using the steering wheel balance - VAS 6458- .
 - Vehicle with coil springs in unladen condition. "Unladen" means: ready for the road (full tank, full windscreen washer/ headlight washer fluid reservoir, spare wheel, vehicle tool kit and jack) but without driver.
 - Vehicle with air suspension in reference position (i.e. at specified height with vehicle ready for the road but without driver ⇒ page 351).
 - Ensure that the sliding plates and turntables are not touching the end stop when checking the alignment.
 - Sensors must be properly attached and adjusted; refer to operating instructions of equipment manufacturer.
 - Perform compensation of wheel rim runout: A certain amount of axial runout at the wheel rims is permissible, but this may



already exceed the specified toe-in tolerance. In such cases it is not possible to set the toe-in correctly without first compensating for the wheel runout.

- Wheel alignment platforms and computer measuring equipment can lose their original levelling setting and calibration over a period of time, and they should therefore be serviced and calibrated at least once a year.
- Precision equipment should be treated with appropriate care.
- If necessary, contact the manufacturer for familiarisation with the proper use of the wheel alignment equipment.

Preparations for measurement 2.3

⇒ "2.3.1 Preparations required before calibration/adjustment of driver assist systems", page 332

⇒ "2.3.2 Preparations for measurement", page 332

rivate or commercial purposes, in part or in whole, is not

Preparations required before calibra-2.3.1 tion/adjustment of driver assist systems n this document. Copyright by AUDI AG.

The following steps are required if one or more driver assist systems on the vehicle are to be calibrated or adjusted via the "Quickstart" procedure (i.e. without first checking and adjusting the wheel alignment):


- Before driving the vehicle onto the alignment platform, make sure there is sufficient space between the vehicle and the setting device. The distance between the setting device and the vehicle must be 120 cm ± 2.5 cm.
- If the available space is not adequate, drive the vehicle backwards onto the alignment platform as required.
- Before commencing calibration/adjustment, interrogate event memory and rectify any faults.
- Vehicle accurately aligned, suspension bounced and rocked several times.
- Ensure that the sliding plates and turntables are not touching the end stop when checking the alignment.
- Activate Wheel change mode: see instructions in ⇒ Owner's Manual.
- Connect battery charger ⇒ Electrical system; Rep. gr. 27; Battery; Charging battery .
- Bring front wheels into straight-ahead position.
- Connect up vehicle diagnostic tester to vehicle and run diagnostic cable out through open window.
- Exterior lighting switched off.
- All vehicle doors closed.
- Press button to select required calibration/adjustment on wheel alignment computer.

2.3.2 Preparations for measurement


Special tools and workshop equipment required



Brake pedal actuator - V.A.G 1869/2-



Steering wheel balance - VAS 6458-



- ◆ For vehicles with air suspension: vehicle diagnostic tester
- Wheel alignment computer approved by VW/Audi

Requirements

- Sensors must be properly attached and adjusted; refer to operating instructions of equipment manufacturer.
- Ensure that the sliding plates and turntables are not touching the end stop when checking the alignment.
- Drive vehicle onto wheel alignment unit and ensure that suspension is not under stress, if necessary by moving vehicle backwards and forwards several times.
- Before starting the initial measurement and before making any adjustments, make sure that the steering is returned correctly to the centre position by turning the steering wheel uniformly in both directions using the steering wheel balance - VAS 6458-.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



2.4 Wheel alignment specifications

- ⇒ "2.4.1 Wheel alignment specifications, Sportback (front axle)", page 334
- ⇒ "2.4.2 Wheel alignment specifications, Sportback (rear axle)", page 335
- ⇒ "2.4.3 Wheel alignment specifications, Saloon/Avant (front

axle)", page 336

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

⇒ "2.4.4 Wheel alignment specifications, saloon/Avant (rear AG. AUDI AG does not guarantee or accept any liability axle)", page 339

with respect to the correctness of information in this document. Copyright by AUDI AG.

⇒ "2.4.5 Calculating front camber setting on right-hand drive saloon/Avant vehicles", page 340

⇒ "2.4.6 Calculating front camber setting on right-hand drive Sportback vehicles", page 342

2.4.1 Wheel alignment specifications, Sport-back (front axle)



Note

These specifications are applicable for all engines.

	Front-wheel drive / four-wheel drive				
	Standard running gear 1BA	Heavy-duty run- ning gear 1BB	Sports running gear 1BE/1BV	Air suspension, standard running gear 1BK	
Distance between centre of wheel and bottom edge of wing	396 mm ± 10 mm	406 mm ± 10 mm	1BE: 386 mm ± 10 mm 1BV: 385 mm ± 10 mm	386 mm ± 10 mm	
Camber 1)	- 53' ± 23'	- 43' ± 23'	- 1° 5′ ± 23′	- 1° 5′ ± 23′	
Maximum permissible difference between left and right	30′	30′	30′	30′	
Toe setting for each wheel (specification when making adjustment)	+ 10 ± 5′	+ 10 ± 5′	+ 10 ± 5′	+ 10 ± 5′	
Toe setting for each wheel (specification when checking adjustment)	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′	
Toe-out on turns at 20° 2)	1° 49′ ± 30′	1° 49′ ± 30′	1° 49′ ± 30′	1° 49′ ± 30′	
Outer wheel steering angle at full lock	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	
Inner wheel steering angle at full lock	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	

¹⁾ On right-hand drive vehicles, the camber setting must be calculated as a function of the distance between the centre of the wheel and the bottom edge of the wing ⇒ page 342.

²⁾ The wheel on the outside of a curve is turned in less than the inside wheel. This value shows the difference in the steering angles. It may be displayed as a negative value on the wheel alignment computer, depending on the manufacturer.



	Front-wheel drive / four-wheel drive				
	Air suspension, heavy-duty run- ning gear 1BS	Air suspension, RS running gear 2MA	Air suspension, sports running gear 2MB	RS running gear 2MC	
Distance between centre of wheel and bottom edge of wing	391 mm ± 10 mm	386 mm ± 10 mm	386 mm ± 10 mm	391 mm ± 10 mm	
Camber ¹⁾	- 59' ± 23'	-1° 8′ ± 23′	-1° 5′ ± 23′	-1° 2′ ± 23′	
Maximum permissible difference between left and right	30′	30′	30′	30′	
Toe setting for each wheel (specification when making adjustment)	+ 10 ± 5′	+ 10 ± 5′	+ 10 ± 5′	+ 10 ± 5′	
Toe setting for each wheel (specification when checking adjustment)	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′	
Toe-out on turns atect 20° 2)	ed by 1c49 /r±j 30 /Copy	ring fbr 49 (v±t 30 /r co	nme 1 °i 49 ½± 30 ses, i G does not guarante	n par 1.ºo49 h ± v 30 (e, is	
Outer wheel steering angle at full lock	33° 24′ + 1° 30′ pect to the 2° rectne	33° 24′ + 1° 30′ ss of inform2tion in	33° 24′ + 1° 30′ this docume2t. Copy	33° 24′ + 1° 30' right by AUD2•AG.	
Inner wheel steering angle at full lock	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	

¹⁾ On right-hand drive vehicles, the camber setting must be calculated as a function of the distance between the centre of the wheel and the bottom edge of the wing \Rightarrow page 342.

Additional data for vehicles with front-wheel drive and four-wheel drive:

The additional data listed here are intended only to facilitate diagnosis after an accident.

Table ⇒ page 20

2.4.2 Wheel alignment specifications, Sportback (rear axle)



Note

These specifications are applicable for all engines.

	Front-wheel drive / four-wheel drive			
	Suspension with steel springs (all running gear versions)	Air suspension (all running gear versions)		
Camber	- 1°20′ ± 25′	- 1°20′ ± 25′		

²⁾ The wheel on the outside of a curve is turned in less than the inside wheel. This value shows the difference in the steering angles. It may be displayed as a negative value on the wheel alignment computer, depending on the manufacturer.



		Front-wheel drive / four-wheel drive				
	Suspension with steel springs (all running gear versions)	Air suspension (all running gear versions)				
Maximum permissible difference between left and right	30′	30′				
Toe setting for each wheel	+ 10 ± 5′	+ 10 ± 5′				
Total toe	+ 20 ± 10′	+ 20 ± 10'				
Maximum permissible deviation in direction of travel relative to longitudinal axis of vehicle		10′				

Additional data for vehicles with front-wheel drive and four-wheel

The additional data listed here are intended only to facilitate diagnosis after an accident.

Table <u>⇒ page 20</u>

Wheel alignment specifications, Saloon/ 2.4.3 Avant (front axle)



Note

These specifications are applicable for all engines.

		Front-wheel drive / four-wheel drive				
	Standard running gear 1BA / 1BH	Heavy-duty run- ning gear (China) 1BB	Sports running gear 1BE	hybrid 1BE		
Distance between centre of wheel and bottom edge of wing	404 mm ± 10 mm	404 mm ± 10 mm	384 mm ± 10 mm	384 mm ± 10 mm		
Camber 1)	- 43' ± 23'	- 43′ ± 23′	- 1° 5′ ± 23′	- 1° 8′ ± 23′		
Maximum permissible	30′	30′	30′	30′		
difference between left and right	by copyright. Copyin	g for private or comn	nercial purposes, in p	art or in whole, is not		
Toe setting for each wheel (specification when making adjustment)	unles <u>s</u> <u>Nothos</u> ised by ct to the correctness		loes n <u>o</u> t <u>fou</u> <u>ar</u> s ntee o s document. Copyrig			
Toe setting for each wheel (specification when checking adjustment)	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′		
Toe-out on turns at 20° 2)	1° 49′ ± 30′	1° 49′ ± 30′	1° 49′ ± 30′	1° 49′ ± 30′		
Outer wheel steering angle at full lock	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°		
Inner wheel steering angle at full lock	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°		



- 1) On right-hand drive vehicles, the camber setting must be calculated as a function of the distance between the centre of the wheel and the bottom edge of the wing ⇒ page 340.
- 2) The wheel on the outside of a curve is turned in less than the inside wheel. This value shows the difference in the steering angles. It may be displayed as a negative value on the wheel alignment computer, depending on the manufacturer. permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability

with respect to the correctness of information in this document. Conveight by AUDI AC

with respe	ct to the correctness			ht by AUDI AG.	
	Front-wheel drive / four-wheel drive				
	Air suspension, standard running gear 1BK	Heavy-duty run- ning gear 1BR	Air suspension, heavy-duty run- ning gear 1BR (VW511CS China)	Air suspension, heavy-duty run- ning gear 1BS	
Distance between centre of wheel and bottom edge of wing	384 mm ± 10 mm	417 mm ± 10 mm	417 mm ± 10 mm	389 mm ± 10 mm	
Camber 1)	- 1° 5′ ± 23′	- 30′ ± 23′	- 34' ± 23'	- 59' ± 23'	
Maximum permissible difference between left and right	30′	30′	30′	30′	
Toe setting for each wheel (specification when making adjustment)	+ 10 ± 5′	+ 10 ± 5′	+ 10 ± 5′	+ 10 ± 5′	
Toe setting for each wheel (specification when checking adjustment)	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′		
Toe-out on turns at 20° 2)	1° 49′ ± 30′	1° 49′ ± 30′	1° 49′ ± 30′	1° 49′ ± 30′	
Outer wheel steering angle at full lock	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	
Inner wheel steering angle at full lock	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36' + 1° 30' - 2°	

¹⁾ On right-hand drive vehicles, the camber setting must be calculated as a function of the distance between the centre of the wheel and the bottom edge of the wing ⇒ page 340.

²⁾ The wheel on the outside of a curve is turned in less than the inside wheel. This value shows the difference in the steering angles. It may be displayed as a negative value on the wheel alignment computer, depending on the manufacturer.

		Front-wheel drive / four-wheel drive				
	Air suspension, heavy-duty run- ning gear (China) 1BS	Sports running gear (S line) 1BV	Air suspension, allroad 1BY	Air suspension, RS running gear 2MA		
Distance between centre of wheel and bottom edge of wing	389 mm ± 10 mm	374 mm ± 10 mm	393 mm ± 10 mm	384 mm ± 10 mm		
Camber 1)	- 1° 23′ ± 23′	- 1° 20′ ± 23′	- 57' ± 23'	-1° 8′ ± 23′		
Max. permissible camber difference betw. right & left sides of vehicle	30′	30′	30′	30′		



	Front-wheel drive / four-wheel drive			
	Air suspension, heavy-duty run- ning gear (China) 1BS	Sports running gear (S line) 1BV	Air suspension, allroad 1BY	Air suspension, RS running gear 2MA
Toe setting for each wheel (specification when making adjustment)	+ 10 ± 5′	+ 10 ± 5′	+ 10 ± 5′	+ 10 ± 5′
Toe setting for each wheel (specification when checking adjustment)	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′	+ 10 ± 7′
Toe-out on turns at 20° 2)	1° 49′ ± 30′	1° 49′ ± 30′	1° 49′ ± 30′	1° 49′ ± 30′
Outer wheel steering angle at full lock	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°
Inner wheel steering angle at full lock	39° 36′ + 1° 30' - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°

¹⁾ On right-hand drive vehicles, the camber setting must be calculated as a function of the distance between the centre of the wheel and the bottom edge of the wing \Rightarrow page 340.

Additional data for vehicles with front-wheel drive and four-wheel

The additional data listed here are intended only to facilitate diagnosis after an accident.

Table ⇒ page 20

	Front-wheel drive / four-wheel drive				
Protected by copyrigi		RS running gear 2MC e or commercial pur	poses, in part or in w	hole, is not	
permitted unless aut			arantee or accept an		
Distance between centre of wheel and bottom edge of wing	384 mm ±19 mm	:389:mm:±.10.mm:	t. Copyright by AUD:	AG.	
Camber 1)	-1° 5′ ± 23′	-1° 2′ ± 23′			
Max. permissible camber difference betw. right & left sides of vehicle	30′	30′			
Toe setting for each wheel (specification when making adjustment)	+ 10 ± 5′	+ 10 ± 5′			
Toe setting for each wheel (specification when checking adjustment)	+ 10 ± 7′	+ 10 ± 7′			
Toe-out on turns at 20° 2)	1° 49′ ± 30′	1° 49′ ± 30′			

²⁾ The wheel on the outside of a curve is turned in less than the inside wheel. This value shows the difference in the steering angles. It may be displayed as a negative value on the wheel alignment computer, depending on the manufacturer.



	Front-wheel drive / four-wheel drive			
	Air suspension, sports running gear 2MB	RS running gear 2MC		
Outer wheel steering angle at full lock	33° 24′ + 1° 30′ - 2°	33° 24′ + 1° 30′ - 2°		
Inner wheel steering angle at full lock	39° 36′ + 1° 30′ - 2°	39° 36′ + 1° 30′ - 2°		

¹⁾ On right-hand drive vehicles, the camber setting must be calculated as a function of the distance between the centre of the wheel and the bottom edge of the wing ⇒ page 340.

244 Wheel alignment specifications, saloon/ Avant (rear axle)



Note

These specifications are applicable for all engines.

	Front-wheel drive / four-wheel drive						
	Suspension with steel springs (all running gear versions)	Air suspension (all running gear versions)					
Camber	- 1°20′ ± 25′	- 1°20′ ± 25′					
Maximum permissi- ble difference be- tween left and right	30′	30′					
Toe setting for each wheel	+ 10 ± 5′	+ 10 ± 5′					
Total toe	+ 20 ± 10′	+ 20 ± 10'					
Maximum permissi- ble deviation in direc- tion of travel relative to longitudinal axis of vehicle		10′					

Additional data for vehicles with front-wheel drive and four-wheel drive:

Protected by copyright. Copying for private or com The additional data listed here are intended only to facilitate dimmercial purposes, in part or in whole, is not agnosis after an accident unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

Table ⇒ page 20 ith respect to the correctness of information in this document. Copyright by AUDI AG.

²⁾ The wheel on the outside of a curve is turned in less than the inside wheel. This value shows the difference in the steering angles. It may be displayed as a negative value on the wheel alignment computer, depending on the manufacturer.

2.4.5 Calculating front camber setting on right-hand drive saloon/Avant vehicles

On right-hand drive Audi saloon/Avant vehicles, the camber setting at the front wheels must be calculated as a function of the distance between the centre of the wheel and the bottom edge of the wing.

- Measure distance -a- at both front wheels between centre of wheel and bottom edge of wing panel and note it down.
- Maximum permissible difference between distance on right and left ≤ 10 mm
- Running gear 1BA / 1BH / 1BB: specified distance 404 mm / specified camber -43'
- Running gear 1BE: specified distance 384 mm / specified camber -1°5'
- Running gear 1BE hybrid: specified distance 384 mm / specified camber -1°8'
- Running gear 1BK: specified distance 384 mm / specified camber -1°5'
- Running gear 1BR: specified distance 417 mm / specified camber -30'
- Running gear 1BR (VW511CS China): specified distance 417 mm / specified camber -34'
- Running gear 1BS: specified distance 389 mm / specified camber -59'
- ♦ Running gear 1BS (VW511CS China): specified distance 389 purposes, in part or in whole, is not mm / specified camber -1°3'
- Permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability Running gear 1BV: specified distance 374 mm / specified camberi ≥ 1°20 pect to the correctness of information in this document. Copyright by AUDI AG.
- Running gear 1BY: specified distance 393 mm / specified camber -57'
- Running gear 2MA: specified distance 384 mm / specified camber -1°8'
- Running gear 2MB: specified distance 384 mm / specified camber -1°5'
- Running gear 2MC: specified distance 389 mm / specified camber -1°2'

Example: calculating camber for running gear 1BA:


Camber = specified camber + [(measured distance -a- on left side + measured distance -a- on right side) ÷ 2 - specified distance]

Camber = -43' + [(measured distance -a- on left side + measured distance -a- on right side) ÷ 2 - 404 mm]



Note

1' camber = 1 mm vehicle height





Example: the following table shows the front axle camber for running gear 1BA as a function of the mean distance -a- of the left and right sides.



Note

Mean distance -a- of left and right side = (measured distance -aon left side + measured distance -a- on right side) ÷ 2

F	Front camber on right-hand drive saloon/Avant vehicles with running gear 1BA								
Distance betwe	een centre of wh edge of wing	eel and bottom		Maximum permissible					
Trend	Mean dis- tance -a- of left and right side	Mean delta in rel. to speci- fied distance in mm	Camber (value for checking/adjusting)	Tolerance	Max. permissible camber difference betw. right & left sides of vehicle	difference be- tween dis- tance on right and left			
Too high	414	10	-33′	± 23′	30′	≤ 10 mm			
	413	9	-34′						
	412	8	-35′						
	411	7	-36′						
	410	6	-37′						
	409	5	-38′						
	408	4	-39′						
	407	3	-40′						
	406	2	-41′						
	405	1	-42′						
Spec.	404	0	-43′						
Too low	403	-1	-44′						
	402	-2	-45′						
	401	-3	-46′						
	400	-4	-47′						
	399	-5	-48′						
	398	-6	-49′						
	397	-7	-50′						
	396	-8	-51′						
	395	-9	-52′						
	394	-10	-53′						



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

am

2.4.6 Calculating front camber setting on right-hand drive Sportback vehicles

On right-hand drive Audi Sportback vehicles, the camber setting at the front wheels must be calculated as a function of the distance between the centre of the wheel and the bottom edge of the wing.

- Measure distance -a- at both front wheels between centre of wheel and bottom edge of wing panel and note it down.
- Maximum permissible difference between distance on right and left ≤ 10 mm
- Running gear 1BA: specified distance 396 mm / specified camber -53'
- Running gear 1BB: specified distance 406 mm / specified camber -43'
- Running gear 1BE: specified distance 386 mm / specified camber -1°5'
- Running gear 1BV: specified distance 385 mm / specified camber -1°5'
- Running gear 1BK: specified distance 386 mm / specified camber -1°5'
- Running gear 1BS: specified distance 391 mm / specified camber -59'
- Running gear 1BY: specified distance 393 mm / specified camber -57'
- Running gear 2MA: specified distance 386 mm / specified camber -1°8'
- Running gear 2MB: specified distance 386 mm / specified camber -1°5'
- Running gear 2MC: specified distance 391 mm / specified camber -1°2'

Example: calculating camber for running gear 1BA:

Camber = specified camber + [(measured distance -a- on left side + measured distance -a- on right side) ÷ 2 - specified distance]

Camber = -53' + [(measured distance -a- on left side + measured distance -a- on right side) ÷ 2 - 396 mm]



Note


1' camber = 1 mm vehicle height

Example: the following table shows the front axle camber for running gear 1BA as a function of the mean distance -a- of the left and right sides.



Mean distance -a- of left and right side = (measured distance -a- opyright by AUDI AG. on left side + measured distance -a- on right side) ÷ 2

Front camber on right-hand drive Sportback vehicles with running gear 1BA						
Distance between centre of wheel and bottom edge of wing		Maximum permissible difference be- tween dis-				





[Front camber on right-hand drive Sportback vehicles with running gear 1BA									
	Trend	Mean dis- tance -a- of left and right side	Mean delta in rel. to speci- fied distance in mm	Camber (value for checking/adjusting)	Tolerance	Max. permissible camber difference betw. right & left sides of vehicle	tance on right and left			
	Too high	406	10	-43′	± 23′	30′	≤ 10 mm			
	0	405	9	-44′						
		404	8	-45′						
		403	7	-46′						
Prote	cted by copyrigh	402	6	-47'	n part or in whol	e. is not				
- 1	tted unless auth	401	5	-48'	or accept any li					
· I	espect to the co	400	AG. AUDI AG do	-49'	right by AUDI AC	_				
WILLI	espect to the co	rrectnass of into	rmation in this i	document, Copy -50', Copy	ight by AUDI AC	1.				
		398	2	-51′						
		397	1	-52′						
	Spec.	396	0	-53′						
	Too low	395	-1	-54′						
		394	-2	-55′						
		393	-3	-56′						
		392	-4	-57′						
		391	-5	-58′						
		390	-6	-59′						
		389	-7	-60′						
		388	-8	-61′						
		387	-9	-62′						
		386	-10	-63′						

2.5 Wheel alignment procedure



Note

- The vehicle must always be at the reference position/unladen position when measuring wheel alignment ⇒ page 331.
- Check which running gear version is fitted in vehicle. This information is listed on the vehicle data sticker ⇒ page 345.

Always keep to the following sequence of operations.

- Drive vehicle onto wheel alignment unit and ensure that suspension is not under stress, if necessary by moving vehicle backwards and forwards several times.
- Before starting the initial measurement and before making any adjustments, make sure that the steering is returned correctly to the centre position by turning the steering wheel uniformly in both directions using the steering wheel balance - VAS 6458- .
- Carry out wheel rim runout compensation ⇒ page 350.
- Check full steering lock ⇒ page 350.



- Check camber at rear wheels and adjust if necessary ⇒ page 349 .
- 6 Check toe setting at rear wheels and adjust if necessary
 ⇒ page 349
- 7 Check camber at front wheels and centralise if necessary
 ⇒ page 346
- 8 Check toe setting at front wheels and adjust if necessary
 ⇒ page 350 .



Note

If suspension settings have been changed, perform zero compensation of steering angle sender - G85- using ⇒ Vehicle diagnostic tester.

If changes have been made to front and/or rear axle settings:

- Basic setting for dynamic steering must be performed for vehicles with dynamic steering ⇒ page 355.
- Adjust headlights ⇒ Electrical system; Rep. gr. 94; Headlights; Adjusting headlights.

If the rear wheel alignment settings have been changed, the foll purposes, in part or in whole, is not lowing tasks must be performed:

Definition unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- On vehicles with ACC, sensors for adaptive cruise control
 must be adjusted page 358
- On vehicles with lane departure warning system, lane departure warning function must be recalibrated ⇒ page 365
- On vehicles with night vision system, night vision system must be adjusted or calibrated ⇒ page 371
- On vehicles with reversing camera system, reversing camera system must be calibrated ⇒ Communication; Rep. gr. 91; Reversing camera system; Calibrating reversing camera system

2.6 When does wheel alignment have to be checked?

- In the event of handling problems
- Following accident damage
- If suspension components have been removed or renewed.
- If tyres are worn unevenly.

Front suspension component renewed:	Wheel alignment check required				lignment equired
	Yes	No		Yes	No
Upper link (rear)		Х	Shock absorbers		Х
Upper link (front)		Х	Upper transverse links	Х	
Guide link (bottom)		Х	Lower transverse links	Х	
Track control link (bottom)		Х	Bonded rubber bush		Х
Swivel joint		Х			
Air spring strut, coil spring/ shock absorber		Х	Air spring/coil spring		Х
Shock absorber fork		Х			
Wheel bearing housing		Х	Wheel bearing housing	Х	
Track rod	Х		Track rod	Х	



Front suspension component renewed:	Wheel alignment check required		Rear suspension compo- nent renewed:		Wheel alignment check required	
	Yes	No		Yes	No	
Track rod ball joint	Х					
Steering rack ted by copyrigh			ommercial purposes, in part o	r in whole, is	not	
Subframe mitted unless auth	l		Subframe et guarantee or acc	ept a xy)liabil	ity	
Anti-roll bar respect to the co	rrectness of	nforn x ation	Anti-roll banent. Copyright b	/ AUDI AG.	Х	
Coupling rod		Х	Coupling rod		Х	

¹⁾ A wheel alignment check may still be required, even if the position of the subframe has been fixed using locating pins - T40242- ⇒ page 141 : perform a road test.

2.7 Explanatory notes on production control numbers (PR numbers)

The PR no. on the vehicle data sticker indicates the type of running gear (for front axle and rear axle) and which version of the Tyre Pressure Monitoring System / Tyre Pressure Loss Indicator is fitted in the vehicle.


The vehicle data sticker can be found in the spare wheel well and in the Service Schedule.

Front axle/rear axle

The PR nos. for the front axle and rear axle are shown in the illustration: -A- and -B-.

- -A- indicates front axle PR no.
- -B- indicates rear axle PR no.

The PR numbers can be used to identify the correct shock absorber combination in the ⇒ Electronic parts catalogue.



Running gear versions

The PR no. for the different running gear versions is indicated by the -arrow- in the illustration.

In this example the vehicle is fitted with standard running gear, version 1BK.

1BA/1BH = Standard running gear

1BE = Sports running gear

1BB/1BR = Heavy-duty running gear

1BK = Standard running gear, air suspension

1BS = Heavy-duty running gear, air suspension

1BV = Sports running gear (S line)

1BY = allroad Protected by copyright. Copying for private or commercial pur

2MA = RS running gear, air suspension

2MB = Sports running gear, air suspension

2MC = RS running gear

Tyre Pressure Monitoring System/ Tyre Pressure Loss Indicator

The PR no. for the Tyre Pressure Monitoring System / Tyre Pressure Loss Indicator can be found in ELSA in the ⇒ Vehicle-specific notes in the document "Vehicle data".

7K0 = Not equipped with Tyre Pressure Monitoring System

7K6 = Tyre Pressure Loss Indicator

7K8 = Tyre Pressure Monitoring System, frequency 315 MHz Basic

Driver assist systems

The PR nos. for the driver assist systems can be found in ELSA in the ⇒ Vehicle-specific notes in the document "Vehicle data".

1N7, 1N8 = Dynamic steering

7Y2 = Lane departure warning

7Y3 = Lane change assist plus lane departure warning

7Y4 = Lane departure warning (Heading Control Assist)

8T4 = Adaptive cruise control (ACC)


8T5 = Adaptive cruise control with additional features

9R1 = Night vision system

2.8 Adjusting camber at front wheels


The camber cannot be adjusted.

By moving the subframe, it is possible to centralise the camber setting symmetrically within the specified tolerance range.





- Remove noise insulation panels -1- and -2- ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation.
- If fitted, remove front longitudinal members (bottom) on both sides ⇒ General body repairs, exterior; Rep. gr. 63; Bumper (front); Exploded view - impact bar .
- Remove wheel spoilers (both sides) ⇒ General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Exploded view wheel housing liner (front).
- Detach inner sections of wheel housing liners on both sides and press outwards ⇒ General body repairs, exterior; Rep. gr. 66; Wheel housing liners; Removing and installing wheel housing liner (front) .
- Remove heat shield (top section) ⇒ page 52.




CAUTION

Accident risk if subframe is detached

- Do not unscrew subframe bolts completely!
- Slacken subframe boltsy-1cto/6-(left and right) by two turns innercia several stages and in diagonal sequence.

with respect to the correctness of information in this do




 Loosen bolts -arrows- securing tunnel cross member ⇒ Rep. gr. 34 ; Assembly mountings; Exploded view - assembly mountings or ⇒ Rep. gr. 37 ; Assembly mountings; Exploded view - assembly mountings .



Note

When moving the subframe (in order to centralise the camber setting), the vehicle must be raised at the front by positioning the axle lift under the jacking points for the lifting platform.



- Use plastic-coated tyre iron to move subframe (with engine mountings and anti-roll bar) to required position -arrows-.
- Position tool in centre of subframe near track control link and apply pressure between subframe and longitudinal member on body.

If no plastic-coated tyre iron is available, wrap adhesive tape around a conventional tyre iron.

Before checking the camber values, the vehicle must be bounced several times at the front axle.





CAUTION

Take care not to damage any components.

Wheel alignment specifications ⇒ page 334

- Remove subframe bolts one after the other and replace with new bolts.
- Initially tighten bolts -1 to 6- to specified torque only ⇒ page 28 .






- Tighten bolts -arrows- securing tunnel cross member ⇒ Rep. gr. 34 ; Assembly mountings; Exploded view - assembly mountings or ⇒ Rep. gr. 37 ; Assembly mountings; Exploded view - assembly mountings .
- Check camber settings again ⇒ page 334. If OK, tighten bolts f**or subframe by specified angle**r private or commercial purposes, i

Please note: unless authorised by AUDI AG. AUDI AG does not guarantee

All wheel alignment settings must be checked if camber setting. Copy has been altered.

Tightening torques

- ⇒ "2.1 Exploded view subframe", page 28
- ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Exploded view - noise insulation



2.9 Adjusting camber at rear wheels


- Unscrew nut -A- at wheel bearing housing/upper link, and screw on new nut as far as stop.
- Adjust camber by turning adjuster screw -B-. Adjuster screw -B- can also be turned via hexagon flats at tip of screw.

Wheel alignment specifications ⇒ page 334



Note

- The maximum adjustment range is 135° to the left or right of the centre position.
- When the end position of the adjuster screw -B- is reached, do not turn further; otherwise components will be damaged.
- For illustration purposes the camber adjustment is shown with the wheel removed.
- Tighten nut -A- ⇒ Item 13 (page 204).
- Check camber value again after tightening nut -A-⇒ page 334 .




Special tools and workshop equipment required

Socket - T40183-



Protected by copyright. Copying for private or commercial purposes, in part or in whole permitted unless authorised by AUDI AG. AUDI AG does not guar with respect to the correctness of information in this document



- ◆ Commercially available fine-tooth ratchet (not illustrated)
- Unscrew nut -A- at track rod/subframe, and screw on new nut as far as stop.
- Adjust toe setting by turning eccentric bolt -B-.


Wheel alignment specifications ⇒ page 334


- Tighten nut -A- using socket T40183- ⇒ Item 4 (page 203).
- Check toe setting again after tightening nut -A- ⇒ page 334.



Note

- The maximum adjustment range is 90° to the left or right of the centre position.
- Adjusting the individual toe settings automatically alters the geometric running direction of the axle.








2.11 Adjusting toe setting at front wheels

 Measure and note down dimension -a- between track rod ball joint -1- and track rod -2- on both sides. Dimension -a- should be the same on the left and right prior to and after adjustment.

Protected by copyright. Copying for private or commpermitted unless authorised by AUDI AG. AUDI AG with respect to the correctness of information in this



Loosen lock nut -B-.



Note

Counterhold track rod ball joint -C- when slackening or tightening lock nut -B-.

Adjust toe setting at left and right wheels via hexagon flats

Make sure that rubber boot is not twisted after turning track rod. Twisted rubber boots wear out quickly.

Tighten lock nut -B- ⇒ Item 11 (page 405) and check toe-in value again.

The setting may change slightly after tightening lock nut -B-.

However, the adjustment is correct if the measured toe value is still inside the tolerance.

2.12 Wheel runout compensation

The toe-in cannot be set correctly without performing wheel runout compensation.

The existing lateral runout of the wheel rims must be compensated accordingly. Otherwise false results will be obtained.


A certain amount of axial runout at the wheel rims is permissible, but this may already exceed the specified toe-in tolerance. In such cases it is not possible to set the toe-in correctly without first compensating for the wheel runout.

Please observe the operating instructions provided by the manufacturer of the wheel alignment unit.

2.13 Checking full steering lock

The wheel alignment computer is used to determine the full steering lock.

- If the value was outside the tolerance when determining the full steering lock on the wheel alignment unit, inspect the steering and suspension for any damage or distortion and check the symmetry of the track rods. If necessary, shorten the "longer" track rod ball joint (by screwing it further onto the track rod) and renew any damaged components.
- If the steering wheel was found to be out of alignment when checking the centre position of the steering on the wheel alignment unit, inspect the steering and suspension for damage or






distortion and renew any damaged parts. Also check the symmetry of the track rods.

Measure dimension -a- on "shorter" track rod ball joint. Shorten the "longer" track rod ball joint to the same dimension. To do so, screw track rod ball joint -1- further onto track rod -2-.

Dimension -a- on track rod ball joint (right-side) = dimension -aon track rod ball joint (left-side); maximum permissible difference between right and left < 2.5 mm.

When returning steering to centre position, allow steering wheel to "settle" by rocking it evenly back and forth past centre position a few times.



2.14 Checking reference position for wheel alignment (vehicles with air suspension)

Checking reference position for wheel alignment

Before checking the wheel alignment on vehicles with air suspension, the reference position/unladen position must be checked and, if necessary, re-adapted.


To do this, run the »Wheel alignment« program on ⇒ Vehicle diagnostic tester in Guided Functions

Determining height dimension -a-

Height dimension -a- is the value in mm between the centre of the wheel and the bottom edge of the wing/wheel housing.

Determine dimension -a- between centre of wheel and bottom edge of wing/wheel housing, as shown in illustration.

Overview of height dimensions



Protected by copyright. Copying for private or commercial purposes permitted unless authorised by AUDI AG. AUDI AG does not guaran

Sportback espect to the correctness of information in this document. Copyright by AUDI AG.

Running gear	Level setting	Distance between centre of wheel and bottom edge of wing/wheel housing						
		Fron	Front axle F		r axle	Tolerance between		
		Nominal di- mension	Tolerance	Nominal di- mension	Tolerance	left and right		
Standard running gear 1BK	Normal	386 mm	± 10 mm	384 mm	± 10 mm	<= 10 mm		
RS running gear 2MA	Normal	386 mm	± 10 mm	384 mm	± 10 mm	<= 10 mm		
Sports run- ning gear 2MB	Normal	386 mm	± 10 mm	384 mm	± 10 mm	<= 10 mm		
Heavy-duty running gear 1BS	Normal	391 mm	± 10 mm	389 mm	± 10 mm	<= 10 mm		



Saloon/Avant

Running gear	Level setting	Distance between centre of wheel and bottom edge of wing/wheel housing						
		Fron	t axle	Rea	r axle	Tolerance between		
		Nominal di- mension	Tolerance	Nominal di- mension	Tolerance	left and right		
Standard running gear 1BK	Normal	384 mm	± 10 mm	382 mm	± 10 mm	<= 10 mm		
RS running gear 2MA	Normal	384 mm	± 10 mm	382 mm	± 10 mm	<= 10 mm		
Sports run- ning gear co 2MB	Normal opyright. C		± 10 mm te or commercial	382 mm purposes, in par	± 10 mm t or in whole, is r	<= 10 mm		
Heavy-duty vitirunningt to gear 1BS	Normal the corre	389 mm	± 10 mm ation in this docu	387 mm ment. Copyright	± 10 mm t by AUDI AG.	<= 10 mm		
allroad 1BY	Normal	393 mm	± 10 mm	390 mm	± 10 mm	<= 10 mm		



3 Dynamic steering

- ⇒ "3.1 Exploded view dynamic steering", page 353
- ⇒ "3.2 Removing and installing active steering control unit J792 <u>", page 354</u>
- ⇒ "3.3 Basic setting for dynamic steering", page 355

3.1 Exploded view - dynamic steering




Note

- Dynamic steering = active steering
- For more information on the dynamic steering system refer to ⇒ Self-study programme No. 402; Audi dynamic steering .

The illustration below shows the arrangement of components -1- and -2- on a left-hand drive vehicle. The arrangement of components -1- and -2- on a right-hand drive vehicle is symmetrically protected by copyright. Copyring for private or commercial purposes, in part or in whole, is not opposite.

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- 1 Active steering control unit - J792-
 - Basic setting must be performed on the system if active steering control unit - J792- has been renewed ⇒ page 355 .
 - Removing and installing ⇒ page 354
- 2 Steering column
 - Removing and installing ⇒ page 387
- 3 Safety lock for active steer-
 - Removing and installing ⇒ page 392
- 4 Adjuster
 - Adjuster and steering column are combined as one component and renewed together
 - Must not be detached or disconnected from steering column
 - Basic setting of system must be performed if adjuster is renewed ⇒ page 355




3.2 Removing and installing active steering control unit - J792-

Exploded view - active steering control unit - J792-

- 1 Nut, 2.5 Nm
- 2 Bolt, 8 Nm
- 3 Active steering control unit J792-
- 4 Connector, with clip for wiring harness
- 5 Earth wire
- 6 Bracket



Protected by copyright. Copying for private or commercial pupermitted unless authorised by AUDI AG. AUDI AG does not a



Special tools and workshop equipment required rmation in this document. Copyright by AUDI AG.

◆ Torque wrench - V.A.G 1783-



♦ Vehicle diagnostic tester

Removing

The active steering control unit - J792- is located in the footwell in front of the driver's seat.

- When renewing control unit, select "Replace" function for relevant control unit using ⇒ Vehicle diagnostic tester in <u>Guided</u>
 <u>Functions</u> mode.
- Unbolt driver's seat and move to rear with wiring connected ⇒ General body repairs, interior; Rep. gr. 72; Front seats; Removing and installing front seat.
- Remove floor mat.
- Remove sill panel trim ⇒ General body repairs, interior; Rep. gr. 70; Passenger compartment trim panels; Removing and installing sill panel trim.
- Remove foot rest ⇒ General body repairs, interior; Rep. gr. 70; Passenger compartment trim panels; Removing and installing foot rest.
- Unhook floor covering and press to one side.

- If fitted, detach electronics box for control unit for night vision system - J853- from studs and move clear.
- Remove nuts -6-.
- Remove nuts -1- and detach earth connection -2- from stud.
- Carefully unfasten clip attachment of wiring harness -3- from bracket -4-.
- Remove bolts -5- from control unit -7- and detach bracket -4-.
- Unplug connectors of wiring harness -3- from control unit -7-.

Installing

Installation is carried out in reverse sequence. Note the following: Follow sequence when installing control unit:

- Fit bracket -4- onto control unit -7- and tighten bolts -5-.
- Plug connectors of wiring harness -3- into control unit -7-.
- Clip wiring harness -3- into bracket -4-.
- Install control unit with bracket.
- Attach earth connection -2- to stud and tighten nuts -1-.
- Tighten nuts -6-.
- If originally fitted, insert two pins on electronics box for control unit for night vision system - J853- in seat cross member and fit front mounting onto studs.
- Basic setting must be performed on the system if active steering control unit - J792- has been renewed ⇒ page 355.

Tightening torques

- Active steering control unit J792- ⇒ page 354
- ⇒ General body repairs, interior; Rep. gr. 72; Front seats; Exploded view - front seat

3.3 Basic setting for dynamic steering



Note

Dynamic steering = active steering


Special tools and workshop equipment required


Steering wheel balance - VAS 6458-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability w00-11697 with respect to the correctness of information in this docume

Vehicle diagnostic tester









Wheel alignment computer

There are two options for performing the basic setting on the dynamic steering system:

Quick-start

This procedure (basic setting only) should be selected if:

- The active steering control unit J792- has been renewed.
- ♦ The steering angle sender G85- has been calibrated.
- The steering column has been renewed.
- The steering wheel is not straight when driving in a straight line.

Full wheel alignment

This procedure (basic setting and wheel alignment) should be selected if:

- The front axle toe setting has been changed.
- The rear axle toe setting has been changed.
- ♦ If the running gear of the vehicle is modified in any way e.g. conversion from standard running gear to sports running gear.



Note

- The two procedures are programmed on the wheel alignment computer.
- Each procedure runs automatically.
- All you have to do is select the relevant program.

Please note preparations required before calibration/adjustment of driver assist systems <u>⇒ page 332</u>.

- Select basic setting for dynamic steering system on wheel alignment computer.
- Attach quick-release clamps to all four wheels.
- Attach wheel alignment sensors to front and rear wheels.
- Carry out wheel rim runout compensation ⇒ page 350.



Note

- ♦ Disregard the steering wheel position!
- ♦ Only the display on the wheel alignment computer applies!

"Quick-start" procedure:	"Full wheel alignment" procedure:
Drive vehicle onto test platform	Drive vehicle onto test platform
Activate measuring system	Activate measuring system
Select model to the correctness of information in this do	Select model right by AUDI AG.
Carry out wheel rim runout compensation ⇒ page 350 .	Carry out wheel rim runout compensation ⇒ page 350.
Wheel alignment computer indicates "Front wheels straight-ahead"	Perform initial wheel alignment ⇒ page 330
Connect vehicle diagnostic tester	Align wheels <u>⇒ page 330</u>
Select function <u>⇒ page 357</u> .	Perform final wheel alignment
	Answer prompt: "Dynamic steering fitted?"



"Quick-start" procedure:	"Full wheel alignment" procedure:
	Wheel alignment computer indicates "Front wheels straight-ahead"
	Connect vehicle diagnostic tester
	Select function <u>⇒ page 357</u> .

The remaining steps are now performed via the vehicle diagnostic tester.

VAS PC

Connect up ⇒ Vehicle diagnostic tester.

- Select Guided Functions mode.
- Select address "1B Active steering J792".
- Select "1B Functions Active steering J792".
- Select "1B Basic setting" and follow instructions on screen.

ODIS - Offboard Diagnostic Information System

Connect up ⇒ Vehicle diagnostic tester.

- Select Diagnosis mode and begin diagnosis.
- Select Control units tab.
- Select address "1B Active steering J792".
- Select "1B Functions Active steering J792".
- Select "1B Basic setting" and follow instructions on screen.

Then follow basic setting instructions on screen.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




4 Adaptive cruise control

⇒ "4.1 Adjusting adaptive cruise control", page 358

4.1 Adjusting adaptive cruise control

Special tools and workshop equipment required


◆ Adjusting tool - VAS 6190/2-



 ACC setting device - VAS 6430- or setting device, basic set -VAS 6430/1-



Protected by copyright. Copying for private or commercial purposes, in part or in whole permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any with respect to the correctness of information in this document. Copyright by AUDI AG



- ♦ ACC reflective mirror, Audi VAS 6430/3-
- Vehicle diagnostic tester
- Wheel alignment computer

There are two options for adjusting the sensors for adaptive cruise control:

Quick-start

This procedure (adjustment only) should be selected in the following cases:

- If the adaptive cruise control unit J428- and/or control unit 2 for adaptive cruise control - J850- have been removed and installed.
- ♦ If the front bumper has been removed and installed.
- If the front bumper has been detached or moved.
- If the front bumper is damaged.
- ◆ If the misalignment angle is greater than -0.8° to +0.8°.
- ♦ If there is excessive vertical misalignment of the sensors for adaptive cruise control .

Full wheel alignment

This procedure (adjustment and wheel alignment) should be selected in the following cases:



- If the rear axle toe setting has been changed.
- If the running gear of the vehicle is modified in any way e.g. conversion from standard running gear to sports running gear.



Note

The two procedures are programmed on the wheel alignment computer. Each procedure runs automatically. All you have to do is select the relevant program.



Note

Before performing ACC adjustment, check whether the vehicle is equipped with a night vision system. If so, it may be necessary to calibrate the camera for the night vision system first (depending on the repair work involved). The two adaptive cruise control sensors can be adjusted afterwards. Having set the distance between the camera for the night vision system and the calibration unit for night vision system - VAS 6430/6-, this setting can be used to perform the ACC adjustment.

The steps listed under "Adjustment procedure (when wheel alignment has not been previously checked)" are only required if no wheel alignment check has already been performed.

Please note preparations required before calibration/adjustment of driver assist systems ⇒ page 332.

Adjustment procedure (when wheel alignment has not been pre-rotal purposes, in part or in whole, is not viously checked) permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- Attach quick-release clamps to rear wheels.
- Attach wheel alignment sensors to rear wheels.
- Carry out wheel rim runout compensation for rear wheels.
- Connect up vehicle diagnostic tester to vehicle and run diagnostic cable out through open window.

Adjustment procedure (when wheel alignment has been previously checked)

Bring front wheels into straight-ahead position.

Adjustment procedure continued (irrespective of previous wheel alignment check)

- Connect battery charger ⇒ Electrical system; Rep. gr. 27; Battery; Charging battery .
- Close all vehicle doors.
- Press button to select ACC adjustment procedure in wheel alignment computer.

Always follow the adjustment procedure below:

Set up equipment with ACC reflective mirror, Audi - VAS 6430/3- in centre position at a distance of 120 cm ± 2.5 cm from Audi rings.






- This step is necessary if you have not already adjusted/calibrated the camera for the night vision system.
- If the camera for the night vision system has already been adjusted/calibrated, it is not necessary to re-position the ACC Projecting device UVAS 6430 g for private or commercial purposes, in part or in whole, is not
- permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability 2 Position ACC reflective mirror, Audi VAS 6430/3- on right with manager counterings and wanter name to page ument. Copyright by AUDI AG. 2 - Position ACC reflective mirror, Aug. - VAS 975075 with side in front of adaptive cruise control unit - J428-
- 3 -Adjust adaptive cruise control unit - J428-
- Attach ACC reflective mirror, Audi on opposite side of cross bar in front of control unit 2 for adaptive cruise control -J850- .
- Check position of spirit levels and cross bar (refer to display on wheel alignment computer) and correct if necessary.
- Adjust control unit 2 for adaptive cruise control J850-.



Note

Before performing ACC adjustment, check that the two sensors for adaptive cruise control and their brackets and fasteners are properly secured and inspect them for signs of impacts and/or extranéous damage. Service any damaged components as necessary. Similarly, check that the front bumper cover is securely attached and inspect for damage and cracks. Service any damaged components as necessary.

- Detach air intake grille -1- (both sides) ⇒ General body repairs, exterior; Rep. gr. 63; Bumper (front); Removing and installing attachments .
- Remove any dirt from sensor lens.




Procedure if camera for night vision system has not already been calibrated/adjusted

Position ACC setting device - VAS 6430- so that distance -A- is attained between ACC reflective mirror, Audi - VAS 6430/3- (in centre position) and Audi rings.




Note

- Distance -A- = $120 \text{ cm} \pm 2.5 \text{ cm}$, measured from ACC reflective mirror, Audi - VAS 6430/3- to surface of Audi rings.
- Do not pull on the cross bar when moving -VAS 6430- .






Attach front wheel alignment sensors -1- to -VAS 6430- .




Procedure (all situations)

Fit ACC reflective mirror, Audi on right side next to vertical slide, as shown in illustration.




In area -A-, align number -2- on rotary knob with mark on mirror (number 2 on rotary knob must face vehicle).






Protected by copyright. Copying for private or commercial purposes, permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any with respect to the correctness of information in this document. Copy

Set up -VAS 6430- by moving it from side to side -arrows B-.




Use adjusting screws -1-, -2- and -3- to bring spirit levels -Aand -B- on -VAS 6430- into horizontal position.

Protected by copyright. Copying for private or commercial purposes, in pa permitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyrigh



- Using crank handle -arrow- on -VAS 6430-, set mirror -4- so that laser beam coincides with centre of sensor lens in vertical plane. If necessary, re-position mirror -4- laterally on cross bar so that laser beam coincides with centre of sensor lens in horizontal plane.
- Set identical individual front axle toe values with fine adjustment screw -5-.
- Difference between individual toe values must be less than 6' or equal.





- Balance out spirit levels -2- on wheel alignment sensors -1-.
- Then check again that laser beam -3- from -VAS 6430- coincides with sensor lens.



Note

- -VAS 6430- is correctly aligned if the laser beam still coincides with the sensor lens at this stage, after the identical toe values have been set.
- The alignment of -VAS 6430- must be repeated if the laser beam does not coincide with the sensor lens.
- Switch on vehicle diagnostic tester.

The vehicle diagnostic tester is ready for operation when the selector buttons for the operating modes appear on the screen.


- Switch on ignition. Protected by copyright. Copying for private or commercial
- Touch the Guided Fault Finding button on the display does not guarantee or accept any liability screen.
- with respect to the correctness of information in this document. Copyright by AUDI AG. Select the following:
- Make
- Type
- Model year
- Version
- Engine code
- Confirm the entered information.


Wait until diagnostic tester has interrogated all control units in the vehicle.

- Press the Go to button and select the option "Function/component selection".
- Select the relevant program in "Guided Functions".

Then follow adjustment instructions on screen.

For fine adjustment of adaptive cruise control unit - J428- in "Guided Functions", use screws -1- (bottom) and -2- (top).









When adjustment of adaptive cruise control unit - J428- has been successfully completed, perform adjustment of control unit 2 for adaptive cruise control - J850- .

The procedures for adjusting control unit 2 for adaptive cruise control - J850- and adaptive cruise control unit - J428- are basically the same. ACC reflective mirror, Audi -1- has to be refitted on opposite side of cross bar ⇒ page 358.




For fine adjustment of control unit 2 for adaptive cruise control - J850- in "Guided Functions", use screws -1- (bottom) and -2- (top).



ACC adjustment is not completed until diagnostic tester displays "Final control element diagnosis ended".

- Switch off ignition.
- Detach connector of diagnosis cable at diagnostic connection.
- Disconnect battery charger ⇒ Electrical system; Rep. gr. 27;
- Battery: Charging battery Protected by Copyright. Copying for private or commercial purposes, in part or in whole, is not Install air intake grille ⇒ General body repairs, exterior; Reparamete or accept any liability gr. 63; Bumper (front); Removing and installing attachments.
 - with respect to the correctness of information in this document. Copyright by AUDI AG.






5 Front camera for driver assist systems

⇒ "5.1 Calibrating front camera for driver assist systems", page 365

5.1 Calibrating front camera for driver assist systems

Special tools and workshop equipment required

♦ ACC setting device - VAS 6430-



- Vehicle diagnostic tester
- Wheel alignment computer



Note

- Check that setting device VAS 6430- is locked in centre position.
- Check that the camera control unit J852- is seated correctly in the bracket.
- Check that the camera vision is unobstructed (visual inspec-
- ♦ Before commencing calibration, interrogate event memory and rectify any faults.

There are two options for performing the calibration:

Quick-start

This procedure (calibration only) should be selected if:

- The fault "No or incorrect basic setting / adaption" is registered in the event memory.
- ♦ The camera control unit J852- is removed and installed or renewed.
- The windscreen is removed or renewed.
- The reference position has been re-adapted on vehicles with air suspension by copyright. Copying for private or commercial purposes, in part or in whole, is not

Full wheel ralignment less authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

This procedure (calibration and wheel alignment) should be ment. Copyright by AUDI AG. selected if:

- The rear axle toe setting has been changed.
- The running gear of the vehicle is modified in any way e.g. conversion from standard running gear to sports running gear.





Note

The two procedures are programmed on the wheel alignment computer. Each procedure runs automatically. All you have to do is select the relevant program.

Please note preparations required before calibration/adjustment of driver assist systems ⇒ page 332.

Calibration/adjustment procedure (when wheel alignment has not been previously checked)

- Attach quick-release clamps to all four wheels.
- Attach rear wheel alignment sensors.
- Carry out wheel rim runout compensation for rear wheels.

Calibration/adjustment procedure (when wheel alignment has been previously checked)

Bring front wheels into straight-ahead position.


Calibration/adjustment procedure continued (irrespective of previous wheel alignment check)

- Press button to select calibration/adjustment procedure in wheel alignment computer.
- Set up -VAS 6430- as shown in illustration so that distance -A- measured from hub centres of front wheels to cross bar of -VAS 6430- is 150 cm ± 2.5 cm.



Note

Do not pull on the cross bar when moving -VAS 6430-.




Attach front wheel alignment sensors -1- to -VAS 6430-.



Note

For the next step the wheel alignment platform must be set at the lowest available position.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability







Determine height difference -A- between floor level where -VAS 6430- is set up and wheel contact patch as shown in illustration and enter this value in the wheel alignment comal purpo

puter permitted unless authorised by AUDI AG. AUDI AG does not gua

with respect to the correctness of information in this document



Loosen bolt -arrow- and set measuring bar -1- on floor.




Using crank -1-, adjust calibration screen to specified height -2- as indicated by wheel alignment computer.

When specified height -2- has been set, move measuring bar up slightly and tighten clamping bolt.



Note


If the height of the calibration screen has to be corrected at a later stage of the procedure, the measuring bar must be set on the floor when making the adjustment.





Set spirit level -A- to horizontal position with adjuster screw


The spirit level -A- has to be adjusted at this point to compensate for any floor irregularities.




Move -VAS 6430- sideways -arrow B- until display on wheel alignment computer is within tolerance.



Protected by copyright. Copying for private or d permitted unless authorised by AUDI AG. AUDI with respect to the correctness of information



Secure by tightening bolts -2- and -3- -VAS 6430- lightly. (This will prevent the -VAS 6430- from rolling away).







Turn fine adjustment screw -1- until display on wheel alignment computer is within tolerance.



Protected by copyright. Copying for private or commercial pur permitted unless authorised by AUDI AG. AUDI AG does not g with respect to the correctness of information in this docume



Set spirit level -A- to horizontal position with adjuster screw



Set spirit level -B- to horizontal position with adjuster screw

Concluding work is carried out via ⇒ Vehicle diagnostic tester.

Connect vehicle diagnostic tester and start Guided Fault Finding for the vehicle in question.

Wait until the vehicle diagnostic tester has interrogated all control units in the vehicle.


- Press the Go to button and select the option "Function/component selection".
- Select the relevant program in Guided Functions.

Then follow the instructions on the screen to perform the calibra-




Note

The next step required in the Guided Fault Finding program is to measure the height of the body.





Measure height of body -a- at all four wheels between tyre contact surface and bottom edge of wing panel/wheel housing at centre of wheel.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




6 Night vision system

⇒ "6.1 Calibrating night vision system", page 371

6.1 Calibrating night vision system

Special tools and workshop equipment required

Setting device, basic set - VAS 6430/1- or setting device - VAS 6430-



- Calibration unit for night vision system VAS 6430/6-
- Linear laser VAS 6350/3- (can be taken from calibration unit VAS 6350-)
- Vehicle diagnostic tester
- Wheel alignment computer



Note

- Check that the camera for night vision system R212- is correctly seated in the bracket and that the camera vision is unobstructed (visual inspection).
- Check whether the protection window on the camera for night vision system - R212- has been damaged by a stone chip and renew if necessary ⇒ Communication; Rep. gr. 91; Night vision system; Removing and installing camera for night vision system .
- If the vehicle is equipped with adaptive cruise control and night vision system, the night vision system must be adjusted/calibrated before the adaptive cruise control.
- ♦ If the ACC reflective mirror, Audi VAS 6430/3- is attached to the cross bar of the setting device, basic set - VAS 6430/1- or setting device cVAS 6430 prit must be removed mmercial purposes, in part or in whole, is not

There are two options for performing the calibration/adjustment: spect to the correctness of information in this document. Copyright by AUDI AG.

Quick-start

This procedure (calibration/adjustment only) should be selected if:

- The fault "No or incorrect basic setting / adaption" is registered in the event memory.
- The camera has been removed or renewed.
- The bumper or radiator grille has been removed or renewed.

Full wheel alignment

This procedure (calibration/adjustment and wheel alignment) should be selected if:



- Adjustments have been made to the rear suspension geome-
- The running gear of the vehicle has been modified in any way.



Note

The two procedures are programmed on the wheel alignment computer. Each procedure runs automatically. All you have to do is select the relevant program.

Please note preparations required before calibration/adjustment of driver assist systems ⇒ page 3

Adjustment procedure (when wheel alignment has not been previously checked)


- Select calibration procedure for night vision system on wheel alignment computer.
- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Attach wheel alignment sensors according to instructions on AUDI AG does not guarantee or accept any liability wheel alignment computer.

Calibration/adjustment procedure (when wheel alignment has been previously checked)

- Connect battery charger ⇒ Electrical system; Rep. gr. 27; Battery; Charging battery .
- Bring front wheels into straight-ahead position.
- Connect up vehicle diagnostic tester to vehicle and run diagnostic cable out through open window.
- Switch off exterior lights on vehicle.
- Close all vehicle doors.


Procedure for all vehicles:

Connect up vehicle diagnostic tester to vehicle and run diagnostic cable out through open window.






- Place calibration unit for night vision system on centre of cross bar on setting device, basic set - VAS 6430/1-.
- When sliding calibration unit for night vision system onto cross bar, recess -arrows- must surround nut or bolt -A-.



- Swivel clamps -A- into place (left and right).
- Hand-tighten clamping bolts -1- (left and right).




- Position setting device, basic set VAS 6430/1- with calibration unit for night vision system in front of vehicle.
- Position calibration unit for night vision system VAS 6430/6at distance -A- from camera for night vision system.




Note

Distance -A- = 120 cm \pm 2.5 cm, measured from calibration unit for night vision system - VAS 6430/6- to lens of camera for night vision system - R212- .




- Attach front wheel alignment sensors to cross bar private or commercial purposes, in part or in whole, is not
- For the next steps, the lifting platform must be set to the lowest available position itA-respect to the correctness of information in this






- Insert linear laser VAS 6350/3- -arrow- into guide on calibration unit for night vision system and secure.
- Switch on linear laser VAS 6350/3- . A laser beam will be directed at the vehicle.




Use crank on rear side of calibration unit to align laser beam with centre of camera lens in horizontal plane.

The specified height has now been attained and the linear laser - VAS 6350/3- can be switched off.



Set spirit level -A- to horizontal position with adjuster screw

The spirit level -A- has to be adjusted at this point to compensate for any floor irregularities.






Protected by copyright. Copying for private or commercial purposes, permitted unless authorised by AUDI AG. AUDI AG does not g


with respect to the correctness of information in this document. Copyright by AUDI AG.




Move -VAS 6430- sideways -arrow B- until display on wheel alignment computer is within tolerance.



Secure by tightening bolts -2- and -3- -VAS 6430- lightly. (This will prevent the -VAS 6430- from rolling away).




Turn fine adjustment screw -1- on cross bar until display on wheel alignment computer is within tolerance.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- Set spirit level -A- to horizontal position with adjuster screw
- Set spirit level -B- to horizontal position with adjuster screw



- Switch on linear laser VAS 6350/3- again, check specified height and correct if necessary. A laser beam will be directed at the vehicle.
- Use crank on rear side of calibration unit to align laser beam with centre of camera lens in horizontal plane.

The specified height has now been attained and the linear laser - VAS 6350/3- can be switched off.



- Connect power cable -A- of calibration unit for night vision system to mains.
- Switch on calibration unit for night vision system at switch




Note

An internal initialisation routine runs on the calibration unit for night vision system when you switch it on. If the routine is completed successfully without errors, both LEDs -C- flash simultaneously and an acoustic tone can be heard at the same time. The calibration unit for night vision system then goes into standby mode (the green LED will flash slowly to indicate this status).



Note

Check the spirit levels (visual inspection) and re-adjust if necessary.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Press button -A- to activate the heating function.

An acoustic signal confirms that the heating function has been activated. The heater element is then in the warm-up phase.

When the specified temperature is reached, the green LED lights up permanently.

Protected by copyright. Copying for private or commerci

The control unit automatically switches off the heater elements after about 20 minutes. A periodic acoustic signal will be given about 1 minute before this happens rectness of information in this do

The automatic timer can be reset to 20 minutes at any time by briefly pressing button -A-. An acoustic signal confirms that the timer has been reset.

Concluding work is carried out via ⇒ Vehicle diagnostic tester.

Connect vehicle diagnostic tester and start Guided Fault Finding for the vehicle in question.

Wait until the vehicle diagnostic tester has interrogated all control units in the vehicle.

- Press the Go to button and select the option "Function/component selection".
- Select the relevant program in Guided Functions.

Follow adjustment/calibration instructions on screen of diagnostic tester.

Mechanical alignment of the camera for night vision system -R212- around its roll axis is achieved by turning the adjuster screw with a hexagon key (minimum length approx. 120 mm).


- To do so, open bonnet and detach lock carrier cover -1- ⇒ General body repairs, exterior; Rep. gr. 63; Bumper (front); Exploded view - bumper cover .
- Apply hexagon key -2- and adjust in accordance with specifications in "Guided Fault Finding".




Note

Ensure that no objects or persons are between the camera for night vision system - R212- and the calibration unit for night vision system during the adjustment procedure.

Adjustment of the pitch and yaw angles for the camera for night vision system - R212- is fully electronic: start the appropriate program on ⇒ Vehicle diagnostic tester in Guided Functions mode.








Steering

Steering wheel

- ⇒ "1.1 Exploded view steering wheel", page 378
- 2 Removing and installing steering wheel", page 378
- 1.1 Exploded view - steering wheel
- 1 Steering column electronics control unit J527-
- Removing and installing permittæd Eléctricaltsystem;by Rep. gr. 94; Steering with rescolumn switch module; Removing and installing steering column electronics control unit -J527-
- 2 Airbag steering wheel
 - Removing and installing ⇒ page 378
- 3 Bolt
 - □ 50 Nm
 - ☐ Always renew if removed
- 4 Electrical connector
- 5 Electrical connector
- 6 Driver's airbag unit
 - □ Removing and installing ⇒ General body repairs, interior; Rep. gr. 69; Airbag (driver side); Removing and installing airbag unit with igniters
- 7 Locking bar
 - □ Releasing ⇒ General body repairs, interior; Rep. gr. 69; Airbag (driver side); Removing and installing airbag unit with igniters
- 8 Trim cap
 - Not fitted on this model



1.2 Removing and installing steering wheel

Special tools and workshop equipment required




◆ Torque wrench - V.A.G 1331-

Protected by copyright. Copying for private or commercial purposes, in permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Steering wheel balance - VAS 6458-



Removing



Note

- Applies to vehicles with dynamic steering:
- Before detaching it from the steering column, the steering wheel must be aligned accurately in a horizontal position using the steering wheel balance - VAS 6458- . Use the steering wheel balance - VAS 6458- to align the new steering wheel horizontally on the steering column.
- After completing the above step, check the steering wheel position on the steering angle sender - G85- . To do so, select the corresponding measured value block in the self-diagnosis for the steering column electronics control unit - J527- . If the value displayed is > 0.5°, the steering angle sender - G85must be re-calibrated and the dynamic steering re-adapted: start the appropriate program on ⇒ Vehicle diagnostic tester in Guided Functions mode.
- Turn wheels to straight ahead position.
- Move steering wheel upwards and rearwards as far as possible, using the full range of the steering column adjuster.
- Remove airbag unit (driver side) ⇒ General body repairs, interior; Rep. gr. 69; Airbag (driver side); Removing and installing airbag unit with igniters .



Note

The steering must be in the centre position (wheels straightahead) when the steering wheel is removed and installed.

- Remove bolt -1-.
- Mark relative position of steering wheel to steering column with a felt-tip pen.
- Pull steering wheel -2- off steering column.

Installing

Installation is carried out in reverse sequence. Note the following: Before fitting steering wheel, make sure wheels are in straight ahead position.

- If installing original steering wheel: Make sure marks on steering column and steering wheel coincide.
- If installing new steering wheel (no marks): Steering wheel must be mounted in centre position (spoke horizontal and wheels in straight-ahead position).
- Install steering wheel.
- Install airbag unit ⇒ General body repairs, interior; Rep. gr. 69; Airbag (driver side); Removing and installing airbag unit with igniters .
- Test-drive vehicle.
- If steering wheel is not straight, remove it again and adjust it on steering column splines.

Tightening torques

Exploded view steering wheel", page 378 A48-10623

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



2 Steering column

- ⇒ "2.1 Exploded view steering column", page 381
- ⇒ "2.2 Checking steering column for damage", page 385
- ⇒ "2.3 Handling and transporting steering column", page 386
- ⇒ "2.4 Removing and installing steering column", page 387
- ⇒ "2.5 Removing and installing safety lock for active steering (locking solenoid)", page 392
- ⇒ "2.6 Removing and installing intermediate steering shaft", page
- ⇒ "2.7 Removing and installing control unit for electronic steering column lock J764", page 398
- ⇒ "2.8 Removing and installing control unit for electrically adjustable steering column J866 ", page 400

2.1 Exploded view - steering column

- ⇒ "2.1.1 Exploded view steering column (with manual adjustment)", page 381
- ⇒ "2.1.2 Exploded view steering column (with electrical adjustment)", page 384
- Exploded view steering column (with manual adjustment) 2.1.1



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 - Bolt


- □ 30 Nm
- □ Always renew if removed
- ☐ The tapped hole for the bolt must always be cleaned (e.g. with a thread tap)
- ☐ First, start the thread of the bolt and try to pull off the intermediate steering shaft to check that it is correctly seated. Then tighten bolt.
- 2 Intermediate steering shaft
 - Removing and installing <u>'±opaged395</u>copyrigh
 - Note correct position of a sealing boot
- 3 Dash panel cross member

4 - Bolt

□ Tightening torque ⇒ General body repairs, interior; Rep. gr. 70; Dash panel cross member; Exploded view dash panel cross member

5 - Mounting bracket

 Removing and installing ⇒ General body repairs, interior; Rep. gr. 70; Dash panel cross member; Removing and installing mounting bracket



6 - Bolt

□ 5 Nm

- 7 Control unit for electronic steering column lock J764-
 - ☐ Fitted on vehicles with safety ignition lock
 - □ Removing and installing ⇒ page 398
 - When renewing control unit, select "Replace" function for relevant control unit using ⇒ Vehicle diagnostic tester in Guided Functions mode.

8 - Bolt

- □ 20 Nm
- □ 2x
- Note correct installation sequence ⇒ page 391

9 - Bolt

- □ 20 Nm
- □ 2x
- Note correct installation sequence ⇒ page 391

10 - Steering column

- ☐ Different versions; for correct version refer to ⇒ Electronic parts catalogue
- ☐ Vehicles with dynamic steering: system must be re-calibrated if steering column is renewed ⇒ page 355




Audi A6 2011 ➤ , Audi A6 China 2012 ➤ , Audi A7 Sportback 2011 ➤ Running gear, front-wheel drive and four-wheel drive - Edition 12.2018



	Removing and installing ⇒ page 387
Prote	e Checking for damage i <mark>⇒rpage 385</mark> e or commercial purposes, in part or in whole, is not
1/18 F11 1	dandle nless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
12 ^{ith} E	Boltpect to the correctness of information in this document. Copyright by AUDI AG.
	5 Nm
13 - E	Bolt
	Secures pedal cluster
	Tightening torque ⇒ Brake system; Rep. gr. 46 ; Brake pedal; Exploded view - brake pedal
14 - E	Bolt
	20 Nm
	2x
	Note correct installation sequence <u>⇒ page 391</u>
15 - E	Bolt
	30 Nm
	Always renew if removed
	The tapped hole for the bolt must always be cleaned (e.g. with a thread tap)
16 - N	Nut
	3 Nm

2.1.2 Exploded view - steering column (with electrical adjustment)

2.1.2 1 - Bolt □ 30 Nm ☐ Always renew if removed The tapped hole for the bolt must always be cleaned (e.g. with a thread tap) □ First, start the thread of the bolt and try to pull off the intermediate steering shaft to check that it is correctly seated. Then tighten bolt. 2 - Intermediate steering shaft Removing and installing ⇒ page 395 Note correct position of sealing boot 3 - Control unit for electrically adjustable steering column -J866-Removing and installing ⇒ page 400 4 - Dash panel cross member 5 - Bolt



6 - Mounting bracket

☐ Tightening torque ⇒
General body repairs,
interior; Rep. gr. 70;
Dash panel cross member; Exploded view dash panel cross mem-

- □ Removing and installing ⇒ General body repairs, interior; Rep. gr. 70; Dash panel cross member; Removing and installing mounting bracket
- 7 Bolt
 - □ 5 Nm
- 8 Bolt
 - □ 5 Nm
- 9 Control unit for electronic steering column lock J764-
 - □ Removing and installing ⇒ page 398
 - ☐ Fitted on vehicles with safety ignition lock
 - ☐ When renewing control unit, select "Replace" function for relevant control unit using ⇒ Vehicle diagnostic tester in Guided Functions mode.
- 10 Bolt
 - □ 20 Nm
 - □ 2x
 - Note correct installation sequence ⇒ page 391
- 11 Bolt
 - □ 20 Nm

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability



ч	ZX
	Note correct installation sequence <u>⇒ page 391</u>
12 - 8	Steering column
	Different versions; for correct version refer to ⇒ Electronic parts catalogue
	Vehicles with dynamic steering: system must be re-calibrated if steering column is renewed ⇒ page 355
	Removing and installing <u>⇒ page 387</u>
	Checking for damage <u>⇒ page 385</u>
13 - E	Solt Secures pedal cluster Tightening torque ⇒ Brake system; Rep. gr. 46 ; Brake pedal; Exploded view - brake pedal
14 - E	Bolt
	20 Nm d by copyright. Copying for private or commercial purposes, in part or in whole, is not
	o <mark>2</mark> Xnitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability Note correct installation sequence ⇒ page 391 with respect to the correctness of information in this document. Copyright by AUDI AG.
15 - E	Bolt
	30 Nm
	Always renew if removed
	The tapped hole for the bolt must always be cleaned (e.g. with a thread tap)
16 - N	Nut
	3 Nm


2.2 Checking steering column for damage

Visual inspection

- Check all parts of steering column for damage.

Checking function

- Check that steering column turns easily and smoothly.
- Check that steering column can be adjusted for height and reach without sticking.
- Check whether the tube moves clearly in direction of arrow -A- or -B-.
- If it does, the steering column must be renewed.





2.3 Handling and transporting steering col-

⇒ "2.3.1 Handling and transporting steering column (with manual adjustment)", page 386

⇒ "2.3.2 Handling and transporting steering column (with electrical adjustment)", page 387

Handling and transporting steering col-2.3.1 umn (with manual adjustment)




- These instructions for handling the steering column MUST be observed at all times.
- Incorrect handling can damage the steering column and thus cause a safety risk.

Correct handling and transportation of steering column

- Using gloves, take the steering column out of its packaging with both hands and carry it with both hands.
- Take hold of the steering column by the upper column tube -1- and close to the upper universal joint -2- as shown in the illustration.


Protected by copyright. Copying for private or commercial pur permitted unless authorised by AUDI AG. AUDI AG does not g with respect to the correctness of information in this docume



Incorrect handling of steering column

Carrying the steering column by the following parts will cause damage:

- Release handle
- Weight balancing springs 2 -
- A steering column that has been dropped onto a hard surface or shows signs of damage must not be installed in the vehicle.
- The steering column must not be put down on the shafts at either end.
- The ends of the shafts must not be subjected to any impact.






2.3.2 Handling and transporting steering column (with electrical adjustment)

CAUTION

- These instructions for handling the steering column MUST be observed at all times.
- Incorrect handling can damage the steering column and thus cause a safety risk.

Correct handling and transportation of steering column


- Using gloves, take the steering column out of its packaging with both hands and carry it with both hands.
- Take hold of the steering column as shown in the illustration at the top column tube -1- and near the dynamic steering adjuster -2- or at the bottom column tube -3- (depending on the version).



Incorrect handling of steering column

Carrying the steering column by the following parts will cause damage:


- Connector and wiring harness
- 2 -Spindles of electric steering column adjuster
- Motors of electric steering column adjuster
- A steering column that has been dropped onto a hard surface or shows signs of damage must not be installed in the vehicle.
- The steering column must not be put down on the shafts at either end.
- ◆ The ends of the shafts must not be subjected to any impact.



2.4 Removing and installing steering column

Special tools and workshop equipment required private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

◆ Torque wrench - V.A.G 1331-



Removing



Before removing the steering column, please note the following points:

Draw a sketch showing

- the layout of the electrical wiring harnesses
- the attachment of the electrical wiring harnesses
- the fitting locations of the cable ties.

This applies particularly to the wiring harness for the control unit for electronic steering column lock - J764- .

Before installing the steering column, please note the following ate or commercial purposes, in part or in whole, is not points:

permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liability

- Restore the layout of the electrical wiring harnesses exactly nation in this document. Copyright by AUDI AG. as it was prior to removal.
- Restore the attachments of the electrical wiring harnesses exactly as they were prior to removal.
- All cable ties unfastened or cut open when removing the steering column must be re-attached in the same position when refitting it.
- When adjusting the steering column, check that the wiring harness leading to the control unit for electronic steering column lock - J764- is not trapped and does not come into contact with any sharp edges.



Note

- The replacement steering column is only supplied as a complete unit. Repair is not possible.
- Only the control unit for electronic steering column lock J764can be renewed separately.
- Turn wheels to straight ahead position.
- Move steering wheel down and to rear as far as possible, making use of full range of steering column adjuster.
- Remove steering wheel ⇒ page 378.
- Remove dash panel cover (driver side) ⇒ General body repairs, interior; Rep. gr. 68; Storage compartments/covers/trim panels; Removing and installing dash panel cover (driver side).




- If fitted, remove knee airbag with bracket (driver side) ⇒ General body repairs, interior; Rep. gr. 69; Knee airbags; Removing and installing knee airbag with igniter.
- Remove footwell vent (driver side) ⇒ Heating, air conditioning; Rep. gr. 87; Air duct system; Removing and installing footwell vent (driver side) .
- Remove steering column trim ⇒ General body repairs, interior; Rep. gr. 68; Storage compartments/covers/trim panels; Exploded view - steering column trim .
- Remove steering column switch module ⇒ Electrical system; Rep. gr. 94; Steering column switch module; Removing and installing steering column switch module .



On steering columns for dynamic steering: never slacken or remove the bolts of the dynamic steering unit.


Remove bolt -2- and detach intermediate steering shaft -3from steering column -1-.




Applies to electrically adjustable steering column:

- Unplug electrical connector -arrow- and move clear.

Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does no with respect to the correctness of information in this docu




If fitted, unplug electrical connectors -1, 2, 3- for dynamic steering and move clear.





Applies to all versions:

- Unscrew bolts -1 ... 7- for steering column from central tube, supporting steering column by hand from below.
- Pull steering column back slightly, detach from positioning holes -arrows- on central tube and lower.



On vehicles with safety ignition lock, unplug electrical connector -1- at control unit for electronic steering column lock -J764-, move wiring harness -2- clear and detach steering column.

Installing

Installation is carried out in reverse sequence. Note the following:

If the steering column has been renewed on a vehicle with safety ignition lock, use the bolt fitted in the new steering column to secure control unit for electronic steering column lock - J764- .







Note

Protected by copyright. Copying for private or If the steering column has been renewed, use the bolt fitted in the new steering column to secure control unit for electronic DIA steering column lock 1764-


Before fitting new bolt -2-, clean threaded hole with a thread tap or similar.





Vehicles with safety ignition lock


- After plugging in electrical connector -1-, make sure wiring harness is secured by clip -2- at the appropriate location.
- Check that wiring harness -3- leading to control unit for electronic steering column lock - J764- -1- does not become trapped and does not come into contact with sharp edges when steering column is adjusted.





Note correct installation sequence

- Fit positioning pins -arrows- on steering column into positioning holes on central tube.
- Screw in all bolts only loosely.
- First tighten bolt -1- to specified torque.
- Then tighten bolt -2- to specified torque.
- Then tighten bolts -3- and -4- to specified torque.
- Then tighten bolts -5- and -6- to specified torque.
- Tighten bolt -7- to specified torque.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Push intermediate steering shaft -3- onto steering column -1as far as stop and tighten bolt -2-.
- If previously fitted, install knee airbag with bracket (driver side) ⇒ General body repairs, interior; Rep. gr. 69; Knee airbags; Removing and installing knee airbag with igniter .
- Install steering column switch module ⇒ Electrical system: Rep. gr. 94; Steering column switch module; Removing and installing steering column switch module.
- Install steering column trim ⇒ General body repairs, interior; Rep. gr. 68; Storage compartments/covers/trim panels; Exploded view - steering column trim .
- Install footwell vent (driver side) ⇒ Heating, air conditioning; Rep. gr. 87; Air duct system; Removing and installing footwell vent (driver side) .
- Install dash panel cover (driver side) ⇒ General body repairs, interior; Rep. gr. 68; Storage compartments/covers/trim panels; Removing and installing dash panel cover (driver side).
- Install steering wheel ⇒ page 378.
- If control unit for electronic steering column lock J764- has been renewed it must be re-adapted to the immobilizer; start appropriate program on ⇒ Vehicle diagnostic tester in Guided Functions.



Note


If the same steering column and the same control unit for electronic steering column lock - J764- are being re-installed, the control unit for electronic steering column lock - J764- does not have to be adapted.

- After installing the steering column switch module, the steering angle sender - G85- must be calibrated; start the appropriate program on ⇒ Vehicle diagnostic tester in Guided Functions mode.
- If steering column was renewed, "Basic setting for dynamic steering" must be performed on vehicles with dynamic steering (active steering) 3.3 Basic setting for dynamic steering", page 355.

Tightening torques

- ⇒ "2.1 Exploded steering column", page 381
- Removing and installing safety lock for nercial purposes, in part or in whole, is not 2.5 active steering (locking solenoid) UDI AG does not guarantee or accept any liability

Special tools and workshop equipment required formation in this document. Copyright by AUDI AG.





◆ Torque wrench - V.A.G 1783-



Vehicle diagnostic tester



Note the following before working on the steering column.

- Steering components are safety components!
- For reasons of safety, all work on the steering system must be carried out by suitably trained and qualified personnel. Work that is not performed properly can result in serious accidents.
- Restore the layout of the electrical wiring harnesses exactly as it was prior to removal.
- Restore the attachments of the electrical wiring harnesses exactly as they were prior to removal.

Removing




The steering wheel must not be turned and the straight-ahead position or the steering angle of the front wheels must not be altered when the actuator has been removed. Otherwise the steering wheel may not be properly centred after the work is completed. It is important to keep all components clean when carrying out the following steps.

- Turn steering wheel to straight-ahead position (front and rear wheels must be in line) and allow steering lock to engage in straight-ahead position if possible.
- Switch off ignition. Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Remove dash panel cover (driver side) -2- ⇒ General body repairs, interior; Rep. gr. 68; Storage compartments/covers/ trim panels; Removing and installing dash panel cover (driver side).




- Mark position of active steering safety lock actuator -F437-(dynamic steering) -arrow- for subsequent installation.
- Unplug electrical connector -4- from actuator -3-.
- Clean paint residue out of heads of bolts -1 and 2-.
- Remove bolts -1 and 2- and detach actuator -3- from steering column.
- To remove bolts -1 and 2-, use socket provided in repair kit for new actuator.

Installing

Protected by copyright. Copying for private or commercial purpose Installation is carried out in reverse sequence. Note the following:

- After renewing the active steering safety lock actuator -F437-(dynamic steering), you must perform a software update of the active steering control unit -J792-; start the corresponding program on the ⇒ Vehicle diagnostic tester in Guided Functions mode.
- If a new active steering safety lock actuator F437- (dynamic steering) is being installed, transfer the marking from the old actuator to the new actuator before installation.





A48-10721

Fit new actuator according to marking made before removal and secure with two new bolts -1 and 2- according to specifications in table below using socket supplied in repair kit.

Sequence	Bolt no.	Tightening torque
1	1	2 + 2 Nm
2	2	4 + 2 Nm
3	1	8 + 2 Nm
4	2	8 + 2 Nm

- Plug in electrical connector at actuator.
- Erase event memory.
- Drive vehicle to initialise system turn wheels to approx. 45° from the straight-ahead position in both directions.

Checking function

Road test vehicle in an area closed to traffic and check the func-




- ◆ Steering forced unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
- Self-centring pect to the correctness of information in this document. Copyright by AUDI AG.
- Play
- Noise
- ♦ Warning lamp
- Read out event memory after road test. The event memory must not show any faults.

2.6 Removing and installing intermediate steering shaft

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1331-



Removing

- Turn wheels to straight ahead position.
- Move steering wheel down and to rear as far as possible, making use of full range of steering column adjuster.
- Move driver's seat back as far as possible.
- Switch off ignition and remove ignition key.




To prevent unintentional turning, secure steering wheel in straight-ahead position with adhesive tape -arrow-.



Note


- Use adhesive tape that can be completely removed afterwards reial without leaving marks.
 permitted unless authorised by AUDI AG. AUDI AG does no
- Do not turn steering wheel while performing repair work, as otherwise airbag coil connector and return ring with slip ring -F138- could be damaged.
- Remove dash panel cover (driver side) ⇒ General body repairs, interior; Rep. gr. 68; Storage compartments/covers/trim panels; Removing and installing dash panel cover (driver side) .




CAUTION

Risk of burns from the exhaust system depending on the type of engine.

- Remove bolt -arrow-.
- Detach intermediate steering shaft -1- from steering rack -2-.
- Remove bolt -2- and detach intermediate steering shaft -3from steering column -1-.
- Remove noise insulation (rear) ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation .








Carefully fold back floor covering.

Remove nuts -arrows-.

Pull sealing boot off body.

Remove intermediate steering shaft towards passenger com-Protecte Partment right. Copying for private or commercial purposes, in part o perminstallingess authorised by AUDI AG. AUDI AG does not guarantee or acce with Installation is carried out in reverse sequence. Note the following: ht by







Note

Always clean threaded hole for bolt at universal joint (using a thread tap or similar).

- Before installing intermediate steering shaft, check that rubber grommet on sealing boot is properly fitted.
- When installed, arrow -1- must point upwards.




- Working from passenger compartment, bring intermediate steering shaft into installation position.
- When transporting the steering shaft, hold it by the upper steel shaft above the sealing boot as shown in the illustration.
- When fitting, hold the steering shaft with one hand on the sealing shell below the sealing boot and with the other hand on the lower steel shaft as shown in the illustration.





Risk of damage to steering shaft and sealing boot.

- The steering shaft must not be carried by holding the sealing boot.
- The sealing boot must not be pulled off the steering shaft.
- The joints must not be deflected further than the stop.





Then push intermediate steering shaft -1- onto steering rack -2- as far as stop and tighten bolt -arrow-.




With bolt ⇒ Item 1 (page 384) screwed in by hand, try to pull off intermediate steering shaft to check that it is correctly seated. Then tighten bolt ⇒ Item 1 (page 384).

The remaining installation steps are carried out in the reverse sequence.

Tightening torques


⇒ "2.1 Exploded view -



Removing and installing control unit for 2.7 electronic steering column lock - J764-

Special tools and workshop equipment required information in this document. Copyright by AUDI AG.

♦ Torque wrench - V.A.G 1783-



Vehicle diagnostic tester



Removing



Before removing the steering column, please note the following

Draw a sketch showing

- the layout of the electrical wiring harnesses
- Prote de the attachment of the electrical wiring harnesses in part or in whole, is not
- permitting locations of the cable ties! AG does not guarantee or accept any liability
- with This applies particularly to the wiring harness for the control unitght by AUDI AG. for electronic steering column lock - J764- .

Before installing the steering column, please note the following points:

- Restore the layout of the electrical wiring harnesses exactly as it was prior to removal.
- Restore the attachments of the electrical wiring harnesses exactly as they were prior to removal.
- All cable ties unfastened or cut open when removing the steering column must be re-attached in the same position when refitting it.
- When adjusting the steering column, check that the wiring harness leading to the control unit for electronic steering column lock - J764- is not trapped and does not come into contact with any sharp edges.
- When renewing control unit, select "Replace" function for relevant control unit using > Vehicle diagnostic tester in Guided Functions mode.
- Remove steering column ⇒ page 387.
- Remove bolt -1- and detach control unit for electronic steering column lock - J764- -2-.




After removing the control unit, make sure no dirt or foreign bodies get into the steering column.

Installing


Installation is carried out in reverse sequence. Note the following:

- If only the control unit for electronic steering column lock -J764- has been renewed, the original bolt for securing the control unit can be re-used.
- If the steering column has been renewed, remove the protective cover and use the bolt fitted in the new steering column to secure control unit for electronic steering column lock - J764-.






To install control unit for electronic steering column lock -J764-, insert lug -arrow A- into groove -arrow B- on steering column and press control unit for electronic steering column lock - J764- firmly onto steering column by hand.



- When entire surface of control unit for electronic steering column lock - J764- -2- makes flush contact with steering column, fit bolt -1- and tighten.
- Install steering column ⇒ page 387.
- If the warning lamp for the steering angle sender G85- lights up in the instrument cluster, rectify the fault and perform the basic setting for the dynamic steering if necessary ⇒ page 355

Tightening torques

⇒ "2.1 Exploded view - steering column", page 381



2.8 Removing and installing control unit for electrically adjustable steering column -J866-

Special tools and workshop equipment required

◆ Torque wrench - V.A.G 1410-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI

Vehicle diagnostic tester with respect to the correctness of information in this document. Copyright by AUDI AG.



Removing

- When renewing control unit, select "Replace" function for relevant control unit using ⇒ Vehicle diagnostic tester in Guided Functions mode.
- Remove steering column ⇒ page 387.
- Unplug connector -1-.
- Remove bolt -2-.
- Slightly lift control unit for electrically adjustable steering column - J866- -3- and remove from steering column in direction of -arrow-.


Installing


Installation is carried out in reverse sequence. Note the following:

- To install control unit for electrically adjustable steering column - J866-, insert lug -1- into groove -arrow- on steering column -2-.
- Basic setting of steering column must be performed if control unit for electrically adjustable steering column - J866- has been renewed.
- Connect vehicle diagnostic tester and start Guided Functions for the vehicle in question.
- Select the relevant program in Guided Functions, "09 -Electronic central electrics".
- Follow the instructions on the screen.

Tightening torques

◆ ⇒ "2.1 Exploded view - steering column", page 381







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



3 Steering rack

- ⇒ "3.1 Exploded view steering rack", page 402
- ⇒ "3.2 Removing and installing steering rack", page 407
- ⇒ "3.3 Removing and installing boot", page 411
- ⇒ "3.4 Removing and installing track rod", page 416
- ⇒ "3.5 Removing and installing track rod ball joint", page 421

3.1 Exploded view - steering rack

- ⇒ "3.1.1 Exploded view steering rack with track rods", page 402
- ⇒ "3.1.2 Exploded view steering rack", page 403

3.1.1 Exploded view - steering rack with track rods


- 1 Electromechanical steering rack with track rods
 - With power steering control unit 1500 piless a
 - □ Removing and installing ⇒ page 407
 - Servicing ⇒ page 403
 - Different versions available ⇒ Electronic parts catalogue

A removable heat insulation mat was fitted on the steering rack at the start of production. This heat insulation mat must also be fitted when re-installing the old steering rack.

During the course of production, this heat insulation mat was replaced by a new mat which is permanently bonded onto the steering rack. With this type of steering rack, it is not necessary to transfer the removable mat from the old steering rack to the new one.

Replacement steering racks are always supplied with a permanently bonded heat insulation mat.

- 2 Bolt
 - 80 Nm +180°
 - □ Always renew if removed
- 3 Subframe
- 4 Nut
 - ☐ Inserted into subframe
 - Always renew if removed





- 5 Intermediate steering shaft
- 6 Bolt
 - ☐ Tightening torque ⇒ Item 1 (page 382)
- 7 Wheel bearing housing
- 8 Nut
 - □ 100 Nm
 - □ Always renew if removed

3.1.2 Exploded view - steering rack

This overview is applicable to LHD and RHD vehicles (layout is similar).



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Note

- PRenew self-locking nuts and bolts rivate or commercial purposes, in part or in whole, is not
- pWelding and straightening work on steering components is not permitted pt any liability
- Use only power steering rack grease to grease rack (pinion side) and ball races (motor side). Important: different types of grease are required for the left and right sides; for correct type refer to ⇒ Électronic parts catalogue .
- Hose clips -1 and 8- are tightened with different tightening torques.

1 - Hose clip


- □ Always renew if removed
- Use clamp tensioner to tighten hose clip ⇒ page 406



Note

The new hose clip should not be opened.

- □ For correct version refer to ⇒ Electronic parts catalogue
- 2 Track rod
 - □ 100 Nm
 - Removing and installing ⇒ page 416
 - Grease joint with power steering rack grease
 - ☐ If track rod is bent and needs to be renewed, track control link on this side of vehicle is also damaged and must be renewed
- 3 Electromechanical steering rack
 - Removing and installing ⇒ page 407
 - Grease rack with power steering rack grease. Important: different types of grease are required for the left and



right sides; for correct type refer to ⇒ Electronic parts catalogue.

☐ Different versions available ⇒ Electronic parts catalogue

A removable heat insulation mat was fitted on the steering rack at the start of production. This heat insulation mat must also be fitted when re-installing the old steering rack.

During the course of production, this heat insulation mat was replaced by a new mat which is permanently bonded onto the steering rack. With this type of steering rack, it is not necessary to transfer the removable mat from the old steering rack to the new one.

Replacement steering racks are always supplied with a permanently bonded heat insulation mat.




4 - Tı	rack rod ball joint
	Removing and installing <u>⇒ page 421</u>
	Check that dust caps are seated correctly and not damaged rposes, in part or in whole, is not
	Specified dimension range 406 AUDI AG. AUDI AG does not guarantee or accept any liability
	If track rod ball joint is bent and needs to be renewed, track control link on this side of vehicle is also damaged and must be renewed
5 - N	ut
	80 Nm
	Counterhold track rod ball joint when loosening and tightening
6 - S	pring-type clip
	Always renew if removed
	Installing spring-type clip ⇒ page 407
7 - B	oot
	Check for damage
	,
	grease ⇒ ETKA - Electronic parts catalogue .
	Before installation, check boot seating surface on steering rack housing for damage. If sealing surface on steering rack housing is damaged, steering rack must be renewed.
	g
u	Must be installed correctly <u>⇒ page 407</u>
.	
	ose clip
	Always renew if removed
u	Use clamp tensioner to tighten hose clip <u>⇒ page 406</u>
i	Note
	The new hose clip should not be opened.
	For correct version refer to ⇒ Electronic parts catalogue
	rack rod
_	100 Nm
	Removing and installing <u>⇒ page 416</u> Grease joint with power steering rack grease
	If track rod is bent and needs to be renewed, track control link on this side of vehicle is also damaged
_	and must be renewed
10 - ⁻	Track rod ball joint
	Removing and installing <u>⇒ page 421</u>
	Check that dust caps are seated correctly and not damaged
	Specified dimension ⇒ page 406
	If track rod ball joint is bent and needs to be renewed, track control link on this side of vehicle is also damaged and must be renewed
11 - I	Nut
	80 Nm
	Counterhold track rod ball joint when loosening and tightening
12 - \$	Spring-type clip
	Always renew if removed
	Installing spring-type clip ⇒ page 407

13 - Boot

- Check for damage
- Always renew if removed
- ☐ Before installation, grease evenly all round inside of boot seating surfaces with power steering rack grease ⇒ ETKA - Electronic parts catalogue.
- Before installation, check boot seating surface on steering rack housing for damage. If sealing surface on steering rack housing is damaged, steering rack must be renewed.
- Must not be twisted when adjusting toe setting
- Must be installed correctly ⇒ page 407
- □ Renewing ⇒ page 411

Specified dimension for track rod ball joint


- Apply steel ruler -2- to track rod ball joint -1- and slide as far as rolled edge -arrow- on end of track rod ball joint.
- The entire steering rack with track rod, track rod ball joint and track rod control link (on the corresponding side) must be re- does newed if dimension -a- is less than 188 mm.



Tightening hose clip (inner)

- Apply clamp tensioner -1-, as shown in illustration. Ensure jaws of tool make contact with lugs -arrows- on hose clip.
- Tighten clip by turning spindle with torque wrench -2- (take care to keep tool straight).
- Use torque wrench -2- with adjustment range 5 ... 50 Nm (e.g. -V.A.G 1331-).
- Make sure thread of spindle on tool -1- turns freely. Lubricate with MoS2 grease if necessary.
- If the thread is stiff (e.g. due to dirt), the required clamping force will not be attained at the hose clip when the specified tightening torque is applied.


Type of hose clip	Clamp tensioner - V.A.G 1682 A- with adapter -V.A.G 1682 A/1- (Hazet)	Clamp tensioner - V.A.G 1682- with adapter -V.A.G 1682 A/1- (Ötiker)
Hose clip Ø 85 mm (passenger side) ⇒ Item 8 (page 405)	7 Nm	9 Nm
Hose clip Ø 59 mm (driver side) ⇒ Item 1 (page 404)	10 Nm	12 Nm





Installing rubber boot (outer):

• Dimension -a- = 2 mm



3.2 Removing and installing steering rack



Note

The power steering rack is removed and installed complete with track rods.

A removable heat insulation mat was fitted on the steering rack at the start of production. This heat insulation mat must also be fitted when re-installing the old steering rack.

During the course of production, this heat insulation mat was replaced by a new mat which is permanently bonded onto the steering rack. With this type of steering rack, it is not necessary to transfer the removable mat from the old steering rack to the new one: d by copyright. Copying for private or commercial purposes, in part or in whole, is not new one d by copyright. Copying

Replacement steering racks are always supplied with a permarantee or accept any liability nently bonded heat insulation mat information in this document. Copyright by AUDI AG.

Special tools and workshop equipment required


♦ Torque wrench - V.A.G 1331-




◆ Torque wrench - V.A.G 1332-



Ring spanner insert - V.A.G 1332/7-



Ball joint puller - T40010 A-




Removing

- Turn wheels to straight ahead position.
- Switch off ignition and remove ignition key.
- To prevent unintentional turning, secure steering wheel in straight-ahead position with adhesive tape -arrow-.



Note



◆PrDo not turn steering wheel while performing repair work, asses, in otherwise airbag coil connector and return ring with slip ring -PF138- could be damaged.by

with respect to the correctness of information in this document. Copyr

Remove front wheels ⇒ page 329.






Unscrew nut -1- on joint pin -2- of track rod ball joint until it is flush with end of thread. Counterhold if necessary when loosening.



Note

Leave nut screwed on a few turns to protect threads on joint pin.




Press track rod ball joint off wheel bearing housing using ball joint puller - T40010 A- . Then remove nut.




Note

Make sure the two lever arms of the puller are parallel when maximum force is exerted; adjust as necessary.




Remove noise insulation panels -1 and 2- ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation.



- Unscrew nuts -arrows- and lower anti-roll bar.



Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG with respect to the correctness of information in this





Release clip -arrow-, unplug electrical connector -1- and move electrical wiring clear.



Protected by copyright. Copying for private or commercial purpo

- Release remaining clips -arrows- on cross brace and move wiring harness clears authorised by AUDI AG. AUI
- Remove cross brace page 54: of information in this document





Risk of damage to running gear components.


- Never place the vehicle on its wheels if the subframe mounting, steering rack or subframe cross brace is not correctly installed!
- The vehicle must not be supported on the subframe or the subframe cross brace (e.g. using a trolley jack or similar)!


- Remove bolt -arrow-.
- Pull intermediate steering shaft -1- off steering rack -2- and secure intermediate steering shaft to prevent it from slipping out.

- Release retainer, press catch downwards and unplug electrical connector -1- for signal wires (CAN bus and terminal 15) at power steering control unit - J500-.
- Unplug electrical connector -2- for voltage supply (terminal 30) at power steering control unit J500- (release retainer -arrow- and push catch downwards).










- Remove bolts -1, 2- and remove guard plate, if fitted.
- Push steering rack slightly to the side-arrow A- and take out from below -arrow B-


Protected by copyright. Copying for private or commercial purp permitted unless authorised by AUDI AG. AUDI AG does not gu with respect to the correctness of information in this documer



Installing

Installation is carried out in reverse sequence. Note the following:

Screw in bolts -1 and 2- loosely at first, then tighten.





With bolt <u>⇒ Item 1 (page 384)</u> screwed in by hand, try to pull off intermediate steering shaft to check that it is correctly seated. Then tighten bolt ⇒ Item 1 (page 384).

- Install anti-roll bar ⇒ page 53.
- Install cross brace ⇒ page 51.

If a new electromechanical steering rack has been installed, start the program J 500 Replace control unit in the ⇒ Vehicle diagnostic tester using the Guided Fault Finding function.


Check and adjust wheel alignment ⇒ page 330.

Tightening torques

♦ ⇒ "3.1.1 Exploded view - steering rack with track rods", page 402

3.3 Removing and installing boot

Special tools and workshop equipment required



Torque wrench - V.A.G 1331-


V.A.G 1331 W00-11166

Torque wrench - V.A.G 1332-


Protected by copyright. Copying for private or con mercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does with respect to the correctness of information in this document. Copyright by AUDI AG.

V.A.G 1332 W00-11165

Ring spanner insert - V.A.G 1332/7-




Hose clip pliers - V.A.G 1921-






Clamp tensioner - V.A.G 1682 A- with adapter -V.A.G 1682 A/



◆ Ball joint puller - T40010 A-



n this document. Copyright by AUDI AG.

Removing

Boot must always be renewed following removal.

CAUTION

commercial purposes, in part or in whole, is not If boot is damaged, moisture and dirt can enter steering rack and cause irreparable damage less authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- A film of lubricant should be visible on and around the teeth of the steering rack. Renew steering rack if no film of lubricant is present.
- When cleaning the steering rack and surrounding components, removing steering rack components and lubricating the steering rack, ensure that no dirt enters the steering rack through the defective rubber boot.
- Remove front wheel ⇒ page 329.
- Turn wheels to straight ahead position.
- Remove noise insulation ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation .
- Clean power steering rack and subframe in vicinity of rubber boot.




No dirt must be allowed to enter the steering rack through a defective rubber boot during this operation.



Unscrew nut -1- on joint pin -2- of track rod ball joint until it is flush with end of thread. Counterhold if necessary when loos-

Leave nut screwed on a few turns to protect threads on joint pin.




Press track rod ball joint off wheel bearing housing using ball joint puller - T40010 A- . Then remove nut.



Note


Make sure the two lever arms of the puller are parallel when maximum force is exerted; adjust as necessary.




Protected by copyright. Copying for private or commercial purposes, in

Mark position of nut -2- on track rod -1- for refitting.

Loosen nut -2- (counterhold track rod ball joint -3-).



- Release spring-type clip -3- using hose clip pliers -V.A.G 1921- and detach.
- Detach hose clip -1- and pull boot -2- outwards off power steering rack.






- Unscrew track rod ball joint -3- and nut -2- from track rod -1-.
- Detach rubber boot with spring-type clip from track rod.



Note

- Renew the complete steering rack unit if there are signs of corrosion, damage, wear or dirt on the rack.
- The complete steering rack unit must also be renewed if there is no visible lubricating film on the rack.



Installing

Installation is carried out in reverse sequence. Note the following: mmercial purposes, in part or in whole, is not Boot must always be renewed following removal AUDI AG. AUDI AG does not guarantee or accept any liability

Before installation grease evenly all round inside of boot seating this document. Copyright by AUDI AG. surface with power steering rack grease ⇒ ETKA - Electronic parts catalogue.

Before installation, check boot seating surface on steering rack housing for damage. If sealing surface on steering rack housing is damaged, steering rack must be renewed.

The rack must be lubricated with grease supplied in the repair kit before installing.



Do NOT use any other type of grease.

For this procedure turn steering to full lock in both directions.

A removed steering rack is shown for ease of illustration.


Grease the rack on the side with the teeth -A- and on the side that contacts the thrust pieces.




Note

Use only power steering rack grease for greasing rack. Important: different types of grease are required for the left and right sides; for correct type refer to ⇒ Electronic parts catalogue .


- Turn wheels to straight ahead position.
- Fit new hose clips and rubber boot onto track rod.
- Screw in nut -1- and track rod ball joint -3- as far as marking made when removing.
- Tighten nut -2- to specified torque. Counterhold at track rod ball joint -3-. Fit rubber boot with new hose clip onto steering rack housing.
- Make sure that boot is correctly seated on power steering rack.
- Boot must engage in groove and make contact with contour of power steering rack.






Installing hose clip (inner)

- Apply clamp tensioner as shown. Ensure jaws of tool make contact with lugs -arrows- on hose clip ⇒ page 406.
- Tighten hose clip by turning spindle with torque wrench (take care to keep clamp tensioner straight).
- Tightening torque ⇒ page 406
- Use torque wrench with 5, 550 Nm adjustment range (e.g. mmercia V.A.G 1331-).
- permitted unless authorised by AUDI AG. AUDI AG does Make sure thread of spindle on tool -1- turns freely. Lubricate with MoS2 grease if necessary or rectness of inform
- If the thread is stiff (e.g. due to dirt), the required clamping force will not be attained at the hose clip when the specified tightening torque is applied.
- Secure spring-type clip -3- on boot -2- with hose clip pliers -V.A.G 1921- .





Installing rubber boot (outer):

Dimension -a- = 2 mm

The remaining installation steps are carried out in the reverse sequence.

Check and adjust wheel alignment as required, see chart ⇒ page 344 .


Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.

Tightening torques

- ⇒ "3.1.2 Exploded view steering rack", page 403
- ⇒ "3.1.1 Exploded view steering rack with track rods", page 402

3.4 Removing and installing track rod

Special tools and workshop equipment required





◆ Torque wrench - V.A.G 1331-



♦ Torque wrench - V.A.G 1332-



◆ Ring spanner insert - V.A.G 1332/7-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is no permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



♦ Hose clip pliers - V.A.G 1921-





Open-end spanner attachment - V.A.G 1923-




Clamp tensioner - V.A.G 1682 A- with adapter -V.A.G 1682 A/



Protected by copyright. Copying for private or commercial purposes permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabition of the permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabition of the permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabition of the permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabition of the permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabition of the permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabition of the permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabition of the permitted unless authorised by AUDI AG. with respect to the correctness of information in this doc



Ball joint puller - T40010 A-



Removing

The track rods can be removed and installed with the steering rack in the vehicle.

- Remove front wheel ⇒ page 329.
- Remove noise insulation ⇒ General body repairs, exterior; Rep. gr. 66; Noise insulation; Removing and installing noise insulation .





- Measure and note down dimension -a- between track rod ball joint -1- and track rod -2- on both sides. Dimension -a- should be the same on both sides after installation.
- If necessary, shorten the "longer" track rod ball joint (by screwing it further onto the track rod).
- Clean power steering rack and subframe in vicinity of rubber boot.



Take care to prevent dirt from entering the power steering rack and boot when renewing the track rod.

- Release spring-type clip -3- using hose clip pliers -V.A.G 1921- and detach.
- Detach hose clip -1- and pull boot -2- outwards off power steering rack.






Unscrew nut -1- on joint pin -2- of track rod ball joint until it is flush with end of thread. Counterhold if necessary when loosening.

Leave nut screwed on a few turns to protect threads on joint pin.

Protected by copyright. Copying for private or commercial p permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this docum




Press track rod ball joint off wheel bearing housing using ball joint puller - T40010 A- . Then remove nut.



Note

Make sure the two lever arms of the puller are parallel when maximum force is exerted; adjust as necessary.



- Unscrew track rod. When doing so, counterhold piston rod of power steering rack using open-end spanner -1-.
- 2 Open-end spanner attachment V.A.G 1923-

Installing


Installation is carried out in reverse sequence. Note the following:


Boot must always be renewed following removal.

Before installation, grease evenly all round inside of boot seating surfaces with steering rack grease ⇒ ETKA - Electronic parts catalogue.

Before installation, check boot seating surface on steering rack housing for damage. If sealing surface on steering rack housing is damaged, steering rack must be renewed.

Attach track rod using open-end spanner attachment -V.A.G 1923- -2-. When doing so, counterhold piston rod of power steering rack using open-end spanner -1-.








Protected by copyright. Copying for private or

- Renew spring-type clips-3+ and O-type-hose clips-1/2 AUDI AG. AUDI Installing hose clip: with respect to the correctness of information
- Fit new hose clip -1- and tighten ⇒ page 406.




Installing rubber boot

- Dimension -a- = 2 mm
- Align track rod so that pin of track rod ball joint is in installation position.
- Insert track rod into wheel bearing housing as far as the stop.
- Fit front wheel ⇒ page 329.
- Check and adjust wheel alignment as required, see chart ⇒ page 344 .

Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.

Tightening torques

- ⇒ "3.1.1 Exploded view steering rack with track rods", page 402
- ⇒ "3.1.2 Exploded view steering rack", page 403





Removing and installing track rod ball 3.5 joint

Special tools and workshop equipment required


♦ Torque wrench - V.A.G 1331-



♦ Torque wrench - V.A.G 1332-




Ring spanner insert - V.A.G 1332/7-



♦ Ball joint puller - T40010 A-




Protected by copyright. Copying for private or commercial purposes, in part of permitted unless authorised by AUDI AG. AUDI AG does not guarantee or ac with respect to the correctness of information in this document. Copyright



Removing

- Remove front wheel ⇒ page 329
- Measure and note down dimension -a- between track rod ball joint -1- and track rod -2- on both sides. Dimension -a- should be the same on both sides after installatione or commercial purpose
- If necessary, shorten the "longer" tracking ballijoint (by screw-quara ing it further onto the track rod).




Unscrew nut -1- on joint pin -2- of track rod ball joint until it is flush with end of thread. Counterhold if necessary when loosening.



Note

Leave nut screwed on a few turns to protect threads on joint pin.




Press track rod ball joint off wheel bearing housing using ball joint puller - T40010 A- . Then remove nut.



Note


Make sure the two lever arms of the puller are parallel when maximum force is exerted; adjust as necessary.



- Just slacken nut -2- but do not remove. Counterhold at track rod ball joint -3-.
- Unscrew track rod ball joint -3-.

Installing


Installation is carried out in reverse sequence. Note the following:





- Screw track rod ball joint -1- onto track rod -2- until dimension -a- measured on removal is obtained.
- Align track rod so that pin of track rod ball joint -1- is in installation position.
- Insert track rod ball joint into wheel bearing housing as far as the stop.
- A48-10709

Tighten nut -1-. Counterhold if necessary when tightening.




- Tighten nut -2-.
- Fit front wheel ⇒ page 329.
- Check and adjust wheel alignment as required, see chart ⇒ page 344 .

Wheel alignment must always be checked and adjusted if necessary using VW/Audi-approved equipment.

Tightening torques

- ⇒ "3.1.1 Exploded view steering rack with track rods",
- ⇒ "3.1.2 Exploded view steering rack", page 403





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.